



322 L



325 L X-SERIES



325 L XT-SERIES

325 RJX-SERIES


Spare parts
Ersatzteile
Pièces détachées
Reserve onderdelen
Repuestos
Reservdelar

A**B**


C***compl 503 94 11-01****D**

E**F**


G




H





J







K




L**M***Compl 503 28 31-10***ZAMA C1Q - EL 11**

N Accessories
 Zubehöre
 Accessoires
 Acessorios
 Tillbehör



*compl 503 97 71-01



| PART NUMBER | SQUARE | NOTE | PART NUMBER | SQUARE | NOTE | PART NUMBER | SQUARE | NOTE | PART NUMBER | SQUARE | NOTE |
|--------------|--------|------|--------------|--------|------|--------------|--------|------|-------------|--------|------|
| 501 60 02-02 | N | | 503 85 89-01 | F | | 537 01 97-01 | M | | | | |
| 501 78 33-01 | N | | 503 86 45-01 | A | | 537 01 98-01 | M | | | | |
| 502 03 55-05 | N | | 503 87 17-01 | J | | 537 01 99-01 | M | | | | |
| 502 11 46-02 | N | | 503 87 18-01 | D | | 537 02 00-01 | M | | | | |
| 502 19 71-01 | A | | 503 87 19-01 | A | | 537 02 01-01 | M | | | | |
| 502 20 38-01 | A | | 503 87 19-03 | A | | 537 02 02-01 | M | | | | |
| 502 20 40-01 | E | | 503 87 21-01 | D | | 537 02 03-01 | M | | | | |
| 502 20 65-03 | E | | 503 87 26-01 | K | | 537 02 04-01 | M | | | | |
| 502 21 58-01 | N | | 503 87 28-01 | H | | 537 02 05-01 | M | | | | |
| 502 28 59-01 | N | | 503 87 33-01 | F | | 537 02 06-01 | M | | | | |
| | | | | | | | | | | | |
| 502 51 27-01 | N | | 503 87 35-01 | F | | 537 02 07-01 | M | | | | |
| 503 20 02-10 | A | | 503 87 36-01 | F | | 537 02 09-01 | M | | | | |
| 503 20 02-16 | A | | 503 87 79-01 | B | | 537 02 10-01 | M | | | | |
| 503 20 02-25 | C | | 503 87 80-01 | B | | 537 02 11-01 | M | | | | |
| 503 20 02-35 | J | | 503 87 85-01 | B | | 537 02 16-01 | M | | | | |
| 503 20 03-25 | E | | 503 87 90-01 | A | | 537 03 20-02 | J | | | | |
| 503 20 07-25 | A | | 503 88 79-01 | E | | 537 03 20-04 | J | | | | |
| 503 20 14-12 | C | | 503 88 80-01 | E | | 537 03 22-01 | H | | | | |
| 503 20 25-16 | C | | 503 88 81-01 | E | | 537 03 23-01 | K | | | | |
| 503 20 29-50 | J | | 503 88 88-01 | A | | 537 03 24-01 | K | | | | |
| | | | | | | | | | | | |
| 503 21 07-16 | N | | 503 89 01-01 | N | | 537 03 41-01 | F | | | | |
| 503 21 71-20 | BFH | | 503 89 03-01 | E | | 537 04 10-01 | C | | | | |
| 503 21 75-16 | AE | | 503 91 09-01 | E | | 537 04 11-01 | K | | | | |
| 503 21 75-20 | DFK | | 503 91 10-01 | G | | 537 04 12-01 | K | | | | |
| 503 21 75-25 | K | | 503 91 18-02 | G | | 537 04 23-01 | H | | | | |
| 503 21 75-50 | E | | 503 91 81-01 | B | | 537 04 24-01 | G | | | | |
| 503 21 77-16 | F | | 503 93 42-02 | N | | 537 04 58-01 | H | | | | |
| 503 21 83-16 | N | | 503 93 55-01 | C | | 537 04 64-01 | C | | | | |
| 503 22 65-04 | E | | 503 93 66-01 | G | | 537 04 67-01 | H | | | | |
| 503 23 00-61 | A | | 503 94 02-01 | L | | 537 04 68-01 | H | | | | |
| | | | | | | | | | | | |
| 503 23 51-08 | H | | 503 94 03-01 | A | | 537 05 23-01 | G | | | | |
| 503 28 31-10 | EM | | 503 94 05-01 | L | | 537 05 25-01 | B | | | | |
| 503 28 90-30 | J | | 503 94 10-01 | A | | 537 06 86-01 | G | | | | |
| 503 28 90-38 | J | | 503 94 11-01 | C | | 537 08 27-01 | A | | | | |
| 503 44 32-01 | G | | 503 94 12-01 | C | | 537 08 30-01 | A | | | | |
| 503 47 89-01 | M | | 503 94 14-01 | C | | 725 23 70-51 | C | | | | |
| 503 47 90-01 | M | | 503 94 26-01 | E | | 725 23 78-51 | A | | | | |
| 503 47 92-01 | M | | 503 95 97-01 | C | | 725 23 79-51 | A | | | | |
| 503 47 96-01 | M | | 503 96 13-01 | BD | | 725 23 80-51 | A | | | | |
| 503 47 97-01 | M | | 503 96 14-01 | B | | 731 23 12-01 | C | | | | |
| | | | | | | | | | | | |
| 503 48 00-01 | M | | 503 96 25-01 | E | | 731 23 14-01 | AE | | | | |
| 503 48 01-01 | M | | 503 96 49-01 | F | | 731 71 16-51 | FH | | | | |
| 503 48 02-01 | M | | 503 97 21-01 | D | | 735 31 08-20 | F | | | | |
| 503 48 05-01 | M | | 503 97 43-01 | M | | 735 31 11-00 | C | | | | |
| 503 48 08-01 | M | | 503 97 71-01 | N | | 735 31 25-10 | C | | | | |
| 503 48 11-01 | M | | 503 97 98-02 | F | | 735 31 28-10 | C | | | | |
| 503 48 16-01 | M | | 503 97 98-14 | F | | 735 58 08-10 | A | | | | |
| 503 48 18-01 | M | | 503 97 98-17 | F | | 737 44 08-00 | J | | | | |
| 503 48 19-01 | M | | 503 97 98-27 | F | | 738 21 01-04 | C | | | | |
| 503 49 71-01 | E | | 503 98 12-02 | D | | 738 21 01-10 | L | | | | |
| | | | | | | | | | | | |
| 503 53 57-01 | M | | 503 98 12-04 | D | | 738 21 99-00 | C | | | | |
| 503 66 59-01 | M | | 503 98 12-07 | D | | 738 22 96-15 | C | | | | |
| 503 71 22-01 | JL | | 503 98 12-14 | D | | 740 42 06-00 | B | | | | |
| 503 71 48-01 | C | | 503 98 54-01 | A | | 740 43 15-00 | A | | | | |
| 503 71 54-01 | A | | 503 99 55-01 | B | | | | | | | |
| 503 71 82-01 | B | | 503 99 55-02 | B | | | | | | | |
| 503 71 86-03 | A | | 503 99 56-01 | B | | | | | | | |
| 503 74 16-01 | N | | 503 99 56-02 | B | | | | | | | |
| 503 74 16-02 | N | | 503 99 78-01 | A | | | | | | | |
| 503 75 53-01 | M | | 537 00 84-01 | F | | | | | | | |
| | | | | | | | | | | | |
| 503 78 52-01 | A | | 537 01 13-01 | B | | | | | | | |
| 503 79 88-01 | N | | 537 01 16-01 | A | | | | | | | |
| 503 81 60-01 | H | | 537 01 19-01 | A | | | | | | | |
| 503 83 61-01 | L | | 537 01 25-01 | M | | | | | | | |
| 503 84 28-01 | H | | 537 01 26-01 | M | | | | | | | |
| 503 84 29-01 | H | | 537 01 30-01 | C | | | | | | | |
| 503 85 24-73 | L | | 537 01 32-72 | J | | | | | | | |
| 503 85 27-71 | J | | 537 01 32-74 | J | | | | | | | |
| 503 85 28-01 | F | | 537 01 41-01 | J | | | | | | | |
| 503 85 87-01 | F | | 537 01 96-01 | M | | | | | | | |