

# 324HDA55<sub>X-SERIES</sub>

**Spare parts**

**Ersatzteile**

**Pièces détachées**

**Reserve onderdelen**

**Repuestos**

**Reservdelar**

Replaces

Ersetzt

Remplace


Vervangt


Reemplaza

Ersätter


106 40 14-61

## 324HDA55x







**C** 324HDA55x  
compl 537 14 86-18




**D** 324HDA55x

\*544 04 41-01




# E

324HDA55x  
\*compl 503 85 29-06




# F




# G


\*compl 531 00 86-41



# H




# J




# K


\*compl 531 00 86-96



**L**




**M**






# N




P








Q

\*compl 531 00 86-81 Walbro WYB-6B

Walbro WYB-6B



**R** Accessories  
 Zubehöre  
 Accessoires  
 Acessorios  
 Tillbehör  
 \*compl 537 30 14-17



| PART NUMBER  | SQUARE NOTE | PART NUMBER  | SQUARE NOTE | PART NUMBER  | SQUARE NOTE | PART NUMBER  | SQUARE NOTE |
|--------------|-------------|--------------|-------------|--------------|-------------|--------------|-------------|
| 502 19 71-01 | D           | 531 00 86-51 | FGHJ        | 531 00 87-27 | N           | 740 42 06-00 | E           |
| 502 28 61-01 | F           | 531 00 86-52 | G           | 531 00 87-28 | F           |              |             |
| 503 20 07-25 | A           | 531 00 86-53 | GJ          | 531 00 87-29 | M           |              |             |
| 503 20 14-12 | A           | 531 00 86-54 | M           | 531 00 92-05 | R           |              |             |
| 503 20 17-22 | B           | 531 00 86-55 | M           | 531 00 92-71 | R           |              |             |
| 503 21 66-18 | E           | 531 00 86-56 | M           | 537 00 84-01 | G           |              |             |
| 503 21 68-25 | M           | 531 00 86-57 | M           | 537 01 13-01 | E           |              |             |
| 503 21 75-16 | D           | 531 00 86-59 | Q           | 537 08 86-01 | D           |              |             |
| 503 22 10-12 | AB          | 531 00 86-60 | Q           | 537 09 10-01 | D           |              |             |
| 503 22 75-02 | B           | 531 00 86-61 | Q           | 537 09 11-01 | D           |              |             |
| 503 23 00-24 | B           | 531 00 86-62 | Q           | 537 14 86-18 | C           | N            |             |
| 503 23 03-02 | A           | 531 00 86-63 | Q           | 537 23 16-01 | A           | N            |             |
| 503 25 05-01 | M           | 531 00 86-64 | Q           | 537 23 17-01 | A           | N            |             |
| 503 55 86-05 | R           | 531 00 86-65 | Q           | 537 23 18-01 | A           | N            |             |
| 503 71 82-01 | E           | 531 00 86-66 | Q           | 537 23 20-01 | A           | N            |             |
| 503 85 29-06 | E           | 531 00 86-67 | Q           | 537 23 21-01 | A           | N            |             |
| 503 87 19-03 | D           | 531 00 86-68 | Q           | 537 23 22-01 | A           | N            |             |
| 503 87 79-01 | E           | 531 00 86-69 | Q           | 537 23 26-01 | A           | N            |             |
| 503 87 80-01 | E           | 531 00 86-70 | Q           | 537 23 28-01 | A           | N            |             |
| 503 91 81-01 | E           | 531 00 86-71 | Q           | 537 23 35-01 | A           | N            |             |
| 503 94 03-01 | D           | 531 00 86-72 | Q           | 537 23 36-01 | A           | N            |             |
| 503 96 13-01 | E           | 531 00 86-73 | Q           | 537 23 37-01 | A           | N            |             |
| 503 96 14-01 | E           | 531 00 86-74 | Q           | 537 23 42-01 | A           | N            |             |
| 503 98 96-01 | R           | 531 00 86-75 | Q           | 537 28 38-01 | B           | N            |             |
| 503 99 55-02 | E           | 531 00 86-76 | Q           | 537 28 39-01 | B           | N            |             |
| 503 99 56-02 | E           | 531 00 86-77 | Q           | 537 28 40-01 | B           | N            |             |
| 531 00 24-43 | Q           | 531 00 86-78 | Q           | 537 28 44-01 | B           | N            |             |
| 531 00 75-12 | R           | 531 00 86-79 | Q           | 537 29 42-01 | A           | N            |             |
| 531 00 75-13 | R           | 531 00 86-81 | HQ          | 537 30 14-17 | R           | N            |             |
| 531 00 86-08 | N           | 531 00 86-82 | H           | 537 30 96-01 | M           |              |             |
| 531 00 86-09 | N           | 531 00 86-83 | H           | 537 31 10-01 | M           |              |             |
| 531 00 86-10 | N           | 531 00 86-84 | H           | 537 31 11-01 | M           |              |             |
| 531 00 86-11 | N           | 531 00 86-86 | HQ          | 537 31 14-01 | H           |              |             |
| 531 00 86-12 | N           | 531 00 86-87 | H           | 537 31 16-01 | J           |              |             |
| 531 00 86-13 | N           | 531 00 86-88 | Q           | 537 33 51-01 | E           |              |             |
| 531 00 86-14 | N           | 531 00 86-89 | Q           | 537 33 67-01 | M           |              |             |
| 531 00 86-15 | N           | 531 00 86-90 | Q           | 537 34 15-01 | A           | N            |             |
| 531 00 86-16 | MN          | 531 00 86-91 | Q           | 537 34 18-01 | A           | N            |             |
| 531 00 86-17 | JN          | 531 00 86-92 | H           | 537 34 52-02 | G           |              |             |
| 531 00 86-18 | N           | 531 00 86-93 | H           | 537 34 53-02 | F           |              |             |
| 531 00 86-19 | N           | 531 00 86-94 | H           | 537 36 21-01 | R           |              |             |
| 531 00 86-20 | N           | 531 00 86-95 | H           | 537 39 49-01 | A           | N            |             |
| 531 00 86-21 | N           | 531 00 86-96 | K           | 537 40 48-01 | A           | N            |             |
| 531 00 86-22 | N           | 531 00 86-97 | K           | 537 40 64-02 | A           | N            |             |
| 531 00 86-23 | N           | 531 00 86-98 | K           | 537 41 66-01 | A           | N            |             |
| 531 00 86-24 | N           | 531 00 86-99 | K           | 537 44 23-01 | A           | N            |             |
| 531 00 86-25 | N           | 531 00 87-01 | K           | 544 00 48-01 | B           | N            |             |
| 531 00 86-26 | N           | 531 00 87-02 | K           | 544 04 41-01 | D           | N            |             |
| 531 00 86-27 | P           | 531 00 87-03 | K           | 544 06 40-01 | A           | N            |             |
| 531 00 86-28 | P           | 531 00 87-04 | J           | 544 09 31-01 | A           | N            |             |
| 531 00 86-29 | P           | 531 00 87-05 | J           | 544 11 89-01 | D           | N            |             |
| 531 00 86-30 | P           | 531 00 87-06 | J           | 725 23 78-51 | D           |              |             |
| 531 00 86-31 | P           | 531 00 87-08 | J           | 725 52 87-55 | A           |              |             |
| 531 00 86-32 | P           | 531 00 87-09 | J           | 725 52 91-01 | A           |              |             |
| 531 00 86-33 | P           | 531 00 87-10 | J           | 725 53 23-05 | A           |              |             |
| 531 00 86-34 | P           | 531 00 87-11 | J           | 725 53 25-55 | N           |              |             |
| 531 00 86-35 | P           | 531 00 87-12 | J           | 725 53 29-55 | A           |              |             |
| 531 00 86-36 | P           | 531 00 87-14 | L           | 725 53 70-55 | M           |              |             |
| 531 00 86-37 | P           | 531 00 87-15 | L           | 725 63 31-55 | B           |              |             |
| 531 00 86-38 | P           | 531 00 87-16 | L           | 732 25 16-01 | A           |              |             |
| 531 00 86-39 | P           | 531 00 87-17 | L           | 734 11 46-01 | A           |              |             |
| 531 00 86-40 | P           | 531 00 87-18 | L           | 734 11 52-01 | AD          |              |             |
| 531 00 86-41 | G           | 531 00 87-19 | L           | 735 31 11-00 | A           |              |             |
| 531 00 86-42 | G           | 531 00 87-20 | L           | 735 31 19-00 | A           |              |             |
| 531 00 86-43 | G           | 531 00 87-21 | N           | 735 31 25-10 | A           |              |             |
| 531 00 86-45 | G           | 531 00 87-22 | N           | 735 31 33-10 | A           |              |             |
| 531 00 86-46 | G           | 531 00 87-23 | N           | 737 38 52-00 | A           |              |             |
| 531 00 86-47 | G           | 531 00 87-24 | N           | 738 21 98-04 | A           |              |             |
| 531 00 86-49 | G           | 531 00 87-25 | N           | 738 21 99-04 | A           |              |             |
| 531 00 86-50 | G           | 531 00 87-26 | N           | 738 88 10-01 | A           |              |             |

Set of gaskets, Dichtungssats,  
Jeu de joints, Juego de juntas,  
Packningssats

N = New part, Neues teil,  
Nouvelle piece, Nueva pieza  
Ny detalj