

# 325HDA55<sub>X-SERIES</sub>

# 325HE3<sub>X-SERIES</sub>

# 325HE4<sub>X-SERIES</sub>

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

Replaces

Ersetzt

Remplace

Vervangt

Reemplaza

Ersätter



106 26 36-61

*E-tech*


# A

\*compl 537 12 63-01


## TYPE A




## TYPE B



# B 325HDA55




# B 325HE3




# B


325HE4




# C




# D




# E



# F




# G




# H

\*compl 537 06 86-02




# J


\* compl 537 13 75-01



# K




# L





# M






\*compl 503 85 24-74




# N

\*compl 537 04 07-11 (325 HE3, 325 HE4)  
\*compl 537 04 07-13 (325 HDA55)

**Accessories**  
**Zubehöre**  
**Accessoires**  
**Accessorios**  
**Tillbehör**





① 531 00 45-52  
**Set of gaskets**  
**Dichtungssatz**  
**Juego de juntas**  
**Jeu de joints**  
**Packningssats**

② 531 00 45-53  
**Repairkit**  
**Reparatursatz**  
**Juego de reparación**  
**Kit de réparation**  
**Reparationsssats**

① ② 537 02 00-01

① ② 537 02 01-01

MODEL 325HDA55X-SERIES, 325HE3X-SERIES, 325HE4X-SERIES

| PART NUMBER   | SQUARE NOTE | PART NUMBER  | SQUARE NOTE | PART NUMBER  | SQUARE NOTE | PART NUMBER  | SQUARE NOTE |
|---------------|-------------|--------------|-------------|--------------|-------------|--------------|-------------|
| 501 36 02-05  | C           | 503 88 80-01 | F           | 537 05 11-01 | H           | 737 44 08-00 | K           |
| 501 36 11-88  | C           | 503 88 81-01 | F           | 537 05 25-01 | D           | 738 21 01-10 | M           |
| 501 36 48-78  | C           | 503 88 88-01 | B           | 537 06 86-02 | H           | 738 88 10-01 | A           |
| 501 36 49-38  | C           | 503 89 03-01 | F           | 537 07 36-01 | L           | 740 42 06-00 | D           |
| 501 69 17-01  | N           | 503 91 09-01 | F           | 537 08 27-01 | B           |              |             |
| 502 19 71-01  | B           | 503 91 10-01 | H           | 537 08 39-01 | B           |              |             |
| 502 20 40-01  | F           | 503 91 18-02 | H           | 537 08 55-01 | B           |              |             |
| 502 20 65-03  | F           | 503 91 81-01 | D           | 537 08 86-01 | BL          |              |             |
| 502 21 58-01  | N           | 503 93 66-01 | H           | 537 09 10-01 | B           |              |             |
| 503 20 02-35  | K           | 503 94 02-01 | M           | 537 09 11-01 | B           |              |             |
| 503 20 03-25  | F           | 503 94 03-01 | B           | 537 09 12-01 | B           |              |             |
| 503 20 07-16  | B           | 503 94 05-01 | M           | 537 09 52-01 | B           |              |             |
| 503 20 29-50  | K           | 503 94 10-01 | B           | 537 10 44-01 | E           | N            |             |
| 503 21 35-12  | E           | 503 94 26-01 | F           | 537 12 19-01 | A           |              |             |
| 503 21 48-01  | J           | 503 96 13-01 | D           | 537 12 21-01 | A           |              |             |
| 503 21 66-20  | DG          | 503 96 14-01 | D           | 537 12 22-01 | A           |              |             |
| 503 21 68-16  | B           | 503 96 25-01 | F           | 537 12 23-01 | A           |              |             |
| 503 21 68-20  | EGL         | 503 96 49-01 | G           | 537 12 24-01 | C           |              |             |
| 503 21 68-25  | L           | 503 97 40-01 | P           | 537 12 25-01 | C           |              |             |
| 503 21 71 -16 | J           | 503 97 43-01 | P           | 537 12 30-01 | A           |              |             |
| 503 21 75-16  | F           | 503 97 98-30 | G           | 537 12 31-01 | A           |              |             |
| 503 21 75-50  | F           | 503 97 98-31 | G           | 537 12 32-01 | A           |              |             |
| 503 21 77-16  | G           | 503 97 98-38 | G           | 537 12 33-01 | A           |              |             |
| 503 22 65-04  | F           | 503 98 12-32 | E           | 537 12 34-01 | A           |              |             |
| 503 23 30-02  | A           | 503 98 12-33 | E           | 537 12 36-01 | C           |              |             |
| 503 23 31-02  | A           | 503 98 12-37 | E           | 537 12 37-01 | C           |              |             |
| 503 23 51-11  | J           | 503 98 96-01 | N           | 537 12 38-01 | C           |              |             |
| 503 28 31-12  | FP          | 503 99 55-02 | D           | 537 12 39-01 | A           |              |             |
| 503 28 90-41  | K           | 503 99 56-02 | D           | 537 12 40-01 | A           |              |             |
| 503 44 32-01  | H           | 531 00 45-52 | P           | 537 12 41-01 | C           |              |             |
| 503 47 89-01  | P           | 531 00 45-53 | P           | 537 12 42-01 | A           |              |             |
| 503 47 92-01  | P           | 531 00 49-57 | A           | 537 12 43-01 | A           |              |             |
| 503 47 96-01  | P           | 531 00 75-12 | N           | 537 12 44-01 | A           |              |             |
| 503 47 97-01  | P           | 531 00 75-13 | N           | 537 12 45-01 | A           |              |             |
| 503 48 00-01  | P           | 537 00 00-01 | J           | 537 12 46-01 | A           |              |             |
| 503 48 01-01  | P           | 537 00 84-01 | G           | 537 12 47-01 | A           |              |             |
| 503 48 05-01  | P           | 537 01 13-01 | D           | 537 12 48-01 | A           |              |             |
| 503 48 08-01  | P           | 537 01 25-01 | P           | 537 12 50-01 | A           |              |             |
| 503 48 11-01  | P           | 537 01 26-01 | P           | 537 12 51-01 | A           |              |             |
| 503 48 18-01  | P           | 537 01 32-75 | K           | 537 12 52-01 | A           |              |             |
| 503 48 19-01  | P           | 537 01 41-01 | K           | 537 12 53-01 | A           |              |             |
| 503 49 71-01  | F           | 537 01 96-01 | P           | 537 12 54-01 | A           |              |             |
| 503 51 98-01  | A           | 537 01 97-01 | P           | 537 12 55-01 | A           |              |             |
| 503 53 57-01  | P           | 537 01 98-01 | P           | 537 12 56-01 | A           |              |             |
| 503 57 76-01  | H           | 537 01 99-01 | P           | 537 12 57-01 | A           |              |             |
| 503 66 59-01  | P           | 537 02 00-01 | P           | 537 12 58-01 | A           |              |             |
| 503 71 22-01  | KM          | 537 02 01-01 | P           | 537 12 59-01 | A           |              |             |
| 503 71 82-01  | D           | 537 02 02-01 | P           | 537 12 60-01 | A           |              |             |
| 503 73 58-01  | H           | 537 02 03-01 | P           | 537 12 61-01 | A           |              |             |
| 503 74 16-01  | N           | 537 02 04-01 | P           | 537 12 62-01 | A           |              |             |
| 503 74 16-02  | N           | 537 02 05-01 | P           | 537 12 63-01 | A           |              |             |
| 503 75 53-01  | P           | 537 02 06-01 | P           | 537 12 64-01 | A           |              |             |
| 503 83 61-01  | M           | 537 02 07-01 | P           | 537 12 65-01 | A           |              |             |
| 503 85 24-74  | M           | 537 02 08-01 | P           | 537 12 66-01 | A           |              |             |
| 503 85 28-01  | G           | 537 02 09-01 | P           | 537 13 04-01 | A           |              |             |
| 503 85 87-01  | G           | 537 02 11-01 | P           | 537 13 75-01 | J           |              |             |
| 503 85 89-01  | G           | 537 03 20-05 | K           | 537 14 09-01 | P           |              |             |
| 503 86 45-01  | B           | 537 03 23-01 | L           | 537 14 34-01 | P           |              |             |
| 503 87 17-01  | K           | 537 03 24-01 | L           | 537 15 46-01 | A           |              |             |
| 503 87 18-01  | E           | 537 03 41-01 | G           | 537 17 31-01 | A           | N            |             |
| 503 87 19-01  | B           | 537 03 94-01 | K           | 537 17 32-01 | A           | N            |             |
| 503 87 21-01  | E           | 537 03 99-01 | J           | 537 17 33-01 | A           | N            |             |
| 503 87 28-01  | J           | 537 04 01-01 | J           | 537 17 98-01 | A           | N            |             |
| 503 87 33-02  | G           | 537 04 07-11 | N           | 725 23 78-51 | B           |              |             |
| 503 87 35-02  | G           | 537 04 07-13 | N           | 725 53 25-55 | A           | N            |             |
| 503 87 36-01  | G           | 537 04 11-01 | L           | 727 63 70-01 | A           |              |             |
| 503 87 79-01  | D           | 537 04 12-01 | L           | 731 23 14-01 | BF          |              |             |
| 503 87 80-01  | D           | 537 04 24-01 | H           | 731 71 16-51 | GJ          |              |             |
| 503 87 85-01  | D           | 537 04 58-01 | J           | 734 11 52-01 | B           |              |             |
| 503 88 79-01  | F           | 537 04 89-01 | P           | 735 31 08-20 | G           |              |             |

N = New part  
 Neues teil  
 Nouvelle piece  
 Nueva pieza  
 Ny detalj