

# 326HD60<sub>X-SERIES</sub>

# 326HD75<sub>X-SERIES</sub>

**Spare parts**

Replaces

**Ersatzteile**

Ersetzt

**Pièces détachées**

Remplace

**Reserve onderdelen**

Vervangt

**Repuestos**


Reemplaza

**Reservdelar**


Ersätter

106 27 57-62


**A** \*compl 537 12 81-03



**B** \*compl 537 41 88-01




**C**



# D


\*compl 537 22 16-01

\*\*compl 537 08 51-02





# E

\*compl 537 08 52-01



# F




**G****H**

\*compl 544 00 25-01



537 35 34-36 **326HD60**537 35 34-37 **326HD75**

\*\*compl 503 87 33-02




**J**

\*compl 537 10 56-07 326HD60  
\*compl 537 10 56-08 326HD75




**K**

- \*compl 537 18 94-02
- \*\*compl 503 98 23-03
- \*\*\*compl 537 11 02-01
- \*\*\*\*compl 544 08 32-01






\*compl 537 28 00-05













**N** Accessories  
Zubehöre  
Accessoires  
Acessorios  
Tillbehör

\*compl 502 21 60-09



531 00 75-13 **UL22**



531 00 75-12 **UL21**



531 00 92-05