

327Lx

327LDx

327Rx

327RDx

327RJx

323RII

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

A




Brand
HUSQVARNA

Page Title	Page Note
BEVEL GEAR	1

A Position #	Article #	Quantity	Notes	Kit
1	537 19 92-02	1		
2	503 85 63-01	1		1
3	537 28 56-01	1		1
4	537 29 26-01	1		1, 5
5	537 23 49-01	1		1
6	735 31 28-10	1		1
7	503 25 24-01	1		1
8	738 21 98-00	1		1
9	503 20 15-01	1		1
10	503 20 14-12	1		1
11	503 20 07-25	1		1
12	738 21 99-00	1		1
13	738 21 99-02	1		1
14	735 31 11-00	1		1
15	735 31 25-10	1		1
16	503 20 07-12	1		
17	725 23 70-51	1		
18	503 93 55-01	1		

[Order Husqvarna 327 Parts on eBay](#)

B 327Lx
327RJx




Page Title	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
SHAFT & HANDLE		2

B Position #	Article #	Quantity	Notes	Kit
1	725 23 80-51	1	Lx	
2	725 23 78-51	1	L, LS	
3	503 87 90-01	1	Lx	
4	503 23 00-61	1	L, LS	
5	503 88 88-01	1		
6	503 87 19-01	1	L, LS	
6	503 87 19-03		Lx	
7	503 94 03-01	1		
8	503 20 07-16	1	RJx	
9	503 94 10-01	1	RJx	
10	731 23 14-01	1	RJx	
11	502 19 71-01	1		
12	503 21 68-16	3	RJx	
13	503 99 78-01	1	RJx	
14	537 23 48-01	1		
15	735 31 12-00	1		
16	537 23 75-01	1		
17	537 29 48-01	1		
18	503 79 56-01	1		
19	537 10 10-01	1	RJx	

[Order Husqvarna 327 Parts on eBay](#)

C 327LDx
327RDx



16




17



Page Title	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
SHAFT		3

C Position #	Article #	Quantity	Notes	Kit
1	537 07 99-01	1		
2	537 08 27-01	1		1
3	544 37 87-01	1		1
4	503 78 52-01	1		1
5	544 36 75-01	1		
6	729 92 18-01	2		5
7	502 20 38-01	1		5
8	725 23 79-51	1		5
9	537 01 16-01	1		
10	735 58 08-10	1		
11	537 01 19-01	1		
12	735 58 08-10	1		
13	544 11 37-01	1		
14	735 31 12-00	1		
15	537 23 75-01	1		
16	537 29 48-01	1		
17	503 79 56-01	1		

[Order Husqvarna 327 Parts on eBay](#)



Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
BEVEL GEAR & SHAFT			4


D Position #	Article #	Quantity	Notes	Kit
1	725 23 86-51	1		
2	502 20 38-01	1		
3	503 72 29-01	1		
4	502 21 12-01	1		
5	503 88 88-01	1		
6	503 88 23-01	1		
7	503 20 07-16	1		
8	503 94 10-01	1		
9	731 23 14-01	1		
10	503 21 75-25	2		
11	502 19 71-01	1		
12	537 23 48-01	1		
13	735 31 12-00	1		
14	537 23 75-01	1		
15	537 29 48-01	1		

[Order Husqvarna 327 Parts on eBay](#)

E

327Rx

1




Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
SHAFT & HANDLE			5

E					
Position #	Article #	Quantity	Notes	Kit	
1	502 21 12-01	1			
2	503 88 88-01	1			
3	725 23 82-85	1			
4	502 20 38-01	1			
5	537 37 63-01	1			
6	502 19 71-01	1			
7	537 34 86-01	1			
8	537 34 88-03	1			
9	503 20 02-25	2			
10	731 23 14-01	2			
11	537 34 89-01	1			
12	537 34 87-01	1			
13	503 21 06-19	4			
14	502 28 61-01	1			
15	537 23 48-01	1			
16	735 31 12-00	1			
17	537 23 75-01	1			
18	537 29 48-01	1			

[Order Husqvarna 327 Parts on eBay](#)

F 323RII
327Rx




Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
THROTTLE CONTROLS			6

F					
Position #	Article #	Quantity	Notes	Kit	
1	537 42 45-11	1			
2	502 65 41-01	1			
3	503 22 10-13	1			
4	537 16 02-02	1	327RX		
4	537 16 02-03	1	323 RII		
5	537 41 90-01	1			
6	537 16 08-01	1			
7	537 17 42-01	1			
8	537 16 07-01	1			
9	537 16 06-01	1			
10	537 17 43-01	1			
11	537 16 03-02	1	27RX		
11	537 16 03-01	1	323 RII		
12	503 21 66-18	2			
13	503 20 07-35	1			
14	503 72 43-09	1			
15	731 23 14-01	1			
16	537 17 28-01	1			
17	503 20 02-45	1			
18	537 17 29-01	1			
19	537 36 00-01	1			
20	544 02 09-01	1			
21	502 21 12-01	1			
22	503 21 66-18	1			
23	502 53 16-02	1			
24	537 17 39-01	1			

[Order Husqvarna 327 Parts on eBay](#)

G 327Lx
327LDx
327RJx




Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
THROTTLE CONTROLS			7

G				
Position #	Article #	Quantity	Notes	Kit
1	544 14 36-04	1		
2	537 41 90-01	1		1
3	503 21 66-18	5		1
4	544 10 02-02	1		1
5	503 87 80-01	1		1
6	503 91 81-01	1		1
7	503 96 14-01	1		1
8	544 10 03-02	1		1
9	544 10 08-01	1		1
10	503 87 79-03	1		1
11	544 10 17-02	1		1
12	731 23 14-01	1		1
13	544 11 21-01	1		1
14	503 20 03-20	1		1
15	544 10 17-02	1		1
16	502 65 13-01	1		1
17	502 53 16-01	1		1,16
18	544 17 17-03	1		1,16

[Order Husqvarna 327 Parts on eBay](#)

H 327Lx, LDx, Rx, RDx, RJx
323RII




Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
COVER			8

H Position #	Article #	Quantity	Notes	Kit
1	537 21 32-10	1		
2	502 48 13-01	1		
3	503 20 03-16	4	M5x16	
4	503 21 35-12	2		
5	502 48 16-01	1		
6	544 84 81-01	1		
7	503 21 68-20	1		
8	503 22 24-01	1		
9	502 48 14-01	1		
10	503 20 03-16	1		
11	503 96 13-01	1		
12	740 42 06-00	1		
13	740 42 06-00	1		
14	503 96 13-01	1		
15	502 48 15-01	1		

[Order Husqvarna 327 Parts on eBay](#)

J




Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
CARBURETOR & AIRFILTER			9


J Position #	Article #	Quantity	Notes	Kit
1	537 14 31-03	1		
2	503 96 25-01	1		
3	740 68 11-21	1		
4	502 49 90-01	1		
5	503 21 75-50	2		
6	503 21 77-16	1		
7	503 28 34-01	1	Zama C1Q-EL24	
8	503 49 71-01	1		
9	503 93 66-01	1		
10	503 22 65-04	2		
11	503 91 09-01	1		
12	503 94 26-01	1		
13	503 20 03-25	2		

[Order Husqvarna 327 Parts on eBay](#)

K



22




23



24



25





26

Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
STARTER			10

K Position #	Article #	Quantity	Notes	Kit
1	503 87 33-05	1		
2	735 31 08-20	2		1
3	503 87 36-01	2		1
4	503 87 35-02	2		1
5	544 07 11-02	1		
6	503 21 77-25	1		5
7	544 03 87-01	1		5
8	544 03 88-01	1		5
9	544 16 65-01	1		5
10	537 37 93-02	2		5
11	503 85 89-01	1		5
12	537 00 84-01	1		5
13	537 41 16-01	1		5
14	537 37 93-02	1		5
15	544 03 86-01	1		5, 9
16	503 85 90-01	1		5, 9
17	503 20 03-16	1	M5x16	
18	537 03 41-01	1		
19	503 20 14-12	1	M5x12	
20	503 21 66-18	1		
21	503 21 66-18	1		
22	537 35 34-56	1	327LDx	
23	537 35 34-57	1	327RJx	
24	537 35 34-58	1	323RII	
25	537 35 34-59	1	327Rx	
26	537 35 34-60	1	327RDx	

[Order Husqvarna 327 Parts on eBay](#)


L



Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)	
STARTER			11	
L				
Position #	Article #	Quantity	Notes	Kit
1	503 87 33-05	1		
2	735 31 08-20	2		1
3	503 87 36-01	1		1
4	503 87 35-02	2		1
5	503 85 28-06	1		
6	503 21 77-16	1		5
7	503 96 49-01	1		5
8	537 37 93-02	2		5
9	503 85 89-01	1		5
10	537 00 84-01	1		5
11	503 85 87-02	1		5
12	537 37 93-02	1		5
13	503 20 03-16	1	M5x16	
14	503 21 66-18	1		
15	503 21 66-18	1		
16	503 20 14-12	1	M5x12	
17	537 03 41-01	1		

[Order Husqvarna 327 Parts on eBay](#)

M



Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
FUEL TANK			12

M Position #	Article #	Quantity	Notes	Kit
1	537 06 86-07	1		
2	544 32 50-01	1		1
3	537 04 24-01	1		1
4	537 04 24-01	1		1
5	503 73 58-01	2		1
6	504 02 24-01	1		1
7	503 44 32-01	1		1
8	503 93 66-01	1		
9	537 18 49-01	1		
10	544 88 97-02	1		
11	503 91 10-01	4		

[Order Husqvarna 327 Parts on eBay](#)

N



1




2



3

4

5




6



7



8



9


10

11

12

13

14




Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
IGNITION & CLUTCH			13

N Position #	Article #	Quantity	Notes	Kit
1	502 49 36-01	1		
2	537 43 43-01	1		
3	503 23 51-09	1	Champion RCJ 6Y	
4	502 49 37-01	1		
5	503 21 66-18	2		
6	537 23 75-01	1		
7	503 84 29-02	2		
8	537 04 67-02	1		
9	537 03 22-01	1		
10	503 84 28-01	2		9
11	503 81 60-01	1		9
12	537 04 68-02	1		
13	731 71 16-51	1		
14	537 24 96-02	1		

[Order Husqvarna 327 Parts on eBay](#)

P




Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
CYLINDER PISTON & MUFFLER			14

P Position #	Article #	Quantity	Notes	Kit
1	537 22 17-04	1	Cat.	
2	537 22 18-01	1		1
3	537 01 41-01	1		
4	502 07 81-01	3		
5	537 08 51-03	1	Ø=34mm	
6	503 20 07-35	4		5
7	537 40 59-02	1		5
8	537 40 62-01	1		7
9	537 40 62-01	1		7
10	737 44 08-00	1		7
11	503 71 22-01	1		7
12	737 44 08-00	1		7

[Order Husqvarna 327 Parts on eBay](#)

Q




Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
CRANK CASE			15

Q Position #	Article #	Quantity	Notes	Kit
1	537 30 96-01	1		
2	503 21 68-25	1		1
3	503 21 68-25	1		1
4	537 04 12-09	1		
5	537 42 50-01	1		4
6	503 20 03-16	1	M5x16	4
7	537 07 36-01	1		
8	503 25 05-01	1		4
9	537 33 67-01	1		4
10	537 08 52-02	1		
11	503 20 03-16	1		10
12	537 06 69-01	1		10
13	537 08 85-01	1		10
14	537 06 68-01	1		10
15	503 20 03-16	1		10
16	503 20 03-16	1		10
17	503 21 66-18	1		10
18	503 20 03-16	1		10
19	503 21 66-18	1		10
20	503 20 03-16	1		10
21	503 21 77-16	1		10
22	503 20 14-12	1	M5x12	10
23	503 20 03-16	1		10

[Order Husqvarna 327 Parts on eBay](#)

R




Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
CRANK CASE			16

R				
Position #	Article #	Quantity	Notes	Kit
1	503 85 24-74	1		
2	503 94 02-03	1		1
3	503 94 05-01	1		1
4	503 71 22-01	1		1
5	503 94 05-01	1		1
6	503 94 02-03	1		1

[Order Husqvarna 327 Parts on eBay](#)

S






Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
ACCESSORIES			17

S Position #	Article #	Quantity	Notes	Kit
1	503 28 34-01	1	Zama C1Q-EL24	
2	503 97 43-01	1		1
3	503 48 05-01	2		1
4	537 02 02-01	1		1
5	537 02 07-01	1		1
6	503 48 11-01	1		1
7	503 47 96-01	1		1
8	537 04 89-01	1		1,A,B
9	537 02 04-01	1		1,A,B
10	537 02 01-01	1		1,A,B
11	537 02 00-01	1		1,A,B
12	503 53 57-01	1		1,B
13	503 48 01-01	1		1
14	503 48 00-01	1		1,B
15	503 66 59-01	1		1,B
16	537 02 03-01	1		1,B
17	503 47 97-01	1		1,B
18	537 02 08-01	1		1,B
19	537 01 25-01	1		1
20	537 01 26-01	1		1
21	537 37 03-01	1		1
22	537 37 03-01	1		1
23	503 48 18-01	1		1
24	503 48 19-01	1		1
25	537 04 90-01	1		1
26	537 02 10-01	1		1
27	503 75 53-01	1		1
28	537 01 96-01	1		1
29	537 01 99-01	1		1
30	503 47 92-01	1		1
31	537 01 97-01	1		1
32	503 47 89-01	1		1
33	537 01 98-01	1		1
34	503 47 90-01	1		1
35	537 02 06-01	1		1
36	537 12 78-01	1		1
37	503 97 40-01	1		1
38	503 48 08-01	1		1
39	537 02 16-01	1		1
40	537 02 16-01	1		1
41,A	531 00 45-52	1		
42,B	531 00 45-53	1		

[Order Husqvarna 327 Parts on eBay](#)

T Accessories
Zubehöre
Accessoires
Acessorios
Tillbehör














Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
CARBURETOR			18

T					
Position #	Article #	Quantity	Notes		Kit
1	537 29 95-01	1	323RII, 327Rx		
2	725 23 68-71	2			1
3	537 04 75-01	1			1
4	537 29 34-01	1			1
5	502 27 22-01	1			1
6	503 21 75-16	4			1
7	503 97 71-01	1	327Lx, 327LDx		
8	503 21 07-16	1			7
9	503 79 88-01	1			7
10	503 93 42-02	1	323RII, 327Rx		
11	503 21 07-16	1			10
12	503 79 88-01	1			10

[Order Husqvarna 327 Parts on eBay](#)

U Accessories Zubehöre Accessoires Acessorios Tillbehör

Olja Luftfilter
 Oil Airfilter
 Öl Luftfilter
 Aceite Filtro Air
 Huile Filtera aire




Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
ACCESSORIES			19

U Position #	Article #	Quantity	Notes	Kit
1	502 28 59-01	1		
2	502 11 46-02	1		
3	501 60 02-03	1		
4	502 21 58-01	1		
5	531 00 92-48	1		
6	501 69 17-01	1		
7	503 97 64-01	1		
8	537 35 36-01	1		
9	537 13 04-02	1		
10	537 35 01-01	1		
11	725 23 31-51	1		
12	537 31 29-01	1	200-275 mm	
13	537 21 62-01	1		
13	537 21 62-02	1	USA	
14	537 21 63-01	1		
14	537 21 63-02	1	USA	
15	503 73 40-01	1		14
16	503 73 41-02	1		14
17	502 02 28-02	1		14

[Order Husqvarna 327 Parts on eBay](#)

1



Page Title	Image name	Page Note	Sequence # (i vilken ordning bilderna ska komma i listan)
HARNESS			20

V				
Position #	Article #	Quantity	Notes	Kit
1	537 27 57-01	1		
1	537 27 57-03	1	US	1
2	503 99 61-01	3		1
3	503 99 61-03	1		1
4	537 11 35-01	1		1
5	537 28 84-01	1		1
6	537 28 83-01	1		1
7	537 27 59-01	1		1
8	502 02 28-01	1		1
9	502 02 30-02	1		1,8
10	502 02 38-01	1		1,8
11	502 02 29-02	1		1,8
12	735 31 09-20	1		1,8
13	537 17 54-01	3		1

[Order Husqvarna 327 Parts on eBay](#)



HUSQVARNA PRODUCT REGISTRATION INFORMATION & WARRANTY STATEMENT

All Husqvarna products can be registered online at www.usa.husqvarna.com quickly and easily regardless of their model year. Click the Support tab, then click on the Online Product Registration link, and fill out the electronic form and submit. Ask about Husqvarna's extended service plan!

SECTION 1: LIMITED WARRANTY

Husqvarna Professional Products, Inc ("Husqvarna") warrants the original purchaser the Husqvarna branded product to which this warranty apply (the "Product") that the Product shall be free from defects in material and workmanship from the date of purchase for the period of the applicable "Warranty Schedule" of the Product as set forth below. Additional limitations are described in Section 2 through 6, inclusive.

PRODUCT CATEGORY	CONSUMER WARRANTY SCHEDULE*	COMMERCIAL / PROFESSIONAL WARRANTY SCHEDULE	RENTAL WARRANTY SCHEDULE
Reconditioned Products: Reconditioned chainsaws, trimmers, brushcutters, clearing saws, handheld blowers, backpack blowers, hedge trimmers, and electrical products.	90 Days	N/A	N/A
Chain Saws Lifetime Ignition Warranty (Parts Only). One Year Conditional Crankshaft Warranty for Commercial/Professional use when operated with Husqvarna XP 2 cycle oil (Parts & Labor).	2 Years	90 Days	90 Days
100 Series Trimmers, Stick Edgers, Hedge Trimmers Lifetime Ignition Warranty (Parts Only). Lifetime Shaft Warranty.	2 Years	1 Year	90 Days
200 & 300 Series Trimmers, Brushcutters, Clearing Saws, Stick Edgers, Hovering Trimmers & Hedge Trimmers Lifetime Ignition Warranty (Parts Only) and Lifetime Shaft Warranty apply to these products (excludes Hovering Trimmers).	2 Years	1 Year	90 Days
Blowers (Lifetime Ignition Warranty - Parts Only)	2 Years	2 Years	90 Days
Pole Pruners, Pole Saws, Pole Hedge Trimmers (Lifetime Ignition Warranty - Parts Only)	1 Year	1 Year	90 Days
Residential Walk-Behind Mowers, Tillers, LE389 Edger †	2 Years	N/A	N/A
LE475 Edger †	2 Years	90 Days	90 Days
LT, LTH, LS, XLS, GLS, YT, YTH, GT, GTH, 16H, Pro15, 155 ProFlex Series Lawn & Garden Riders and Residential Zero Turn Mowers †	2 Years	N/A	N/A
MZ and EZ Series Zero Turn Riders †	3 Years or 600 Hours	1 Year or 600 Hours	90 Days
iZ, LZ, BZ Series Zero Turn Riders † (Applies to units factory-equipped with Roll Over Protection System.)	5 Years or 1,500 Hours	5 Years or 1,500 Hours	90 Days
Commercial Walk Mowers † (includes 21" & wide area)	3 Years	3 Years	90 Days
Commercial Turf Specialty Equipment †	1 Year	1 Year	1 Year
Zero Turn & Commercial Turf Specialty Attachments	2 Years	1 Year	90 Days
Power Cutters (Lifetime Ignition Warranty - Parts Only)	1 Year	90 Days 1 Year (K750 only)	90 Days
Automatic Mower (1 Year Battery Warranty)	2 Years	90 Days	90 Days
Snow Throwers †	2 Years	90 Days	90 Days
Pressure Washers †	2 Years	2 Years (Excludes 5525PW)	N/A
Generators (Husqvarna's warranty does not cover Engine & Generator Parts, which are warrantied by responsible manufacturer.) †	2 Years (2 nd Year Parts Only)	2 Years – 1365GN only (2 nd Year Parts only)	N/A
Grass Catchers & Bumpers Purchased with New Units	Same Warranty As Unit When Purchased with Unit		
Spreaders	1 Year		
Parts & Accessories Purchased Separately	30 days		
Husqvarna Utility Vehicles** (Engines/transmissions shall be warrantied through Husqvarna.)	2 Year or 2,000 Hour Powertrain & 1 Year or 1,000 Hour Body Warranty		
HUV Batteries: 4210E Versions	4 Year Pro-rated		
Husqvarna Safety Apparel***	90-day		
Batteries**** (Consumer Products where applicable)	1 year	N/A	
Replacement Parts, Accessories including Bars and Chains, Tools and Display Items. Emission Control System Components necessary to comply with CARB-TIER II and EPA Regulations (Excludes components which are part of engine systems manufactured by third part engine manufacturers for which the purchaser has received a separate warranty with product at time of purchase.)	30 Day Warranty		

† Refer to Section 3 for items not covered by this warranty

*All consumer product use must have been limited to the owner's residence. Warranted for noncommercial, nonprofessional, noninstitutional and nonincome producing use.

HUV 2 Year or 2,000 Hour Powertrain (The engine assembly, unitized transaxle assembly (gasoline vehicle), motor, and main frame assembly are warranted with respect to parts and labor against defects in material and workmanship or a period of two years or 2000 hours of operation, whichever first occurs, from the date of purchase.) & **1 Year or 1,000 Hour Body Warranty (All remaining components of the vehicle not specified otherwise and all other original equipment options and accessories supplied by Husqvarna are warranted with respect to parts and labor against defects in material and workmanship for a period of one year or 1000 hours of operation, whichever first occurs, from the date of purchase.)

HUV's Gas & Diesel Powered Battery: 0 – 6 months free replacement and 7 – 12 months prorated

HUV's Electric Powered – 4 year or 16,000 Energy Unit Limited Warranty Period

***Husqvarna safety apparel warranty is from the date of the customer's original purchase for defects in material and workmanship. Normal wear, tear or abuse is not covered under warranty. All care and maintenance instructions must be followed as stated by the manufacturer on the care label. The fit of the protective apparel/boot is not covered under warranty.

****Battery 1 Year prorated limited warranty with 100% replacement during the first 6 months.

Lifetime Warranty (Parts and Labor): All tiller tines and trimmer shafts against breakage. Proof of purchase required.

Lifetime Warranty ("PARTS ONLY" after initial warranty expiration): Ignition coils and modules on handheld product. Proof of purchase required.

SECTION 2: HUSQVARNA'S OBLIGATIONS UNDER THE WARRANTY

Husqvarna will repair or replace defective components without charge for parts or labor if a component fails because of a defect in material or workmanship during the warranty period.

SECTION 3: ITEMS NOT COVERED BY THIS WARRANTY

The following items are not covered by this warranty:

- (1) Normal customer maintenance items which become worn through normal regular use, including, but not limited to, belts, blades, blade adapters, bulbs, clutches, clutch drums, filters (fuel line, fuel filters, air filters, oil filters), sprockets, guide bars, lubricants, rewind springs, saw chain, spark plugs, starter ropes and tiller tines;
- (2) Natural discoloration of material due to ultraviolet light;
- (3) Engine and drive systems not manufactured by Husqvarna; these items are covered by the respective manufacturer's warranty as provided in writing with the product information supplied at the time of purchase; all claims must be sent to the appropriate manufacturer.
- (4) Lawn and garden attachments that are covered by a third party which gives a warranty, all claims for warranty should be sent to the manufacturer.
- (5) Commercial or consumer mowing decks with sand abrasion damage.
- (6) Emission Control System components necessary to comply with CARB-TIER II and EPA regulations which are manufactured by third party engine manufacturer.

SECTION 4: EXCEPTIONS AND LIMITATIONS

This warranty shall be inapplicable to defects resulting from the following:

- (1) Accident, abuse, misuse, negligence and neglect, including stale fuel, dirt, abrasives, moisture, rust, corrosion, or any adverse reaction due to incorrect storage or use habits;
- (2) Failure to operate or maintain the unit in accordance with the Owner's/Operator's manual or instruction sheet furnished by Husqvarna;
- (3) Alterations or modifications that change the intended use of the product or affects the product's performance, operation, safety, or durability, or causes the product to fail to comply with any applicable laws; or
- (4) Additional damage to parts or components due to continued use occurring after any of the above.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE PURCHASER. HUSQVARNA SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THESE PRODUCTS EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THESE PRODUCTS IS LIMITED IN DURATION TO THE WARRANTY PERIOD AS DEFINED IN THE LIMITED WARRANTY STATEMENT. HUSQVARNA RESERVES THE RIGHT TO CHANGE OR IMPROVE THE DESIGN OF THE PRODUCT WITHOUT NOTICE, AND DOES NOT ASSUME OBLIGATION TO UPDATE PREVIOUSLY MANUFACTURED PRODUCTS.

Some states do not allow the exclusion of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary by state.

SECTION 5: CUSTOMER RESPONSIBILITIES

The product must exhibit reasonable care, maintenance, operation, storage and general upkeep as written in the maintenance section of the Owner's/Operator's manual. Should an operational problem or failure occur, the product should not be used. Failure caused by continued use is not covered by warranty. Product should be delivered, at owners expense, as is, to an authorized Husqvarna Servicing Retailer for evaluation. Proof of purchase, as explained in section 6, rests solely with the customer.

SECTION 6: PROCEDURE TO OBTAIN WARRANTY CONSIDERATION

It is the Owner's and Retailer's responsibility to make certain that the Warranty Registration Card is properly filled out and mailed to Husqvarna. This card should be mailed within ten (10) days from the date of purchase in order to confirm the warranty and to facilitate post-sale service. Proof of purchase must be presented to the authorized Husqvarna retailer in order to obtain warranty service. This proof must include date purchased, model number, serial number, and complete name and address of the selling retailer. To obtain the benefit of this warranty, the product believed to be defective must be delivered to an authorized Husqvarna retailer in a timely manner, no later than thirty (30) days from date of the operational problem or failure. The product must be delivered at the owner's expense. Downtime, pick-up and delivery charges are not covered by this warranty. An authorized Husqvarna retailer can be located by calling 1-800-HUSKY-62 or visiting www.husqvarna.com

Subject to change without notice.

HUSQVARNA 7349 Statesville Road, Charlotte, NC 28269

IR
Part Number 525 88 56-01