


32R



1.1990


Spare parts

Pièces détachées

PARTS LIST NO. 530-067739 - 12/15/89		HUSQVARNA PARTS LIST	TRIMMER MODEL: 32 R
Page No. 1	REPLACES NONE		

Note: Illustrations may differ from actual models due to design changes


WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Shaft
Lubrication
46

Key No.	Part No.	Description	Key No.	Part No.	Description
1	530 02 79-00	Kill Switch Bracket	31	530 09 47-59	Hub Ass'y.
2	530 02 75-88	Handlebar Cap	32	952 70 85-28	Spool w/Line
3	530 01 09-65	Throttle Lever Ass'y. w/ Lock (Incl. #4 & 7)	33	530 09 44-94	Cover
4	530 01 57-68	Nut	35	530 09 46-40	Seal
5	530 02 76-89	Spacer	36	530 09 46-39	Dust Cup
6	530 02 35-75	Nut	38	530 09 46-33	Shield
7	530 01 58-00	Screw	39	530 02 76-15	Shield Retention Plate
8	530 02 77-26	Wire Harness Ass'y.	40	530 03 11-11	Hex Wrench (5/32)
9	530 02 78-93	Terminal Lock	41	530 03 10-98	Hex Wrench (3/16)
10	530 09 45-72	Handlebar Bracket	42	952 70 85-22	Brush Blade - 8"
11	530 02 77-66	Handlebar Grip	43	530 01 57-92	Washer
12	530 02 77-36	Handguard Grip	44	530 01 54-92	Washer
13	530 01 41-03	Handlebar	45	530 01 57-93	Nut
14	530 09 14-26	Tie Strap	46	530 03 01-02	Shaft Lubrication
15	530 02 77-06	Drive Shaft Pad	47	530 09 46-38	Shoulder Strap
16	530 09 45-98	Clamp Harness Ass'y.	52	952 70 85-24	Weed Blade (Optional)
17	580 01 51-97	Nut	53	530 06 92-56	Shield Kit Ass'y. (Incl. 17 - 19)
18	530 01 22-07	Handlebar Clamp	54	530 01 50-37	Screw
19	530 09 47-57	Drive Shaft Housing	55	530 09 45-70	Line Limiter
20	530 09 45-66	Drive Shaft	56	530 01 56-53	Locknut
21	530 06 92-52	"T" Handle Ass'y.	57	530 01 57-90	Screw
22	530 01 57-91	Screw			
23	530 01 53-28	Lockwasher			
24	530 09 46-12	Screw	A	530 02 91-67	Decal-Shaft Warning (Upper)
25	530 00 17-11	Screw	B	530 02 91-68	Decal-Shaft Warning (Lower)
26	530 00 16-42	Lockwasher	C	530 02 78-84	Decal-Handlebar Warning
27	530 09 45-71	Grass Washer	D	530 02 77-55	Decal-Blade Direction
28	530 09 45-68	Gear Box Ass'y.			
29	580 09 46-16	Screw	Not Shown		
30	952 70 85-29	Cutting Head Ass'y. (Incl. #31-33)		530 06 76-81	Operator's Manual

PARTS LIST NO. 530-067789 - 12/15/89	HUSQVARNA PARTS LIST		TRIMMER MODEL: 32 R
Page No. 2	REPLACES NONE	Note: Illustrations may differ from actual models due to design changes	



PARTS LIST NO. 530-067759 - 12/15/89		HUSQVARNA PARTS LIST		TRIMMER MODEL: 32 R	
Page No. 3		REPLACES NONE		Note: Illustrations may differ from actual models due to design changes	
Key No.	Part No.	Description	Key No.	Part No.	Description
1	530 01 57-73	Screw	51	53003 91-34	Ignition Module Kit
2	530 02 75-29	Air Filter Cover	52	530 01 51-28	Screw
3	530 02 75-30	Air Filter	53	530 03 91-36	Flywheel Ass'y.
4	530 01 58-49	Screw	54	530 02 75-72	Flywheel Counterweight
5	530 02 75-28	Spacer	55	530 02 94-73	Fan Housing
6	530 01 52-54	Wave Washer	56	530 06 92-91	Starter Pulley
7	530 02 75-26	Choke Shutter	57	530 02 75-31	Starter Spring
8	530 02 75-27	Air Filter Plate	58	530 02 75-69	Starter Handle
9	530 06 92-47	Fuel Line Kit	59	530 06 92-32	Rope Kit
10	530 01 08-97	Fuel Pick-up Ass'y.	60	530 01 41-14	Pulley Housing Ass'y.
11	530 03 52-59	Carburetor (WA-199)	61	530 09 41-89	Clutch Washer
12	† 530 01 91-56	Carburetor Gasket	62	530 06 92-54	Clutch
13	530 01 08-07	Fuel Cap Ass'y.	63	530 01 57-96	Washer
14	530 01 57-75	Screw	64	530 00 17-33	Nut
15	530 02 76-81	Throttle Cable Ass'y.	65	530 01 41-15	Clutch Housing
16	530 02 91-88	Shroud & Tank Ass'y.	66	530 01 57-67	Screw
17	† 530 01 91-54	Gasket	67	530 02 75-11	Spacer
18	530 02 75-93	Reed	68	530 01 57-70	Screw
19	530 02 75-94	Reed Stop	69	530 01 57-69	Screw
20	530 01 09-60	Connecting Rod Ass'y. (Incl. Bearings)	70	530 01 54-96	Screw
21	530 01 09-34	Crankshaft Ass'y.	71	530 02 75-23	Pulley Retainer
22	530 01 51-26	Flywheel Key	72	530 01 57-68	Locknut
23	530 01 57-72	Screw	73	530 06 92-76	Engine Gasket Kit (†Indicates Contents)
27	530 04 57-71	Screw	75	530 02 76-90	Lead Wire/Grommet Ass'y.
28	530 01 40-16	Crankcase Ass'y. (Incl. #39-42)	76	530 03 50-14	*+ Metering Diaphragm
32	530 01 40-15	Crankcase & Crankshaft Ass'y. (Incl. #21,28, 38 & 43)	77	530 03 51-51	*+ Metering Diaphragm Gasket
33	530 01 52-41	Screw	78	530 03 51-47	*+ Circuit Plate Gasket
34	530 01 51-62	Piston Pin Retainer	79	530 03 51-42	Hi Speed Needle
35	530 02 58-75	Piston Ring	80	530 03 50-36	Hi Speed Needle Spring
36	† 530 01 91-61	Cylinder Gasket	81	530 03 51-41	Idle Needle
37	530 06 92-77	Piston Kit (Incl. #34,35 & pin)	82	530 03 50-23	Idle Needle Spring
38	530 01 57-88	Spacer	83	530 03 52-03	Idle Speed Screw
39	530 03 21-03	Inner Bearing	84	530 03 52-08	Idle Speed Spring
40	530 01 57-87	Retaining Ring	85	530 03 50-28	+ Metering Lever Pin
41	530 01 91-58	Crankshaft Seal	86	530 03 50-31	+ Metering Lever
42	530 03 21-02	Outer Bearing	87	530 03 51-88	+ Metering Lever Spring
43	530 01 57-89	Crankshaft Retaining Ring	88	530 03 51-06	+ Inlet Needle Valve
44	530 01 57-17	Screw	89	530 03 51-78	+ Inlet Screen
45	530 02 77-81	Muffler Guard	90	530 03 51-66	*+ Pump Diaphragm
46	530 06 92-57	Muffler Kit	91	530 03 51-64	*+ Pump Gasket
47	530 02 49-03	Muffler Spring	92	530 03 52-60	Carb. Kwik Repair Kit (+ Indicates Contents)
48	530 01 22-38	Cylinder	93	530 03 51-85	Carb. Gasket/Diaphragm Kit (*Indicates Contents)
49	530 03 00-58	Spark Plug	94	530 01 58-23	Screw (Incl. in Starter Pulley Kit)
50	530 01 52-39	Screw	A	530 02 94-09	Instruction Decal
			Not Shown		
				530 06 12-44	Carton
				530 01 41-75	Carton Contents Bag