

340, 345, 350

Spare parts

Ersatzteile

Pièces détachées



Reserve onderdelen

Repuestos




Reservdelar


A

A



B




B***compl 544 21 72-01 345e**

C *compl 503 91 05-01 (340)

*503 98 74-01



*503 20 34-74 (x3)




C *compl 537 42 20-01 (340e, 345e)

*503 98 74-01



*503 20 34-74 (x3)




C *compl 537 42 19-01 (350)


*503 98 74-01




*503 20 34-74 (x3)




D




E *compl 503 86 27-03 (EU) 350




E *compl 503 87 96-02 (FG) 340, 340e, 345




E *compl 503 86 28-03 (DF) 340, 340e, 345, 350



F 340




F 340e, 345e, 350





G


*compl 503 87 00-76 (340, 340e)
 *compl 503 87 02-76 (345e)


**G**

**compl 537 25 30-02 (350EPA)
 *compl 503 86 99-03 (350)








J***compl 537 17 20-03**




L



M *compl 537 42 29-01




M *compl 537 10 47-02



N

*compl 503 28 32-08 ZAMA C3-EL18B (340)


ZAMA C3-EL18B





N

*compl 503 28 32-10 ZAMA C3-EL32 (340e, 345e, 350)

ZAMA C3-EL32




P Tillbehör
Accessories
Zubehöre
Accessoires
Accesorios




Winter kit

*compl 544 01 31-01 (340e, 345e)




Winter kit

*compl 537 04 28-02 (340, 350)




Q

Up to 991499999




**From 991500001
to 001400001**







Up to 010604200 (340)
Up to 010602850 (345)
Up to 010702450 (350)



Up to 052299999 (345)



Up to 000601101 (340, 345)





503 92 60-01 (x2)



Up to 030103001
Only EPA (350)

*compl 503 86 99-71 (350)



537 32 40-01 (350)

