

385

385 EPA

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

Replaces

Ersetzt

Remplace

Vervangt

Reemplaza

Ersätter

106 27 41-62

PART NUMBER	SQUARE	NOTE	PART NUMBER	SQUARE	NOTE	PART NUMBER	SQUARE	NOTE	PART NUMBER	SQUARE	NOTE
501 22 04-01	P	2	503 42 67-01	B		503 96 70-01	J		537 04 66-01	J	
501 22 05-01	P		503 43 20-01	B		503 97 50-01	B		537 05 13-01	J	
501 22 08-01	P		503 43 29-01	N		503 97 51-01	B		537 05 16-05	M	
501 22 09-01	P		503 43 65-01	A		503 98 66-71	K		537 05 16-06	M	
501 22 12-01	P		503 44 32-01	H		503 98 66-72	K M		537 05 26-01	M	
501 22 13-01	P		503 48 63-01	P		503 98 67-02	L		537 06 32-01	M	
501 22 15-01	P		503 52 13-04	B		503 98 67-71	L		537 06 53-01	M	
501 22 20-01	P		503 52 87-02	K L		503 98 74-01	C		537 06 89-01	P	
501 22 21-01	P		503 53 36-01	P		503 98 82-01	P		537 06 90-01	P	
501 22 25-01	P		503 54 39-01	P N		503 98 85-01	P		537 06 95-01	P	
501 27 08-01	J	compl 2	503 55 66-01	H		503 98 86-01	P		537 06 96-01	C	
501 43 00-01	M		503 55 85-02	Q		503 99 11-05	J		537 06 98-01	P	
501 48 52-01	P		503 55 86-01	Q		503 99 34-04	E		537 07 00-01	P	
501 48 54-02	M		503 55 86-02	Q		503 99 83-01	A		537 07 18-02	M	
501 49 27-03	H		503 56 00-05	G		503 99 93-01	G		537 07 23-01	C	
501 49 48-02	P		503 57 76-02	H		504 30 00-26	B		537 07 94-01	A	
501 54 41-02	B		503 57 86-01	P		504 52 14-03	P		537 07 94-01	A	
501 59 80-02	B		503 57 87-01	P		504 52 14-03	P		537 07 95-01	A	
501 61 58-01	B		503 57 89-01	H		505 30 36-61	B		537 08 62-01	D	
501 62 93-08	M		503 57 89-01	H J		505 31 65-50	P		537 08 67-01	N	
501 63 06-01	N		503 62 12-01	Q		537 00 07-01	C		537 08 92-01	J	
501 67 35-01	M		503 62 49-01	B		537 00 07-02	C		537 09 22-01	H	
501 68 89-01	Q		503 62 61-02	M		537 00 09-01	C		537 09 54-01	J	
501 76 83-05	H		503 64 47-01	B		537 00 10-01	C		537 09 93-01	H	
501 79 51-02	M		503 65 27-01	P		537 00 12-01	J		537 10 64-01	B	
501 81 99-01	M		503 65 28-01	P		537 00 13-01	N		537 10 82-01	P	
501 82 17-01	P		503 66 19-01	P		537 00 14-02	J		537 10 83-01	P	
501 82 18-01	P		503 67 86-01	J		537 00 37-01	G		537 11 14-01	G	
501 87 53-04	A		503 68 41-01	G		537 00 38-71	N		537 13 00-01	P	
501 91 14-01	Q		503 68 45-03	M		537 00 39-71	N		537 13 72-01	C	
502 01 22-01	P		503 70 11-01	G		537 00 57-01	D	1	537 13 79-71	B	
502 20 65-01	G		503 70 99-01	A		537 00 79-01	J		537 13 79-72	B	
502 20 65-05	G		503 71 53-01	D		537 00 87-01	A		537 16 22-04	M	
502 20 83-02	G		503 71 76-01	H		537 00 88-01	H		537 16 97-71	D	
503 08 52-01	M		503 71 82-01	M		537 00 91-01	G		537 16 98-71	D	
503 13 96-01	Q		503 71 82-02	M		537 00 93-01	G		537 17 41-01	A	
503 20 02-12	A		503 71 97-01	A		537 01 47-01	G		537 18 98-01	M	
503 20 02-16	F J		503 73 44-01	J		537 01 47-02	G		537 21 50-01	H J	
503 20 02-20	M		503 73 64-01	H		537 01 47-03	G		537 21 52-02	H J	
503 20 06-08	F		503 74 01-02	C		537 01 55-01	M		537 32 70-01	N	
503 20 07-12	J		503 74 93-01	J		537 01 65-01	C		537 32 70-02	N	
503 20 07-30	J		503 74 93-01	J		537 01 67-01	A		537 33 10-01	A	
503 20 16-35	J		503 75 11-03	A		537 01 68-01	A		537 38 88-01	M	
503 20 25-12	A		503 75 18-01	J		537 01 68-01	A		720 12 40-20	H	
503 20 34-19	N		503 75 22-02	A		537 01 69-01	A		720 12 72-20	H	
503 20 44-26	C		503 75 24-01	B		537 01 71-01	J		724 12 87-59	F	
503 21 28-10	A J M		503 75 61-04	B		537 01 72-01	J		724 32 24-05	M	
503 21 29-06	M		503 76 29-02	A		537 01 74-01	A		725 52 91-56	M	
503 21 49-16	N		503 76 64-02	F		537 01 75-01	H		725 53 09-55	G	
503 21 70-16	Q		503 76 65-03	F		537 01 79-01	H		725 53 29-56	B	
503 21 88-20	H K L M		503 77 43-01	B	1	537 02 44-01	J	compl 1	725 53 33-55	D	
503 21 88-25	J		503 77 52-01	A		537 03 34-01	H		725 53 70-55	F	
503 22 00-01	A		503 77 59-01	D		537 03 35-02	A		731 23 14-01	G	
503 22 10-11	M		503 77 98-01	P		537 03 35-72	A		737 44 13-00	D	
503 22 24-01	J		503 78 72-01	N		537 03 38-01	A		738 22 03-25	E	
503 23 00-04	B		503 79 27-01	A		537 03 39-01	J		740 48 07-02	A	
503 23 00-42	M		503 81 13-01	B		537 03 73-01	L				
503 23 00-63	A		503 81 30-01	B		537 04 03-01	J				
503 23 00-66	A		503 82 98-01	H		537 04 05-01	M				
503 23 43-02	N		503 83 81-02	A		537 04 06-01	M				
503 23 51-08	D		503 84 61-01	J		537 04 13-01	P				
503 25 13-01	E		503 85 96-01	N		537 04 14-01	P				
503 25 61-01	D E		503 89 70-01	A		537 04 15-01	P				
503 26 02-05	J		503 89 76-01	M		537 04 16-01	P				
503 26 22-01	E		503 92 27-01	A		537 04 18-01	P				
503 27 21-01	B		503 95 90-01	F		537 04 19-01	P				
503 28 04-11	G P		503 95 90-03	F		537 04 29-01	J				
503 28 04-13	G P		503 95 90-04	F		537 04 34-01	A				
503 28 90-37	D		503 95 91-01	F		537 04 38-01	Q				
503 40 06-04	G		503 96 22-01	G		537 04 41-02	A				


1 = 537 03 39-01
2 = 501 49 48-02

Set of gaskets, Dichtungssats,
Jeu de joints, Juego de juntas,
Packningssats

N = New part, Neues teil,
Nouvelle piece, Nueva pieza
Ny detalj


EPA = Environmental Protection Agency
(for USA only)

A



A


*compl 537 33 10-01 WA




B



****compl 537 13 79-71 (3/8"x7T)**
****compl 537 13 79-72 (3/8"x8T)**

***compl 503 52 13-04**


**C**

***compl 537 00 07-01 Std**
****compl 537 00 07-02 Hd**




D***compl 537 16 97-71****E*****compl 503 99 34-04****F**

compl 503 95 90-01 FG
compl 503 95 90-03 Jungle
***compl 503 95 90-04 DF**





G




H

*compl 537 00 03-71




J***compl 503 99 11-05**


① 537 03 39-01
Packningssats
Set of gaskets
Dichtungssatz
Jeu de joints
Juego de juntas




K *compl 503 98 66-71
*compl 503 98 66-72 (G)



L *compl 503 98 67-71 WA
*compl 503 98 67-02 WA (G)




M




N

*compl 537 00 38-71




Tilotson HS 299A Tilotson HS 296A EPA




② 501 49 48-02
Packningssats
Set of gaskets
Dichtungssatz
Jeu de joints
Juego de juntas

Q Accessories
Zubehöre
Accessories
Accesorios
Tillbehör


*compl 503 55 85-02




*503 62 12-01




503 55 86-02 NV5*




503 55 86-01 NV4*



*501 91 14-01




503 13 96-01*



501 68 89-01*

Q WINTER KIT
compl 537 04 38-01



503 21 70-16 (x2)

RECOMMENDED PARTS, ACCESSORIES, LUBRICANTS

385XP CHAINSAW

	<u>Item</u>	<u>Part Number</u>	<u>Description</u>
Normal Maintenance Parts	Air Filter- Felt	537 00 93-01	
	Spark Plug	503 23 51-12	
	Fuel Filter	503 44 32-01	
	Fuel Vent	501 62 96-01	
	Ignition Module	537 27 74-01	
	Starter Housing Assy.	537 00 39-71	
	Switch On/Off	503 71 79-01	
	Front Handle	503 98 66-71	
	Chain Brake Cover	537 03 35-02	
	Chain Break Handle	537 01 69-01	
	Oil Gear	503 75 61-04	
	Fuel Cap	537 21 52-02	Clamshell Version 531 30 03-56
	Oil Cap	537 21 52-02	Clamshell Version 531 30 03-56
	Bar Nut	503 22 00-01	
	<u>Item</u>	<u>Part Number</u>	<u>Description</u>
Chainsaw Accessories	Bar	608 00 00-46	HT380-72, 20" Bar (3/8"),(.050"), <i>Clamshell Version: 531 30 05-88</i>
		608 00 00-48	HT380-84, 24" Bar (3/8"),(.050"), <i>Clamshell Version: 531 30 05-89</i>
		608 00 00-51	HT380-93, 28" Bar (3/8"),(.050")
		608 00 00-53	HT380-105, 32" Bar (3/8"),(.050")
		608 00 00-32	HA380-72, 20" Bar (3/8"),(.050")
		608 00 00-35	HA380-84, 24" Bar (3/8"),(.050")
		608 00 00-47	HT388-72, 20" Bar (3/8"),(.058")
		608 00 00-50	HT388-84, 24" Bar (3/8"),(.058")
		608 00 00-52	HT388-93, 28" Bar (3/8"),(.058")
		608 00 00-58	HT388-115, 36" Bar (3/8"),(.058")
		608 00 00-34	HA383-72, 20" Bar (3/8"),(.063")
	Chain	501 84 25-72	H46-72, 20" Chain (3/8"),(.050"), <i>Clamshell Version: 531 30 06-22</i>
		501 84 25-84	H46-84, 24" Chain (3/8"),(.050"), <i>Clamshell Version: 531 30 06-24</i>
		501 84 25-93	H46-93, 28" Chain (3/8"),(.050")
		501 84 25-05	H46-105, 32" Chain (3/8"),(.050")
		501 84 28-72	H48-72, 20" Chain (3/8"),(.058')
		501 84 28-84	H48-84, 24" Chain (3/8"),(.058')
		501 84 28-93	H48-93, 28" Chain (3/8"),(.058')
		501 84 28-15	H48-115, 36" Chain (3/8"),(.058')
		501 87 71-72	H45-72, 20: Chain (3/8"),(.063")
	Scrench	531 30 03-85	Standard combination bar nut wrench, spark plug wrench, and screwdriver
	File Kit	505 69 81-91	File Kit includes: File handle, Combination file guide, 2 round files, and 1 flat file. Use with H80 & H46 chains.
	<u>Item</u>	<u>Part Number</u>	<u>Description</u>
Lubricants	Bar and Chain	610 00 00-14	Bar and Chain Lubricant - 1 Quart
		610 00 00-34	Bar and Chain Lubricant - 1 Gallon
	2 Cycle Low Smoke Oil	610 00 00-85	2 Cycle Low Smoke Oil - 2.6 oz (1 Gallon Mix)
		610 00 00-82	2 Cycle Low Smoke Oil - 6.4 oz (2.5 Gallon Mix)

	<u>Item</u>	<u>Part Number</u>	<u>Description</u>
Protective Apparel	Protective Glasses	605 00 04-15	Lexa- Clear lens
		605 00 04-16	Lexa- Grey lens
	Helmets	505 67 53-15	Helmet System (Husqvarna)
	Protective Gloves	531 30 02-73	Xtreme Duty Work Gloves (Medium)
		531 30 02-74	Xtreme Duty Work Gloves (Large)
		531 30 02-75	Xtreme Duty Work Gloves (X-Large)
	Chaps	605 00 00-13	Pro Forest Apron Chaps (Navy Blue)
		605 00 00-14	Pro Forest Apron Chaps (Orange)

385 XP

Part Number	Description	Square	Part Number	Description	Square
501 22 04-01	BALL	P	503 28 04-11	CARBURATOR	G P
501 22 05-01	SPRING	P	503 28 04-13	CARBURETOR	G P
501 22 08-01	GASKET, METERING SIDE	P 2	503 28 90-37	PISTON RING	D
501 22 09-01	METERING DIAPHRAGM	P 2	503 40 06-04	HOSE	G
501 22 12-01	FUEL PUMP DIAPHRAGM	P 2	503 42 67-01	OIL HOSE	B
501 22 13-01	GASKET, PUMP SIDE	P 2	503 43 20-01	CLUTCH DRUM BEARING	B
501 22 15-01	SCREW	P	503 43 29-01	STARTER ROPE	N
501 22 20-01	LEVER	P	503 43 65-01	LOCK SPRING	A
501 22 21-01	SHAFT	P	503 44 32-01	FUEL FILTER	H
501 22 25-01	SPRING	P	503 48 63-01	COVER SCREW	P
501 27 08-01	SLEEVE	J	503 52 13-04	OIL PUMP	B
501 43 00-01	GROMMET	M	503 52 87-02	SPRING	K L
501 48 52-01	SCREW	P	503 53 36-01	COVER	P
501 48 54-02	SPARK PLUG CONN. KIT	M	503 54 39-01	STARTER HANDLE	P N
501 49 27-03	COVER	H	503 55 66-01	THROTTLE CATCH	H
501 49 48-02	DIAPHRAGM SET	P compl 2	503 55 85-02	TOOL KIT	Q
501 54 41-02	OIL SCREEN	B	503 55 86-01	L-SPANNER	Q
501 59 80-02	68210 RIMSPROCKET	B	503 55 86-02	L-SPANNER	Q
501 61 58-01	SPRING	B	503 56 00-05	CLAMP	G
501 62 93-08	HANDLE	M	503 57 76-02	HOSE	H
501 63 06-01	SLEEVE	N	503 57 86-01	BALL	P
501 67 35-01	SPRING	M	503 57 87-01	SCREW	P
501 68 89-01	COMB.TOOL 8-10-14	Q	503 57 89-01	HOLDER	H
501 76 83-05	HOSE	H	503 57 89-01	HOLDER	H J
501 79 51-02	WASHER	M	503 62 12-01	GREASE	Q
501 81 99-01	SCREW M5X14	M	503 62 49-01	PLUG	B
501 82 17-01	WASHER	P	503 62 61-02	CABLE	M
501 82 18-01	RETAINING RING	P	503 64 47-01	GROMMET	B
501 87 53-04	KNEE JOINT	A	503 65 27-01	SCREW	P
501 91 14-01	GREASE GUN	Q	503 65 28-01	SPRING	P
502 01 22-01	CHOKE FLAP	P	503 66 19-01	LEVER	P
502 20 65-01	SCREW	G	503 67 86-01	SPACER	J
502 20 65-05	SCREW	G	503 68 41-01	LEVER	G
502 20 83-02	KNOB	G	503 68 45-03	VIBRATION ABSORBER	M
503 08 52-01	WASHER	M	503 70 11-01	PIPE	G
503 13 96-01	COMBI TOOL	Q	503 70 99-01	BRAKE SPRING	A
503 20 02-12	SCREW	A	503 71 53-01	DECOMPRESSION VALVE	D
503 20 02-16	SCREW	F J	503 71 76-01	WIRE	H
503 20 02-20	SCREW	M	503 71 82-01	START/STOP SWITCH	M
503 20 06-08	SCREW	F	503 71 82-02	SWITCH (G)	M
503 20 07-12	SCREW	J	503 71 97-01	FELLING DOG	A
503 20 07-30	SCREW	J	503 73 44-01	GROMMET	J
503 20 16-35	SCREW	J	503 73 64-01	SPRING	H
503 20 25-12	SCREW	A	503 74 01-02	HOLDER	C
503 20 34-19	SCREW	N	503 74 93-01	SCREW	J
503 20 44-26	SCREW	C	503 74 93-01	SCREW	J
503 21 28-10	SCREW	A J M	503 75 11-03	COVER	A
503 21 29-06	SCREW	M	503 75 18-01	PIN	J
503 21 49-16	SCREW	N	503 75 22-02	BRAKE BAND	A
503 21 70-16	SCREW	Q	503 75 24-01	WASHER	B
503 21 88-20	SCREW	H K L M	503 75 61-04	PINION	B
503 21 88-25	SCREW	J	503 76 29-02	PROTECTOR	A
503 22 00-01	NUT M8 FLANGE	A	503 76 64-02	SCREEN	F
503 22 10-11	NUT M8X1	M	503 76 65-03	SUPPORT	F
503 22 24-01	NUT	J	503 77 43-01	PIPE	B
503 23 00-04	WASHER 6.1X9	B	503 77 52-01	BUSHING	A
503 23 00-42	WASHER	M	503 77 59-01	GASKET	D 1
503 23 00-63	WASHER	A	503 77 98-01	VALVE	P
503 23 00-66	WASHER	A	503 78 72-01	SPRING	N
503 23 43-02	WASHER	N	503 79 27-01	SUPPORT	A
503 23 51-08	SPARK PLUG RCJ7Y	D	503 81 13-01	SCREW	B
503 25 13-01	BALL BEARING	E	503 81 30-01	SPRING CLIP	B
503 25 61-01	NEEDLE BEARING	D E	503 82 98-01	THROTTLE TRIGGER	H
503 26 02-05	SEALING RING	J	503 83 81-02	CATCH	A
503 26 22-01	SEALING RING	E	503 84 61-01	BUFFER	J
503 27 21-01	RETAINING RING	B	503 85 96-01	STARTER PULLEY	N

IPL, 385, 385 EPA, 2005-03, 544 07 02-01

385 XP

Part Number	Description	Square		Part Number	Description	Square	
503 89 70-01	WASHER	A		537 04 05-01	CABLE	M	
503 89 76-01	CABLE	M		537 04 06-01	CABLE	M	
503 92 27-01	FELLING DOG	A		537 04 13-01	COVER	P	
503 95 90-01	MUFFLER	F		537 04 14-01	CHOKESHAFT	P	
503 95 90-03	MUFFLER	F		537 04 15-01	THROTTLESHAFT	P	
503 95 90-04	MUFFLER	F		537 04 16-01	SPRING	P	
503 95 91-01	MUFFLER NLA	F		537 04 18-01	SPRING	P	
503 96 22-01	SLEEVE	G		537 04 19-01	LEVER	P	
503 96 70-01	BUSHING	J		537 04 29-01	BUMPER	J	
503 97 50-01	CLUTCH	B		537 04 34-01	CHAIN GUIDE	A	
503 97 51-01	CLUTCH SPRING	B		537 04 38-01	WINTER SET	Q	
503 98 66-71	FRONT HANDLE	K		537 04 41-02	KIT-CHAIN TENSIONER	A	
503 98 66-72	** FRONT HANDLE HEATED	K M		537 04 66-01	PLATE	J	
503 98 67-02	HEATED WRAP HANDLE	L		537 05 13-01	BOLT	J	
503 98 67-71	HANDLE	L		537 05 16-05	FLYWHEEL	M	
503 98 74-01	DECAL	C		537 05 16-06	FLY WHEEL	M	
503 98 82-01	SCREEN	P		537 05 26-01	SPACER	M	
503 98 85-01	O-RING	P		537 06 32-01	HOLDER	M	
503 98 86-01	NEEDLES HIGH SPEED	P		537 06 53-01	ELEMENT	M	
503 99 11-05	CRANKCASE	J		537 06 89-01	SPRING	P	
503 99 34-04	CRANKSHAFT	E		537 06 90-01	LOWSPEEDNEEDLE	P	
503 99 83-01	COUPLING	A		537 06 95-01	CAP	P	
503 99 93-01	SLEEVE	G		537 06 96-01	PROTECTOR	C	
504 30 00-26	SEAL	B		537 06 98-01	PLUG	P	
504 52 14-03	BUSHING	P		537 07 00-01	CAP	P	
504 52 14-03	BUSHING	P		537 07 18-02	GENERATOR	M	
505 30 36-61	22273 SPROCKET	B		537 07 94-01	ADJUSTER	A	
505 31 65-50	INLET NEEDLE	P		537 07 94-01	ADJUSTER	A	
537 00 07-01	CYLINDER COVER	C		537 07 95-01	ADJUSTER	A	
537 00 07-02	CYLINDER COVER	C		537 08 62-01	DEFLECTOR	D	
537 00 09-01	COVER	C		537 08 67-01	BUSHING	N	
537 00 10-01	COVER	C		537 08 92-01	NUT	J	
537 00 12-01	CHOKE CONTROL	J		537 09 22-01	TANK VALVE	H	
537 00 13-01	AIR CONDUCTOR	N		537 09 54-01	GROMMET	J	
537 00 14-02	BASE	J		537 09 93-01	CONNECTOR	H	
537 00 37-01	FLANGE	G		537 10 64-01	PUMP PISTON	B	
537 00 38-71	STARTER DEVICE CPL	N		537 10 82-01	CHOKEFLAP	P	
537 00 39-71	STARTER HOUSING	N		537 10 83-01	JET	P	
537 00 57-01	GASKET	D 1		537 13 00-01	NEEDLE HIGH SPEED	P	
537 00 79-01	JET	J		537 13 72-01	SLEEVE	C	
537 00 87-01	BRAKE LEVER	A		537 13 79-71	CLUTCH ASSY	B	
537 00 88-01	PROTECTOR	H		537 13 79-72	CLUTCH ASSY	B	
537 00 91-01	FILTER HOLDER	G		537 16 22-04	IGNITION SYSTEM	M	
537 00 93-01	AIR FILTER - FELT	G		537 16 97-71	CYLINDER	D	
537 01 47-01	AIR FILTER	G		537 16 98-71	PISTON CPL 54 MM	D	
537 01 47-02	AIR FILTER	G		537 17 41-01	PROTECTOR	A	
537 01 47-03	AIR FILTER	G		537 18 98-01	THERMOSTAT	M	
537 01 55-01	PAWL	M		537 21 50-01	SEALING	H J	
537 01 65-01	GROMMET	C		537 21 52-02	TANK CAP	H J	
537 01 67-01	PROTECTOR	A		537 32 70-01	DECAL	N	
537 01 68-01	COVER	A		537 33 10-01	CLUTCH COVER ASSY	A	
537 01 68-01	COVER	A		537 38 88-01	IGNITION MODULE	M	
537 01 69-01	HAND GUARD	A		720 12 40-20	PIN 3X25	H	
537 01 71-01	FELLING DOG	J		720 12 72-20	PIN CPH8 4X20	H	
537 01 72-01	FELLING DOG	J		724 12 87-59	SCREW	F	
537 01 74-01	SLEEVE	A		724 32 24-05	SCREW 3X10	M	
537 01 75-01	VIBRATION ABSORBER	H		725 52 91-56	SCREW MC6S 4X12	M	
537 01 79-01	VIBRATION ABSORBER	H		725 53 09-55	SCREW	G	
537 02 44-01	SPACER	J		725 53 29-56	SCREW MC6S 5X16	B	
537 03 34-01	HANDLE	H		725 53 33-55	SCREW MC6S 5X25	D	
537 03 35-02	CHAIN BRAKE COVER	A		725 53 70-55	SCREW MC6S 6X20	F	
537 03 35-72	CLUTCH COVER	A		731 23 14-01	NUT	G	
537 03 38-01	DECAL	A		737 44 13-00	CLIP	D	
537 03 39-01	GASKET SET	J compl 1		738 22 03-25	BALL BEARING 6203 C3	E	
537 03 73-01	PLATE	L		740 48 07-02	O-RING	A	
537 04 03-01	VALVE	J					
IPL, 385, 385 EPA, 2005-03, 544 07 02-01							