



# 430LS

**Spare parts**

**Ersatzteile**


**Pièces détachées**

**Reserve onderdelen**

**Repuestos**


**Reservdelar**

**A** 430LS  
DRIVE UNIT



Position	Article	Quantity	Notes	Kit
1	528 86 89-01	1		
2	521 82 54-01	1		
3	514 34 42-01	1		
4	528 80 49-01	1		
5	515 63 18-01	1		4
6	516 12 55-01	1		4
7	514 38 25-01	1		4
8	521 80 40-01	1		4
9	528 84 01-01	1		4
10	521 82 20-01	1		4
11	521 82 57-01	1		4
12	521 82 18-01	1		4
13	505 16 94-01	1		4
14	512 84 57-01	1		4
15	515 63 25-01	1		4
16	505 17 15-01	1		4
17	505 17 16-01	1		4
18	521 86 11-01	1		4
20	575 38 51-01	1		
21	574 39 06-01	1		20
22	574 39 07-01	1		20
23	575 38 52,01	1		20
24	529 25 96-01	1		20
25	575 38 53-01	1		20
26	574 39 08-01	1		20
27	529 25 92-01	1		20
28	521 85 16-01	1		20
29	521 51 77-01	4		20
30	529 25 71-01	1		20
31	529 25 61-01	2		20
32	521 80 55-01	1		20
33	529 25 94-01	2		20
35	504 11 43-01	2		20
36	510 91 11-01	2		20
37	503 87 19-01			
38	503 94 03-01	1		
39	502 19 71-01	1		
40	510 90 61-01	1		
47	575 38 41-01	1		
48	574 39 56-01	1		47
49	502 84 39-01	2		47
50	970 41 39-01	2		47
51	521 65 31-01	1		
52	512 84 64-01	2		
62	529 26 64-01	1		
63	505 29 58-01	1		

**B** 430LS  
ENGINE



Position	Article	Quantity	Notes	Kit
1	528 07 33-01	1		
2	504 11 91-01	1		
3	506 74 52-01	4		
4	528 07 37-01	1		
5	528 07 02-01	1		
6	521 75 50-01	1		
7	505 04 04-01	4		
8	521 61 45-01	1		
9	521 61 48-01	2		
10	521 61 47-01	1		
11	504 11 92-01	4		
12	521 61 55-01	1		
13	504 12 12-01	1		
14	504 12 14-01	2		
15	504 12 15-01	1		
16	505 29 67-01	1		
17	504 12 10-01	2		
18	504 11 43-01	3		
19	528 07 38-01	1		
20	504 12 05-01	2		
21	504 12 06-01	1		
22	504 12 09-01	2		
23	504 12 01-01	1		
24	504 12 02-01	2		
25	521 61 60-01	1		
26	504 11 80-01	1		
27	506 68 94-01	1		
28	521 76 93-01	1		
29	512 33 20-01	1		
30	521 61 00-01	1		29
31	521 73 95-01	1		29
32	513 76 47-01	1		29
33	504 11 86-01	2		
34	506 74 57-01	2		
35	528 07 55-01	1		
36	528 07 01-01	1		35
37	502 23 84-01	1		35
38	515 37 87-01	1		35
39	506 74 09-01	1		35
40	506 74 10-01	1		35
41	505 30 67-01	1		35
42	511 35 14-01	1		35
44	506 73 86-01	1		35
45	506 74 12-01	1		35
46	505 30 79-01	2		35
47	506 74 60-01	1		35
48	506 61 26-01	1		35
49	505 30 82-01	1		35
50	506 74 11-01	4		35
51	506 74 61-01	1		35
52	521 51 55-01	2		
53	506 74 15-01	1		
54	575 58 42-01	1		
55	506 61 56-01	1		54
56	504 11 65-01	2		
57	528 07 03-01	1		
58	521 61 52-01	1		
59	521 61 54-01	1		58
60	504 11 96-01	2		
61	528 07 10-01	1		
62	521 75 51-01	1		61
63	521 75 52-01	1		61
64	521 76 82-01	1		61
65	521 76 83-01	1		61

Page B 430LS ENGINE				
Position	Article	Quantity	Notes	Kit
66	512 36 05-01	1		61
67	521 60 98-01	1		61
68	506 60 99-01	1		61
69	525 95 32-01	1		61
70	516 12 41-01	1		61
71	504 11 43-01	2		61
72	529 26 81-01	1		
73	515 39 13-01	4		
74	575 58 43-01	1		
75	511 37 76-01	1		
76	504 11 96-01	2		
77	506 74 56-01	2		
79	515 38 91-01	1		
80	515 38 93-01	1		79
81	513 18 96-01	2		
82	505 05 44-01	2		
83	513 18 95-01	2		
84	512 32 86-01	1		
85	528 07 40-01	1		
86	506 61 59-01	1		
87	512 32 88-01	1		
88	504 11 47-01	1		87
89	515 36 71-01	1		87
90	504 11 50-01	1		87
91	504 11 46-01	1		87
92	504 11 48-01	1		87
93	504 11 49-01	1		87
94	506 61 47-01	1		87
95	515 38 56-01	1		87
96	504 11 44-01	1		
97	506 74 56-01	4		
98	528 07 49-01	1		
99	528 07 43-01	1		98
100	528 07 44-01	1		98
101	506 67 38-01	1		98
102	528 07 47-01	1		
103	575 33 11-01	1		
104	575 33 14-01	1		103
105	528 06 80-01	1		
106	505 30 96-01	1		105
107	515 36 94-01	1		105,106
108	506 74 43-01	1		105,106
109	506 74 68-01	1		105,106
110	506 74 58-01	1		105,106
111	521 61 66-01	1		105
112	506 61 46-01	1		105
113	506 70 70-01	1		105
114	512 84 56-01	3		
115	521 61 67-01	1		
116	575 63 88-01	1		
117	575 76 64-01	1		
118	506 74 42-01	1		
119	521 53 27-01	1		
120	505 31 20-01	1		119
121	521 53 31-01	1		119
122	528 07 48-01	1		
123	523 07 14-01	1		
124	505 30 83-01	1		