





455 Rancher 460

Spare parts
Ersatzteile
Pièces détachées
Reserve onderdelen
Repuestos
Reservdelar


PART NUMBER	SQUARE NOTE	PART NUMBER	SQUARE NOTE	PART NUMBER	SQUARE NOTE	PART NUMBER	SQUARE NOTE
501 46 69-01	N	503 92 31-01	M	537 28 23-01	K		
501 46 84-01	N	503 93 51-01	N	537 28 32-01	D		
501 46 85-01	N	503 93 66-01	L	537 28 41-01	D	N	
501 46 87-01	N	503 97 38-01	K	537 28 42-01	D	N	
501 48 54-02	E	503 98 74-01	C	537 28 43-01	K	N	
501 66 61-01	N	503 99 86-01	M	537 28 63-01	A	N	
501 69 17-01	P	504 13 09-06	N	537 28 64-01	A	N	
501 76 83-25	G	504 21 00-49	N	537 28 65-01	A	N	
502 11 98-01	N	504 21 00-50	N	537 28 66-01	A	N	
502 21 36-01	N	504 35 09-06	N	537 28 76-01	F		
	1		1				
503 20 02-16	G	505 30 51-25	D	537 28 77-01	F		
503 20 05-27	H	505 31 67-17	N	537 29 16-02	B	N	
503 20 34-30	C	505 31 67-36	N	537 29 17-02	B	N	
503 21 02-16	M	505 52 01-25	N	537 29 27-01	E	N	
503 21 29-10	D	505 52 01-27	N	537 29 30-02	H	N	
503 21 53-20	E	530 02 61-19	K	537 29 65-01	K	N	
503 21 55-25	G	530 03 50-15	N	537 29 86-01	A	N	
503 21 68-20	K	537 00 34-01	N	537 30 46-01	M	N	
503 21 70-10	A,K	537 01 74-01	A	537 30 49-01	G	N	
503 21 70-16	Q	537 02 71-01	B	537 30 62-01	N		
503 21 73-21	D	537 04 24-02	L	537 30 89-01	C	N	
503 21 74-12	L	537 04 24-08	L	537 31 05-01	H	N	
503 21 74-16	B	537 04 30-01	A	537 31 40-01	J	N	
503 21 74-50	G	537 06 93-01	B	537 31 79-01	L	N	
503 21 77-16	D	537 07 94-02	A	537 32 04-02	H	N	
503 21 88-25	M	537 08 90-01	A	537 32 05-01	H	N	
503 22 00-01	A	537 09 25-01	D	537 32 10-01	G	N	
503 22 04-01	E	537 10 55-02	B	537 32 30-01	G	N	
503 22 69-02	L	537 10 80-01	A	537 32 33-01	D	N	
503 23 00-60	B	537 11 05-03	B	537 32 33-02	D	N	
503 23 00-63	A	537 16 21-05	E	537 33 21-01	B	N	
503 23 51-08	H	537 21 50-01	L	537 35 60-01	Q	N	
503 24 09-06	B,H,J	537 21 51-02	L	537 35 91-01	B	N	
503 25 16-01	J	537 21 52-02	L	537 40 13-02	H	N	
503 25 52-01	B	537 22 78-01	K	537 40 35-01	K		
503 26 19-01	J	537 22 84-01	B	537 40 66-01	N		
503 28 21-01	G,N	537 23 05-01	M	537 40 67-01	N		
503 28 90-46	H	537 23 06-01	M	537 40 68-01	N		
503 28 90-50	H	537 23 07-01	M	537 40 69-01	N		
503 40 59-01	Q	537 23 25-01	D	537 40 70-01	N		
503 42 43-01	H	537 23 61-01	G	537 40 71-01	N		
503 43 65-01	K	537 24 08-01	L	537 40 72-01	N		
503 44 32-01	L	537 24 14-01	G	537 40 73-01	N		
503 46 59-01	A	537 24 15-01	G	537 40 74-01	N		
503 55 22-01	H	537 24 17-01	D	537 40 75-01	N		
503 56 34-01	N	537 24 29-01	M	537 40 76-01	N		
503 56 42-01	N	537 24 56-01	E	537 40 77-01	N		
503 57 42-01	N	537 24 57-01	H, K	537 40 79-01	N		
503 57 76-02	L	537 24 58-01	H, K	537 40 80-01	N		
503 57 89-01	L	537 25 15-01	F	537 40 81-01	N		
503 58 46-01	N	537 25 15-02	F	537 40 82-01	N		
503 73 58-01	L	537 25 23-01	F	537 40 83-01	N		
503 78 32-01	E	537 25 26-01	B	537 40 84-01	N		
503 79 05-02	E	537 25 29-01	B	537 40 85-01	N		
503 80 04-01	N	537 25 55-01	G	537 40 86-01	N		
503 85 41-01	M	537 25 56-02	G	537 40 87-01	N		
503 85 52-01	A	537 25 57-01	G,Q	537 40 88-01	N		
503 86 92-01	M	537 25 57-02	G	537 40 90-01	N		
503 86 93-01	K	537 25 57-03	G	537 40 91-01	N		
503 86 97-01	G	537 26 04-01	K	537 40 92-01	N		
503 89 08-02	A	537 26 05-01	M	537 41 26-01	N		
503 89 15-01	B	537 26 08-01	G	721 11 64-30	B		
503 89 16-01	B	537 26 09-01	D	725 53 68-55	F		
503 89 24-01	K	537 26 14-01	B	735 31 08-20	A		
503 89 29-01	A	537 26 15-01	B	737 43 12-00	H		
503 89 67-01	N	537 26 24-01	M	740 48 07-02	A		
503 91 06-71	K	537 27 13-01	K				
503 91 39-01	N	537 27 27-01	E				
503 91 40-01	N	537 27 80-01	L				
503 91 54-01	N	537 28 20-02	K				

1 = 537 41 26-01 Set of gaskets, Dichtungssatz, N = New part, Neues teil,
Jeu de joints, Juego de juntas, Nouvelle piece, Nueva pieza
Packingssatz Ny detalj


A***compl 537 28 63-01****B*****compl 537 25 29-01 455 Rancher******compl 537 10 55-02 460**

***compl 537 30 89-01**


(x3) *503 20 34-30-



***compl 537 28 42-01**




E




F

***compl 537 25 15-01 FF**
***compl 537 25 15-02 DF**




G





H

*compl 537 32 04-02 **455 Rancher**
*compl 537 32 05-01 **460**


**J**

*compl 537 31 40-01



K***compl 537 28 20-02**

L



503 21 88-25

537 26 24-01

503 99 86-01

537 26 05-01

537 23 06-01

537 23 07-01

(x3) 503 21 02-16

537 30 46-01

503 85 41-01

503 21 88-25

503 21 02-16 (x3)

503 86 92-01

537 24 29-01

503 21 88-25


503 92 31-01

537 23 05-01

503 86 92-01

N


*compl 503 28 21-01 Walbro WTA-29






① 537 41 26-01
Set of gaskets
Dichtungssatz
Jeu de joints
Juego de juntas
Packningssats

P

Tillbehör
Accessories
Zubehöre
Accessoires
Accesorios

**Q**

WINTER KIT
*compl 537 35 60-01



RECOMMENDED PARTS, ACCESSORIES, LUBRICANTS

455 RANCHER & 460 CHAINSAW

	<u>Item</u>	<u>Part Number</u>	<u>Description</u>
Normal Maintenance Parts	Air Filter - Felt	537 25 57-01	
	Air Filter - Nylon	537 25 57-02	
	Spark Plug	503 23 51-11	Clamshell Version 531 30 06-88
	Fuel Filter	503 44 32-01	
	Primer Bubble	503 93 66-01	
	Ignition Module	537 16 21-05	
	Starter Housing Assy.	537 28 42-01	
	On/Off Switch	537 25 55-01	
	Choke Control	537 25 56-01	
	Handle, Left	537 23 07-01	
	Handle, Right	537 23 06-01	
	Chain Brake	537 28 63-01	
	Oil Gear	537 25 29-01	
	Fuel Cap	537 21 52-02	Clamshell Version 531 30 03-56
	Oil Cap	537 21 52-02	Clamshell Version 531 30 03-56
	Bar Nut	503 22 00-01	
	<u>Item</u>	<u>Part Number</u>	<u>Description</u>
Chainsaw Accessories	Bar	508 95 74-68	FT280-68, 18" Bar (3/8"),(.050"), <i>Clamshell Version: 531 30 04-42</i>
		608 00 01-57	FT280-72, 20" Bar (3/8"),(.050"), <i>Clamshell Version: 531 30 04-40</i>
	Chain	501 84 65-68	H80-68, 18" Chain (3/8"),(.050"), <i>Clamshell Version: 531 30 04-43</i>
		501 84 65-72	H80-72, 18" Chain (3/8"),(.050"), <i>Clamshell Version: 531 30 04-41</i>
	Carrying Case	100 00 01-07	Powerbox Carrying Case with 20" Bar Protector
	Scrench	531 30 03-85	Standard combination bar nut wrench, spark plug wrench, and screwdriver
	File Kit	505 69 81-91	File Kit includes: File handle, Combination file guide, 2 round files, and 1 flat file. Use with H80 & H46 chains.
	<u>Item</u>	<u>Part Number</u>	<u>Description</u>
Lubricants	Bar and Chain	610 00 00-14	Bar and Chain Lubricant - 1 Quart
		610 00 00-34	Bar and Chain Lubricant - 1 Gallon
	2 Cycle Low Smoke Oil	610 00 00-85	2 Cycle Low Smoke Oil - 2.6 oz (1 Gallon Mix)
		610 00 00-82	2 Cycle Low Smoke Oil - 6.4 oz (2.5 Gallon Mix)
	<u>Item</u>	<u>Part Number</u>	<u>Description</u>
Protective Apparel	Protective Glasses	605 00 04-15	Lexa- Clear lens
		605 00 04-16	Lexa- Grey lens
	Helmets	505 67 53-15	Helmet System (Husqvarna)
	Protective Gloves	531 30 02-73	Xtreme Duty Work Gloves (Medium)
		531 30 02-74	Xtreme Duty Work Gloves (Large)
		531 30 02-75	Xtreme Duty Work Gloves (X-Large)
	Chaps	605 00 00-13	Pro Forest Apron Chaps (Navy Blue)
		605 00 00-14	Pro Forest Apron Chaps (Orange)

455 Rancher & 460							
Part Number	Description	Square		Part Number	Description	Square	
501 46 69-01	SCREW	N		503 58 46-01	SCREW	N	
501 46 84-01	SPRING	N		503 73 58-01	FUEL TANK BUSHING	L	
501 46 85-01	BALL	N		503 78 32-01	SPRING, STARTER CATCH	E	
501 46 87-01	SCREW	N		503 79 05-02	RIVET	E	
501 48 54-02	SPARK PLUG CONN. KIT	E		503 80 04-01	JET	N	
501 66 61-01	FUEL INLET SCREEN	N		503 85 41-01	VIBRATION ABSORBER	M	
501 69 17-01	COMBI TOOL	P		503 85 52-01	SLEEVE	A	
501 76 83-25	FUEL HOSE 242/42	G		503 86 92-01	MOVEMENT LIMITER	M	
502 11 98-01	CLIPS	N		503 86 93-01	SUPPORT	K	
502 21 36-01	DIAPHRAGM, FUEL PUMP	N 1		503 86 97-01	SPRING	G	
503 20 02-16	SCREW	G		503 89 08-02	JOINT	A	
503 20 05-27	SCREW	H N		503 89 15-01	SPRING	B	
503 20 34-30	SCREW	C		503 89 16-01	SPRING	B	
503 21 02-16	SCREW	M N		503 89 24-01	CATCH	K	
503 21 29-10	SCREW	D		503 89 29-01	PIN	A	
503 21 53-20	SCREW	E		503 89 67-01	DIAPHRAGM	N	
503 21 55-25	SCREW	G		503 91 06-71	CHAIN CATCHER	K	
503 21 68-20	SCREW	K		503 91 39-01	LIMITER CAP	N	
503 21 70-10	SCREW	A,K		503 91 40-01	LIMITER CAP	N	
503 21 70-16	SCREW	Q		503 91 54-01	CAP	N	
503 21 73-21	SCREW	D		503 92 31-01	SPRING	M	
503 21 74-12	SCREW	L		503 93 51-01	THROTTLE FLAP	N	
503 21 74-16	SCREW	B N		503 93 66-01	AIR PURGE BUBBLE	L	
503 21 74-50	SCREW	G		503 97 38-01	FELLING DOG	K	
503 21 77-16	SCREW	D		503 98 74-01	DECAL	C	
503 21 88-25	SCREW	M		503 99 86-01	SPRING	M	
503 22 00-01	NUT M8 FLANGE	A		504 13 09-06	GASKET	N 1	
503 22 04-01	NUT W/ WASHER	E		504 21 00-49	SPRING, H-NEEDLE	N	
503 22 69-02	CLIP	L		504 21 00-50	SPRING/COMPRESSION	N	
503 23 00-60	WASHER	B		504 35 09-06	GASKET	N 1	
503 23 00-63	WASHER	A		505 30 51-25	STARTER ROPE	D	
503 23 51-08	SPARK PLUG RCJ7Y	H N		505 31 67-17	SCREW	N	
503 24 09-06	BEARING	H,J N		505 31 67-36	E CLIP	N	
503 25 16-01	BEARING	J N		505 52 01-25	FULCRUM PIN	N	
503 25 52-01	NEEDLE BEARING	B		505 52 01-27	LEVER	N	
503 26 19-01	COVER	J N		530 02 61-19	VALVE-CHECK (DUCKBILL)	K	
503 28 21-01	CARBURETOR	G,N N		530 03 50-15	SCREW SHUTTERS	N	
503 28 90-46	PISTON RING	H N		537 00 34-01	SCREW	N	
503 28 90-50	PISTON RING	H N		537 01 74-01	SLEEVE	A	
503 40 59-01	PLUG	Q		537 02 71-01	SCREW	B	
503 42 43-01	NIPPLE	H		537 04 24-02	FUEL HOSE/38MM	L	
503 43 65-01	LOCK SPRING	K		537 04 24-08	HOSE	L	
503 44 32-01	FUEL FILTER	L		537 04 30-01	BRAKE BAND	A	
503 46 59-01	SPRING	A		537 06 93-01	PUMPPISTON	B	
503 55 22-01	CYLINDER PLUG	H		537 07 94-02	SCREW	A N	
503 56 34-01	INLET NEEDLE	N		537 08 90-01	PROTECTOR	A	
503 56 42-01	SPRING	N		537 09 25-01	PULLEY	D	
503 57 42-01	WELCH PLUG	N		537 10 55-02	PUMP	B N	
503 57 76-02	HOSE	L		537 10 80-01	COVER	A	
503 57 89-01	HOLDER	L		537 16 21-05	IGNITION/SPARK PLUG KIT	E	
IPL, 455 Rancher, 460, 2005-03, 544 05 85-01							

IPL, 455 Rancher, 460, 2005-03, 544 05 85-01

455 Rancher & 460							
Part Number	Description	Square		Part Number	Description	Square	
537 21 50-01	SEALING	L		537 29 17-02	CLUTCH DRUM	B N	
537 21 51-02	COVER	L N		537 29 27-01	FLYWHEEL	E N	
537 21 52-02	TANK CAP	L		537 29 30-02	PISTON CPL.	H N	
537 22 78-01	BOLT	K N		537 29 65-01	SCREW, HAND GUARD	K N	
537 22 84-01	CYLINDER	B N		537 29 86-01	DECAL, CLUTCH COVER	A N	
537 23 05-01	FRONT HANDLE	M N		537 30 46-01	VIBRATIONS ABSORBER	M N	
537 23 06-01	HANDLE HALF, RIGHT	M N		537 30 49-01	LOOP	G N	
537 23 07-01	HANDLE HALF, RIGHT	M N		537 30 62-01	BUCKLE	N	
537 23 25-01	HANDLE	D		537 30 89-01	CYLINDER COVER	C N	
537 23 61-01	PARTITION	G N		537 31 05-01	VALVE	H N	
537 24 08-01	SLEEVE	L N		537 31 40-01	CRANKSHAFT	J N	
537 24 14-01	BELLOWS	G N		537 31 79-01	JET	L N	
537 24 15-01	FLANGE	G N		537 32 04-02	CYLINDER	H N	
537 24 17-01	RETURN SPRING	D N		537 32 10-01	INDUCTION MANIFOLD	G N	
537 24 29-01	PIN	M N		537 32 30-01	FILTER HOLDER	G N	
537 24 56-01	PAWL	E N		537 32 33-01	DECAL	D N	
537 24 57-01	GASKET	H, K N		537 33 21-01	OIL SCREEN	B N	
537 24 58-01	GASKET	H, K N		537 35 60-01	WINTER SET	Q N	
537 25 15-01	MUFFLER	F N		537 40 35-01	PLUG	K	
537 25 23-01	SCREEN	F		537 40 66-01	SLEEVE	N	
537 25 26-01	PINION	B N		537 40 67-01	SLEEVE	N	
537 25 29-01	OIL PUMP	B N		537 40 68-01	CHOKE FLAP	N	
537 25 55-01	STOP LEVER	G N		537 40 69-01	SHAFT	N	
537 25 57-01	AIR FILTER	G, Q N		537 40 70-01	SPRING	N	
537 25 57-02	AIR FILTER	G N		537 40 71-01	LEVER	N	
537 25 57-03	AIR FILTER	G N		537 40 72-01	ROD	N	
537 26 04-01	GROMMET	K N		537 40 73-01	COVER	N	
537 26 05-01	THROTTLE TRIGGER	M N		537 40 74-01	SHAFT	N	
537 26 08-01	THROTTLE ROD	G N		537 40 75-01	SHAFT	N	
537 26 09-01	AIR CONDUCTOR	D N		537 40 76-01	PLATE	N	
537 26 14-01	OIL HOSE	B N		537 40 77-01	VALVE	N	
537 26 15-01	OIL HOSE	B N		537 40 79-01	JET	N	
537 26 24-01	THROTTLE LOCK	M N		537 40 80-01	SLEEVE	N	
537 27 13-01	PLATE	K N		537 40 81-01	GASKET	N	
537 27 27-01	CABLE ASSY	E N		537 40 82-01	SCREW	N	
537 27 80-01	SWITCH PLATE	L N		537 40 83-01	SCREW	N	
537 28 20-02	CRANKCASE	K N		537 40 84-01	SPRING	N	
537 28 23-01	AIR CONDUCTOR	K		537 40 85-01	SPRING	N	
537 28 32-01	SLEEVE	D		537 40 86-01	SPRING	N	
537 28 41-01	STARTER DEVICE	D N		537 40 87-01	SCREW	N	
537 28 42-01	STARTER HOUSING CPL.	D N		537 40 88-01	SCREW	N	
537 28 43-01	HAND GUARD	K N		537 40 90-01	NIPPLE	N	
537 28 63-01	CLUTCH COVER	A N		537 40 91-01	NIPPLE	N	
537 28 64-01	COVER	A N		537 40 92-01	LEVER	N	
537 28 65-01	SCREW	A N		721 11 64-30	PIN	B	
537 28 66-01	PAWL	A N		725 53 68-55	SCREW MC6S 6X16	F	
537 28 76-01	HEAT SHIELD	F		735 31 08-20	E-RING 4	A	
537 28 77-01	GASKET	F		737 43 12-00	WRIST PIN CLIP	H	
537 29 16-02	CLUTCH DRUM	B N		740 48 07-02	O-RING	A	

IPL, 455 Rancher, 460, 2005-03, 544 05 85-01

IPL, 455 Rancher, 460, 2005-03, 544 05 85-01