


Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530047963	Assy.—Isolator	28.	530037817	Starter Pulley	54.	530015922	Nut—"U"—Type
2.	530047608	Limiter Strap	29.	530015892	Screw	55.	530047605	Knob—Choke
3.	530042082	Spring—Isolator	30.	530057444	Fan Housing	56.	530049005	Grommet—Knob
4.	530015123	Washer	31.	530069232	Kit—Rope	57.	530056597	Assy—Chassis (Incl. 22,23,37 filter & fuel lines)
5.	530016018	Screw	32.	530037485	Starter Handle	58.	530071259	Kit—Oil Pump (incl. 59,60,62)
6.	530015843	Screw	33.	530027531	Recoil Spring	59.	530037820	Gear—Worm Spring
7.	530036142	Sleeve—AV Spring	34.	530015920	Screw	60.	530049477	Elbow—Oil Pickup
8.	530047583	Front Handle	35.	530015127	Washer—Flywheel	61.	530016064	Screw
9.	530015940	Screw	36.	530039209	Assy—Flywheel	62.	530019206	Seal Block
10.	530015814	Screw	37.	530047192	Fuel Cap Ass'y.	63.	530047663	Assy—Oil Pick-up (Incl. 64—65)
11.	952051338	Chain—18"	38.	530023877	Fitting—fuel line	64.	530038373	Pick-up Oiler
12.	952044418	Bar—18"	39.	530069216	Kit—Fuel line (large)	65.	530056533	Oil Filter
13.	530015826	Pin—Bar Adjust	40.	530047631	Grommet—Cable	66.	530015907	Washer—Thrust
14.	530038593	Retainer—Bar Adjust	41.	530047602	Cable—Throttle	67.	530047061	Assy.—Clutch Drum w/bearing
15.	530069611	Kit—Bar Adj. (incl.13,14)	42.	530047581	Cover—Rear Handle	68.	530015611	Washer—Clutch
16.	530015917	Nut—Bar Mounting	43.	530015886	Screw	69.	530014949	Assy. Clutch
17.	530057447	Assy—Chain Brake	44.	530015906	Screw			
18.	530016132	Screw	45.	530036098	Throttle Lockout			
19.	530038238	Plate—Bar Mounting	46.	530036097	Trigger—Throttle			
20.	530015814	Screw	47.	530042082	Spring—Isolator			
21.	530029850	Chain Catcher	48.	530047582	Handle—Rear			
22.	530016133	Bolt—Bar	49.	530015814	Screw			
23.	530010846	Oil Cap Ass'y.	50.	530053274	Assy. Isolator—lower			
24.	530071666	Kit—Oil Check Valve	51.	530071385	Kit—Isolator (Upper)			
25.	530023817	Spring—Starter Dog	52.	530015875	Screw			
26.	530016134	Nut—Flywheel	53.	530069572	Kit—Switch			
27.	530016080	Screw						

✓ = NEW PART NUMBER FOR THIS IPL

★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)

= THESE PARTS ARE ILLUSTRATED FOR CLARITY. ORDER COMPLETE ASSEMBLY.

⚠ WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530016153	Screw	17.	530049870	Back Plate-Muffler	34.	530049700	Adapter-Carb.
2.	530047578	Shield-Cylinder	18.	530016132	Screw	35.	530016386	Screw
3.	530047213	Assy-Air Purge	19.	530036103	Screen-Spark	36.	530069608	Carb. Gasket
4.	530015780	Screw	20.	530037813	Diffuser-Muffler	37.	530071621	Kit-Carburetor (WT-625)
5.	530095646	Assy-Fuel Pick-up	21.	530069608	Gasket-Muffler			(Note: No Repair kits are available for this carburetor)
6.	530069247	Kit-Line Purge/Carb. (Small Dia)	22.	530047207	Assy-Muffler (Incl. 17-21)	38.	530047604	Housing-Air Filter
7.	530069216	Kit-Line Purge/Tank (large line)	23.	530047062	Assy-Crankshaft	39.	530016101	Nut
8.	530035526	Grommet-Carb Adjust.	24.	530037935	Cap-Crankcase	40.	530037793	Air Filter - Foam
9.	530054144	Seal-Carb Adapter	25.	530069608	Kit-Engine Gasket (incl. 36,32,21)			Not Shown
10.	952030150	Spark Plug (RCJ-7Y)	26.	530031163	Scrunch			
11.	530016136	Clip-High Tension Lead	27.	530056363	Assy-Seal & Bearing			
12.	530049117	Assy-Wire Harness (includes switch)	28.	530038729	Ring-Piston			
13.	530015814	Screw	29.	530015697	Retainer - Piston Pin			
14.	530039198	Module-Ignition	30.	530071408	Kit-Piston - (incl. 28-29)			
15.	530047442	Strap-Ground	31.	530071412	Kit-Cylinder			
16.	530037652	Insulator-Heat	32.	530069608	Gasket-Carb. Adapter			
			33.	530016187	Screw			
								530163693 Manual
								530057267 Decal-Inst.

↖ = NEW PART NUMBER FOR THIS IPL

★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)