




⚠ WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530058381	Bolt	10.	130012121	Piston-Engine	19.	530058389	Assy-Crankshaft (incl. #12)
2.	110052133	Cylinder-Engine	11.	530094024	Pin-Piston	20.	920252134	Shim-T=0.10
3.	110602350	Gasket-Cylinder	12.	530094027	Bearing-Needle		920252135	Shim-T=0.20
4.	921502180	Bolt 6x65	13.	140022330	Crankcase		530094030	Shim-T=0.40
5.	490702577	Muffler-Comp.	14.	223B0630	Screw-Pan-WS		530058394	Shim-T=0.60
6.	110092873	Gasket-Muffler	15.	214B0608	Screw-Pan	21.	110092521	Gasket-Crankcase
7.	180772093	Arrester-Spark	16.	751Q0600	Gasket	22.	140022333	Crankcase
8.	530094023	Ring-Piston Set	17.	920492076	Seal-Oil	23.	551A0610	Pin-Dowel
9.	530094025	Ring-Snap	18.	920452005	Bearing-Ball 6202C3			

✓ = NEW PART NUMBER FOR THIS IPL

* = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)

Note: Illustrations may differ from actual models due to design changes






Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530058344	Bolt-Lock	16.	530094085	Cap-Spark Plug	31.	921442046	Spring-Return
2.	572L0600	Nut-Nylon	17.	530094086	Terminal	32.	131652070	Pawl-Recoil Starter
3.	51123179	Case-Fan	18.	920702107	Plug-Spark	33.	315B0800	Nut-Hex (fine)
4.	51125112	Fan	19.	490062051	Boot	34.	410B0800	W-Plain-S
5.	530089324	Nut-Hex	20.	920592233	Tube-6x7.4x300	35.	131692386	Plate-Recoil Starter
6.	51123178	Case-Fan	21.	920092218	Screw	36.	530058416	Grip-Recoil Starter
7.	36063105	Cover-Fan	22.	922002019	Washer	37.	530058422	Screw
8.	412L0665	Screw-Socket	23.	591012085	Reel- Starter Recoil	38.	130702064	Guide-Rope
9.	470L0520	Screw-Tapping m5x20	24.	921442038	Spring-Recoil	39.	591062117	Rope 3.8x850
10.	530089368	Isolator-Vibro Rubber	25.	314R1000	Nut-Hex (fine)	40.	320992210	Case-Recoil Starter
11.	530058346	Bolt-Lock	26.	920222147	Washer	41.	490882380	Starter-Recoil (incl.# 21-40)
12.	530089445	Assy-Ignition Coil	27.	210502260	Flywheel			
13.	530094080	Bolt	28.	920382078	Key			
14.	920712077	Grommet	29.	920332010	Ring-Snap			
15.	260112321	Wire-Lead	30.	490802155	Pulley-Starting			

✓ = NEW PART NUMBER FOR THIS IPL


★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)

Note: Illustrations may differ from actual models due to design changes



⚠ WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	921512063	Bolt	8.	530058478	Element-Air Filter	15.	530058474	Tube 3x6x130
2.	490892370	Shroud-Engine	9.	530058479	Cap-Air Filter	16.	530058471	Grommet-Tank
3.	920092285	Screw	10.	530058366	Assy-Tank Cap	17.	530058470	Filter-Fuel
4.	490892298	Shroud-Engine	11.	36066-113	Tank-Fuel			
5.	920092274	Screw	12.	530058367	Assy-Fuel Pickup (Incl. 13-17)			
6.	530058475	Assy-Air Filter Case	13.	530058473	Tube 3x5x250			
7.	530058477	Plate-Air Filter	14.	530058472	Clamp-Fuel Filter			





⚠ WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530058433	Gasket-Insulator	12.	530058453	Lever	23.	530058439	Arm
2.	530058431	Adapter	13.	530058450	Screw	24.	530058440	Washer
3.	530058434	Gasket	14.	160302078	Valve-Float	25.	530058441	Ring-Snap
4.	233B0520	Screw-Pan-WP	15.	530058454	Gasket	26.	530058442	Packing
5.	214B0616	Screw-Pan	16.	530058455	Diaphragm	27.	920552147	O-Ring
6.	530058432	Insulator	17.	530058456	Body	28.	530058444	Jet-Main #60
7.	530058435	Gasket	18.	530058457	Pump-Priming	29.	530058445	Gasket
8.	530058477	Body	19.	530058458	Cover-Primer Pump	30.	530058446	Diaphragm
9.	140432051	Filter	20.	530058437	Bracket	31.	530058436	Assy-Carburetor (WYK-106-108)
10.	530058449	Spring	21.	530058459	Screw			
11.	920432094	Pin	22.	530058438	Screw			

Note: Illustrations may differ from actual models due to design changes



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530089316	Nut-Nylon Flange	9.	375L0615	Screw m6x15	16.	530089386	Pipe-Base
2.	530089444	Washer	10.	530089363	Pipe-Elbow C.P.	17.	71056208	Assy-Throttle Lever
3.	530089326	Nut-Hex-U	11.	530089212	O-Ring	18.	530089387	Pipe-Middle
4.	376L0616	Screw-Truss	12.	68031120	Band-Hose	19.	530089388	Pipe-Bend
5.	91027128	Pad-Knapsack	13.	530089436	Clamp-Wire	20.	540122578	Cable-Throttle
6.	68027107	Clip	14.	530089230	Band-Wire	21.	320992326	Case
7.	36063196	Band-Shoulder	15.	530089225	Pipe-Flex			
8.	36122124	Frame-Knapsack						

✓ = NEW PART NUMBER FOR THIS IPL

* = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)