








Ref #	Part Number	Qty	Description
1	501221101		Screw
2	505316462		Diaphragm Cover
3	501220901		Metering Diaphragm
4	501220801		Gasket
5	501485201		Screw
6	501222101		Shaft
7	501222001		Lever
8	501222501		Spring
9	501466701		Needle
10	501502401		Governor
11	501485001		Gasket
12	501821801		Retaining Ring
13	503230102	KS412 Gas Saw Page 2 of 8	Washer
14	501238801	CARBURETOR	Nipple
15	501222401		Filter
16	505316495		Sealing Ring
17	501427101		Bushing
18	501221201		Diaphragm
19	501221301		Gasket
20	501221401		Cover
21	501220301		Plug
22	505316613		Valve
23	501223001		Screw
24	502012201		Choke Flap
25	505316602		Choke Shaft
26	501220401		Ball
27	501222501		Screw
28	505316605		Spring
29	505316458		Spring
30	501221701		high Speed Spring
31	505316454		Screw
32	501268501		Idle Adjustment Screw
33	505316603		Idle Screw
34	502058301		Ball
35	505316619		Throttle Shaft
37	505316114		Throttle Flap
38	501221501		Screw



Ref #	Part Number	Qty	Description
1	503203009		Screw
2	503226601		Nut
3	506029401		Spring
4	503220001		Nut
5	506030601		Adjuster
6	506030001		Front Pulley
7	503230104		Washer
8	503200004		Screw
9	506143201		Stud
10	503200012		Screw
12	506072501		Cutting Arm
14	505303237		Clutch Ass'y. (Incl. 16, 17)
15	505277230	KS412 Gas Saw Page 4 of 8	Rubber Plug
16	505303247	EXTERNAL POWER UNIT	Weight
17	505294112		Spring
18	503230111		Washer
19	506073701		Drive Wheel Ass'y.
20	505302415		Needle Bearing
21	505268303		Cover
22	505275715		Seal Ring
23	506033201		Bolt
24	506029201		Belt Guard
25	725244981		Screw
26	503230033		Washer
27	506033001		V-Belt
28	506029102		Arm
29	738220229		Ball Bearing
30	506028601		Spacer
31	506036201		Washer
32	506028401		Washer
33	506036202		Washer
34	506036204		Spacer
35	506034501		Plate
36	725232751		Screw
37	506028501		Axle
39	506028801		7/8"
39	506028802		20mm
39	506028803		1"
39	506028804		30.5mm
40	506028701		Washer
41	506028901		Washer
42	506033201		Bolt
43	506029801		Handle
44	506029501		Spacer
45	503230005		Washer
46	506029601		Spring
48	735310920		E-Ring
50	506142701		Shield
	501691702		Wrench Not Shown.
	503240602		Flywheel Locking Pin Not Shown.
	505381307		Wrench 8mm Not Shown.



Ref #	Part Number	Qty	Description
1	735581800		Lockwasher
2	505269427		Throttle Rod
3	503230011		Washer
4	505267673		Spacer
5	505279103		Throttle Control
6	505295614		Spring
7	505279104		Throttle Catch
8	505340754		Handle
9	505340795		Right Handle
10	503179901		Stop Button
11	503401701		Contact Spring
12	505279511		Plate
13	503200001	KS412 Gas Saw, Page 6 of 8	Screw
14	503206420	HANDLES & COVER	Screw
15	503230035		Washer
16	505315569		Filter Cover
17	503200008		Screw
18	505315571		Filter
19	506074001		Air Filter
20	505397573		Decal
21	505397579		Decal
22	740420200		O Ring
23	503220101		Plug
24	506073901		Cylinder Cover
25	503208601		Stud
26	506076301		Seal Kit
27	506076401		Filter w/Seal
28	505269289		Bracket
29	505310439		Intake Pipe
30	506096401		Gasket
31	505316621		Carburetor
32	503490801		Gasket
33	505279060		Insulator Flange
34	503490901		Gasket
35	503200018		Screw
36	503226501		Square Nut
37	721425820		Spring Pin
38	503400001		Choke Button
42	505269444		Choke Rod
43	503401801		Cable Holder
44	729571301		Screw
46	503155902		Right Bracket
47	503401302		Left Bracket
48	506072601		Front Handle
49	503200003		Screw
52	503200004		Screw
53	505279512		Absorber
55	503200035		Bolt w/Washer
56	505269302		Bracket
57	503200006		Screw
58	505279513		Absorber
59	503200016		Screw
60	506039901		Support
61	503200010		Screw



⚠ WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

Ref #	Part Number	Qty	Description
1	505312226		Fuel Cap (Incl. 2)
2	740481804		O Ring
3	505318357		Fuel Tank
4	501768301		Hose
5	504357201		Vent Filter
6	501768304		Hose
7	503164001		Vent
8	505310769		Vent Fitting
9	503200009		Screw
10	505350150		Muffler Ass'y.
11	503200005		Screw
13	503454001		Gasket
14	506077001	KS412 Gas Saw, Page 8 of 8	Cylinder/Piston
15	501511203	INTERNAL POWER UNIT	Piston Ring
16	505265814		Retaining Ring
17	506077101		Piston
18	506076601		Crankcase Ass'y. (Incl.35,48,49,51, & 65)
20	503491101		Gasket
21	503235112		Spark Plug
22	501485601		Spring
23	501485402		Spark Plug
24	503200001		Screw
25	505340920		Armature Plate
26	503411801		Ground Wire
27	505320179		High Tension Wire
28	505277516		Insulating Cap
29	506027201		Ignition Unit
31	723129751		Screw
32	505302333		Needle Bearing
33	503158001		Crankshaft Ass'y. (Incl.32,34,35)
34	735880600		Woodruff Key
35	503250001		Ball Bearing
36	720130700		Parallel Pin
37	505277566		Sleeve
38	505295613		Spring
39	505269179		Starter Pawl
40	503200021		Bolt
41	505297917		Lock Spring
42	731231001		Nut
43	505295110		Starter Spring
44	503211102		Screw
45	505262134		Attachment
46	505305120		Starter Rope
47	505307119		Starter Handle
48	503200007		Screw
49	503200008		Screw
50	503279002		Oil Cap
51	503443101		Gasket
52	505275715		Seal Ring
53	505325624		Flywheel
58	503230101		Washer
59	503222101		Flywheel Nut
60	506071403		Starter Pulley
62	503155001		Fan Housing
64	503203101		Screw
65	505220914		Bolt