

▲ WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

Ref #	Part Number	Qty	Description
1	530089204		Shoulder Strap
2	530089314		Washer
3	530089316		Nut
4	530089315		Screw
5	530089203		Band Support
6	530089326		Nut
7	530089201		Knapsack Pad
8	530089202		Knapsack Pad Fitting
9	530089317		Bolt
10	530089200		Knapsack Frame
11	530089318		Bolt
12	530089205		Tank Stay
13	530089206	PP440 Gas Blow Pipe	Absorber
14	530089228	BACKPACK & PIPES	Bend Pipe
15	530089227		Middle Pipe
16	530089330		Nut
17	530089329		Screw
18	530089226		Base Pipe
19	530089229		Hose Band
20	530089225		Flexible Pipe

PP440 Gas Blow Pipe
Absorber

BACKPACK & PIPES

Bend Pipe

Middle Pipe

Nut

Screw

Base Pipe

Hose Band

Flexible Pipe

Tank Stay

Absorber

Bend Pipe

Middle Pipe

Nut

Screw

Base Pipe

Hose Band

Flexible Pipe

Bolt

Knapsack Frame

Bolt

Knapsack Pad Fitting

Knapsack Pad

Nut


Band Support

Screw

Nut


Washer

Shoulder Strap




Ref #	Part Number	Qty	Description
1	530089268		Cap
2	530089269		Cap
3	530089270		Spring
4	530089271		Clip
5	530089272		Retainer
6	530089273		Jet Needle
7	530089274		Throttle Valve
8	530089275		Spring
9	530089344		Screw
10	530089276		Jet Needle
11	530089277		Spring
12	530089265		Arm Float
13	530089278	PP440 Gas Blow	Gasket
14	530089267	CARBURETOR	Cover
15	530089279		Diaphragm
16	530089343		Screw&Washer
17	530089342		Screw
18	530089266		Pin Float
19	530089264		Needle Valve
20	530089263		Gasket
21	530089262		Check Valve
22	530089261		Diaphragm
23	530089260		Pump Cover
24	530089341		Screw & Washer

PP440 Gas Blow Page 4 of 9
 CARBURETOR



Ref #	Part Number	Qty	Description
1	530089321		Nut
2	530089320		Screw
3	530089215		Isolating Rubber
4	530089322		Bolt
5	530089210		Fan Cover
6	530089208		Fan Case (R)
7	530089319		Bolt
8	530089209		Fan
9	530089207		Fan Case (F)
10	530089219		Stop Switch
11	530089325		Screw
12	530089230		Wire Band
13	530089211		Elbow Pipe
14	530089212		O Ring
15	530089214		Gasket
16	530089213		Cover
17	530089323		Screw
18	530089311		Tank Cap Ass'y.
19	530089312		Fuel Systems
20	530089306		Priming Pump
21	530089304		Clip
22	530089305		Fuel Tube
23	530089328		Screw
24	530089216		Lever Holding Ass'y.
25	530089218		Throttle Lever
26	530089223		Earth Wire
27	530089221		Earth Plate
28	530089327		Nut
29	530089220		Plate
30	530089217		Lever Compliance
31	530089280		Throttle Wire
32	530089222		Lead Wire
33	530089224		Tube
34	530089324		Nut
35	530089307		Suction Hose
36	530089308		Fuel Filter
37	530089309		Felt
38	530089310		Sponge

PP440 Gas Blow Page 6 of 9
FUEL SYSTEM



Ref #	Part Number	Qty	Description
1	530089287		Muffler Ass'y.
2	530089286		Muffler Gasket
3	530089246		Spark Plug
4	530089335		Bolt
5	530089237		Cylinder
6	530089259		Carburetor Gasket
7	530089258		Flange
8	530089257		Insulator Gasket
9	530089339		Screw & Washer
10	530089256		Insulator
11	530089340		Screw & Washer
12	530089253		Carburetor
13	530089285	PP440 Gas Blower POWER UNIT	Spring
14	530089281		Air Cleaner Ass'y.
15	530089348		Screw & Washer
16	530089333		Screw & Washer
17	530089288		Bracket
18	530089289		Muffler Cover
19	530089236		Cylinder Cover
20	530089351		Screw
21	530089352		Screw & Washer
22	530089238		Cylinder Gasket
23	530089239		Ring Top
24	530089240		Ring Top
25	530089242		Piston Ass'y.
26	530089241		Piston Pin Clip
27	530089244		Bearing Needle
28	530089354		Screw & Washer
29	530089293		Clamp
30	530089290		Bracket
31	530089294		Starter Recoil
32	530089357		Crankcase Ass'y.
33	530089231		Pin Dowel
34	530089235		Crankcase Gasket
35	530089232		Oil Seal
36	530089234		Ball Bearing
37	530089245		Crankshaft Ass'y.
38	530089247		Rotor
39	530089336		Nut
40	530089338		Bolt & Washer
41	530089331		Screw & Washer
42	530089249		Transister Unit
43	530089337		Screw & Washer
44	530089250		Lead Wire
45	530089243		Woodruff Key
46	530089254		Fuel Tube
47	530089334		Bolt
49	530089283		Spring
50	530089345		Screw & Washer
51	530089284		Element Cleaner
52	530089255		Carburetor Gasket
53	530089291		Bracket
54	530089233		Clamp
55	530089332		Screw & Washer
56	530089248		Ignition Coil
57	530089252		Grommet

Ref #	Part Number	Qty	Description
58	530089303		Starter Rope
59	530089302		Starter Knob
60	530089301		Spring
61	530089300		Reel
62	530089297		Friction Spring
63	530089296		Return Spring
64	530089299		Ratchet
65	530089298		Friction Plate
66	530089356		Screw
67	530089355		Nut
68	530089295		Starter Pulley

PP440 Gas Blower Page 9 of 9
POWER UNIT