



CARBURETOR ASS'Y. PART NO.503-281209

(WP-28P)



Ref #	Part Number	Qty	Description
1	503108701		Screw
2	505316702		Cover
3	505316715		Diaphragm
4	505316734		Metering Lever
5	505316717		Screw
6	505316731		Pin
7	503117001		Needle
8	505316723		Spring
9	503483101		Ring
10	502119801		Clip
11	506028301		Washer
12	503483801		Lever
13	503483401	PP505 Gas Saw Page 2 of 11	Spring Return
14	502103101	CARBURETOR WP-28P	Bushing
15	503117701		Spring
16	503117101		Ball
17	501666101		Filter
18	501468401		Spring
19	503404101		Washer
20	503404301		Screw
21	503482501		Cover-Pump
22	503117501		Screw
23	504210050		Spring
24	505316721		Spring
25	503483701		Needle-Low
26	503483601		Needle-High
27	503483301		Idle Screw
28	530035015		Screw
29	503482701		Valve
30	503482601		Shaft Ass'y.
31	503483501		Spring
32	503484001		Lever
33	505316707		Valve
34	503117201		Gasket-Pump
35	503192201		Screw
36	503482901		Lever
37	503482801		Choke Shaft
38	501467501		Gasket
39	503117301		Diaphragm-Pump
40	503088401		Gasket Kit (Inc. 3,4,7,8,17,34,38,39)


WEST COAST HANDLE AND SPURS #503-438102



Ref #	Part Number	Qty	Description
1	721430350		Pin
2	506093802		Actuator
3	503234502		Washer
4	503436101		Bushing
5	503200225		Screw
6	735311020		E-Clip
7	503200216		Screw
8	506093404		Brake Housing
9	720127050		Pin
10	503436701		Block
11	503436501		Spring
12	503436901		Actuator Arm
13	503435801	PP505 Gas Saw	Pin
14	503408101	HANDLE ASSEMBLY	Spring
15	720123500		Pin
16	506094502		Band
17	503272101		E-Clip
18	503656502		Washer
19	503432001		Clutch Bearing
20	501598002		Rim-3/8"x7T
20	505303661		Rim-3/8"x8T
21	503438401		Clutch Drum Ass'y. (Incl. 17-20)
22	503524601		Clutch Ass'y.
23	503471801		Clutch Spring
24	503202516		Screw
25	501288501		Seal Ring
26	503426701		Oil Pickup Tube
27	501544102		Oil Pickup
28	501615801		Spring
29	503421301		Adjusting Screw
30	503422401		Spring
31	503421401		Pin
32	503230054		Washer
33	503421202		Pump Piston
34	503210632		Screw
35	503428201		Spring
36	503200230		Screw
37	503226501		Nut
38	503425802		Handlebar
39	503425102		Brace
40	503210619		Screw
41	503723601		Worm Gear
42	503435702		Handlebar
43	504125014		Mount
44	503437401		Spacer
45	503200235		Screw
46	503764501		Bushing
47	503434201		Inner Spur
48	503200210		Screw
49	503421006		Oil Pump Ass'y (Incl. 25, 28-33, & 54)
50	503200212		Screw
51	503226501		Nut
52	503434301		Outer Spur
53	503438102		Wrap Around Handlebar Kit (Incl. 7, 36, 42-44, 47, 48, 50-52, 56 & 57,)

Ref #	Part Number	Qty	Description
54	503624901		Dust Shield
55	503230014		Washer
56	503200265		Screw
57	503132802		Spacer
0	503434402		Winter Kit Not Shown.
0	506094406		Chain Brake Ass'y. (Incl. 1, 2, 6, 8-16) Not Shown.
0	503427201		Air Box Post Repair Kit Not Shown.

PP505 Gas SawPage 5 of 11
HANDLE ASSEMBLY




WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

Ref #	Part Number	Qty	Description
1	503766902		Model 425
1	503766901		Model 505
2	501686801		Chain Catcher
3	503220001		Nut
4	506093101		Bar Clamp (Incl.20)
5	501517201		Chain Pad
6	501814801		Bar Plate-Inner
7	503200216		Screw
8	721613800		Vent Pin
9	503426601		Spur
10	501537101		Chain Adjuster
11	503713705		Muffler Ass'y. (Incl. 22-24)
12	725538855	PP505 Gas Saw Page 7 of 11	Screw
13	503200320	POWER UNIT	Screw
14	503200225		Screw
15	503587402		Bushing, Rubber
16	503424301		Fitting
17	501768322		Fuel Line
18	501270801		Crankcase Pin
19	501608201		Pop Rivet
20	506093301		Deflector
21	503203219		Screw
22	503200210		Screw
23	503435401		Exhaust Deflector
24	503435501		Spark Arrestor
25	503428702		Gasket
26	503715301		Decompression Valve (Model 505 only)
27	503200245		Screw
28	503200265		Screw
29	503200220		Screw
30	503437901		Heat Shield
31	501815701		Bar Stud
32	503437504		Model 425
32	503723402		Model 505
33	503428601		Gasket
34	503289015		Model 425 (1 ring)
34	503289031		Model 505 (2 rings)
35	503437702		Model 425
35	503723502		Model 505
36	503733901		Bearing
37	737431200		Keeper
38	503428501		Gasket
39	503420005		Crankcase Ass'y (Incl. 2, 8, 16, 50, & 55)
40	503578901		Oil Cap Retainer
41	501626801		"O" Ring
42	501626601		Oil Cap Ass'y. (Incl. 40-41)
43	505275719		Oil Seal
44	503202512		Screw
45	503553601		Super Clean Duct
46	503553701		Grommet
47	503433701		Mount Shock
48	501444502		Bar Plate-Outer
49	503212806		Screw
50	738220225		Crankshaft Bearing
51	735880600		Woodruff Key
52	503230035		Washer

Ref #	Part Number	Qty	Description
53	503554101		Rear Chain Catcher
54	503764501		Spacer
55	503252002		Bearing w/Seal
56	506088603		Crankshaft Ass'y (Incl. 36, 50, 51 & 55)

PP505 Gas SawPage 8 of 11
POWER UNIT



Ref #	Part Number	Qty	Description
1	503427001		Switch Ass'y.
2	501271302		Grommet
3	503202512		Screw
4	501485402		Plug Boot
5	503620203		Model 425
5	503620502		Model 505
6	503202520		Screw
7	501673501		Starter Dog Spring
8	503230042		Washer
9	501673201		Starter Dog
10	501819901		Screw
11	503212810		Screw
12	503511503	PP505 Gas Saw Page 10 of 14	Flywheel Assy (Incl. 7-10)
13	503281209	STARTER & SHROUD	Carburetor
14	503220001		Nut
15	503212716		Screw
16	503234302		Washer
17	503423001		Air Baffle
18	503432101		Starter Pulley
19	503431901		Starter Spring
20	503432301		Fan Housing (Incl. 11, 15-18, 22-25)
21	503203419		Screw
22	501630601		Eyelet
23	501201502		Rope
24	504654203		Handle
25	503142902		Washer
26	725536855		Screw
27	503514802		Spring Isolator
28	503514801		Spring Isolator
29	503235109		Spark Plug
30	503578901		Oil Cap Retainer
31	503226501		Nut
32	503431401		Inner Ring
33	503430315		Tank & Handle Ass'y. (Includ. 31, 41, & 42)
34	501278201		O Ring
35	501431401		Fuel Cap
36	503427502		Insert
37	504357201		Filter
38	501768304		Hose
39	503432402		Choke Knob
40	501527801		Grommet
41	503443201		Fuel Filter
42	501768313		Fuel Line
43	503434001		Carburetor Gasket
44	503431801		Outer Sealing Ring
45	503431501		Manifold Tube
46	503560003		Clamp
47	503436001		Grommet
48	503434801		Throttle Wire
49	503428001		Spring
50	503424901		Spring
51	503424402		Trigger Lock
52	720123820		Pin
53	503424502		Trigger
54	720123620		Pin
55	503203242		Screw

Ref #	Part Number	Qty	Description
56	503203216		Screw
57	503433113		Air Filter Cover
58	503553901		Std. Nylon Mesh
58	503553902		Felt
59	503202355		Screw
60	503553801		Air Filter Base Plate
61	503164001		Vent Valve
62	501768307		Line

PP505 Gas Saw Page 11 of 11
STARTER & SHROUD