


Ref #	Part Number	Qty	Description
1	530015635		Screw
2	530094212		Handle Cover
3	530010827		Handle Ass'y.
4	530027157		Static Ground Wire
5	530026994		Handle Isolator
6	530015343		Isolator Spacer (Front)
7	530026163		Isolator Cup
8	530015629		Washer
9	530015628		Screw
10	530015561		Screw
11	530015342		Isolator Spacer (Rear)
12	530032091		Ball Bearing (Shroud) When removing or installing the bearing (f530-032091), the area of the shroud (f530-010824) receiving the bearing must be heated to approximately 300 degrees Farenheit to avoid damaging the shroud.
13	530015700		Screw
14	530024371		Air Filter
15	530015687		Screw
16	530015123		Washer
17	530010860		Fan Housing
18	530042023		Starter Pulley Spring
19	530026780		Air Baffle
21	530015479		Screw
22	530015123		Washer
23	530015544		Screw
24	530069232		Rope Kit
25	530026735		Starter Rope Handle
26	530027175		Ground Wire
27	530069252		"T" Handle Kit
28	530094222		Blower Tube Clamp
29	530015197		Nut
30	530015636		Screw
31	530026776		Heat Deflector
32	530010824		Shroud (Incl. #12 & 45) When removing or installing the bearing (f530-032091), the area of the shroud (f530-010824) receiving the bearing must be heated to approximately 300 degrees Farenheit to avoid damaging the shroud.
33	530069269		Blower Hsg. Ass'y. (Incl. #36,46-49 & 55, and #5 of Vacuum Attac. Kit)
34	530094215		Impeller
35	530015661		Screw
36	530015495		Screw
37	530001543		Nut
38	530015367		Screw
39	530015644		Nut
40	530015441		Washer
41	530347987		Washer
42	530015632		Screw
43	530015682		Washer
44	530015168		Screw
45	530001516		Shroud Bearing Retainer
46	530015667		Spring-Tension (Right)
47	530015647		Pivot Pin
48	530015672		Spring-Tension (Left)

1920 Gas Blower Page 2 of 14
 BLOWER ASSEMBLY
 receiving the bearing must be heated to approximately 300 degrees Farenheit to avoid damaging the shroud.


Ref #	Part Number	Qty	Description
49	530094241		Inlet Door Ass'y.
50	530015638		Screw
51	530015637		Fuel Tank Retainer
52	530026781		Fuel Tank Cushion
53	530010897		Fuel Pick-Up Ass'y
54	530069247		Line Kit
55	530015382		Washer
56	530010729		Fuel Cap Ass'y. (Incl. O-Ring)
57	530010815		Fuel Tank Ass'y. (Incl. #53,54 & 56)
59	530015683		Screw
60	530027350		Fuel Tank Shield
61	530069235		Eylet Kit
62	530015823	1920 Gas Blower Page 3 of 14	Screw (Incl. in Starter Pulley Kit)
A	530026938	BLOWER ASSEMBLY	Instruction Decal
B	530026925		Blower/Vac Warning Decal



1

Ref #	Part Number	Qty	Description
1	530069271		Blower Tube Kit
0	530067302		Operator's Manual, Model 1920 Not Shown.
0	530067303		Operator's Manual, Model 1925 Not Shown.
0	530067301		Operator's Manual, Model 1960 Not Shown.

1920 Gas Blower Page 5 of 14
BLOWER TUBE KIT



Carb
Repair
Kit




28

Carb
Gasket
Kit

29


Ref #	Part Number	Qty	Description
1	530035197		Valve Throttle
2	530035015		Screw-Throttle Valve
3	530035132		Shaft Ass'y.-Throttle
4	530035156		Idle Speed Screw
5	530035138		Spring-Throttle Return
7	530035200		Spring-High Speed Mixture Needle
8	530035198		Needle-High Speed Mixture
9	530035162		Plug-5/16 Dia. Welch
11	530035017		Screw-Pump Cover
12	530035191		Cover-Fuel Pump
13	530035164		Gasket-Fuel Pump
14	530035166		Diaphragm-Fuel Pump
15	530035178		Screen-Fuel Inlet
18	530035007		Ring-Throttle Retainer
19	530035106		Valve-Inlet Needle
20	530035139		Spring-Metering Lever
21	530035031		Lever-Metering
22	530035028		Pin-Metering Lever
23	530035016		Screw-Metering Lever Pin
24	530035151		Gasket-Metering Diaphragm
25	530035014		Diaphragm-Metering
26	530035003		Cover-Metering Diaphragm
27	530035021		Screw Ass'y.-Metering Cover
28	530035199		Kit-Carb. Kwik Repair (Inc. 13,14,24,25)
29	530035186		Kit-Carb. Gasket/Diaphragm (Inc. 9,13,14, 19,20,21,22,23,24,25)

1920 Gas Blower Page 7 of 14
 CARBURETOR



Ref #	Part Number	Qty	Description
1	530094426		Nozzle
2	530094518		Elbow
3	530094425		Extension Tube
4	530094424		Pivot Tube
5	952062003		Goggles
A	530027215		Warning Decal

1920 Gas Blower Page 9 of 14
GUTTER ATTACHMENT KIT





Ref #	Part Number	Qty	Description
1	530012244		Models 1920 & 1925
1	530012252		Model 1960
2	530019111		Cylinder Gasket
3	530026413		Models 1920, 1925
3	530026681		Model 1960
4	530015162		Wrist Pin Retainer
5	530015239		Screw
7	530069245		Muffler Ass'y.
9	530024903		Muffler Attachment Spring
10	530010753		Models 1920, 1925
10	530069203		Model 1960
11	530069242		Shaft Kit
12	530012145		Shaft Coupling
13	530094243		Plastic Coupling
14	530626605		Flywheel Nut
15	530023817		Starter Dog Spring
16	530015004		Screw
17	530032092		Piston Pin Bearing Model 1960 Only
18	530027273		Models 1920, 1925
18	530010853		Model 1960
19	530032092		Piston Pin Bearing Model 1960
20	530015351		Washer
21	530032029		Crankshaft Bearing
22	530010757		Crankcase Ass'y. (Incl. #21,23 & 28)
23	530019059		Crankcase Seal
24	530015763		Washer
26	530001717		Coupling Washer
27	530015126		Flywheel Key
28	530015168		Screw
29	530039111		Flywheel Ass'y.
30	530015127		Flywheel Washer
31	530024438		Reed Valve
32	530019108		Carburetor Case to Crankcase Gasket
33	530019105		Carburetor Case Seal
34	530015241		Screw
35	530023367		Washer
36	530026818		Carburetor Case
37	530019157		Carburetor Gasket
38	530026981		Fuel Line Fitting
39	530010875		Fuel Line & Fitting Ass'y.
40	530026797		Choke Guide Plate
41	530026772		Choke Shutter
42	530015674		Screw
43	530035196		Carburetor
44	530015254		Wave Washer
45	530015673		Spacer
46	530015630		Screw
47	530015654		Retaining Ring
48	530015147		Wave Washer
49	530015407		Screw
50	530026773		Choke Actuator
52	530026764		Carb. Case Cover
53	530023807		Choke Knob
54	530015675		Screw
55	530015660		Screw
56	530015123		Washer

1920 Gas Blow Pipe 11 of 14
POWER UNIT

Ref #	Part Number	Qty	Description
57	530015614		Throttle Knob
58	530023575		Grounding Switch Nut
59	530024569		Washer
60	530069204		Toggle Switch Kit (Incl. #58 & 59)
61	530026771		Throttle Wire Ass'y.
62	530026951		Ignition Wire
63	530026829		Ground Wire
64	530024435		Plug Wire Grommet
65	530015128		Screw
66	530039124		Ignition Module
67	530030005		Spark Plug (CJ-8)
68	530003933		Spark Plug Lead Connector
69	530003934		Spark Plug Boot
70	530039082		High Tension Lead Wire
71	530039103		High Tension Lead Ass'y. (Incl. #68,69 & 70)
72	530030054		Crankcase Sealant (Not Supplied With Unit)
73	530069219		Engine Gasket Kit (Inc. 23,32,33,37)

1920 Gas Blow Page 12 of 14
POWER UNIT



Ref #	Part Number	Qty	Description
1	530094654		Elbow
2	530069272		Vacuum Bag Kit (Incl. #1)
3	530010850		Rear Handle Ass'y.
4	530094660		Spacer
5	530069270		Vacuum Tube Kit (Incl. #4)

1920 Gas Blower Page 14 of 14
VAC ATTACHMENT KIT