


ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY OEM.

VIEW 1 OF 2











Ref #	Part Number	Qty	Description
1	36562	1	Cylinder (Incl. 2, 20, 72 & 125)
2	26727	2	Dowel Pin
14	28277	1	Washer
15	31334	1	Governor Rod
16	37729	1	Governor Lever
17	31335	1	Governor Lever Clamp
18	651018	1	Screw, T-15, 8-32 x 19/64"
19D	33857	2	Extension Spring Ass'y. (Incl. 213)
19	31426	1	Extension Spring
20	32600	1	Oil Seal
25A	35883	1	Baffle Extension
25	36552	1	Blower Housing Baffle (Incl. 262)
26	650802	2	Screw, 1/4-20 x 5/8"
26A	650926	1	Screw, 8-32 x 21/64"
30	37835	1	Crankshaft
40	40020	1	Piston, Pin & Ring Set (Std.)
40	40021	1	Piston, Pin & Ring Set (.010" OS)
41	40018	1	Piston & Pin Ass'y. (Std.) (Incl. 43)
41	40019	1	Piston & Pin Ass'y. (.010" OS) (Incl. 43)
42	40022	1	Ring Set (Std.)
42	40023	1	Ring Set (.010" OS)
43	20381	2	Piston Pin Retaining Ring
45	30963B	1	Connecting Rod Ass'y. (Incl. 46 & 49)
46	32610A	2	Connecting Rod Bolt
48	27241	2	Valve Lifter
49	28594	1	Oil Dipper
50	32197A	1	Camshaft (MCR)
60	29745	1	Blower Housing Extension
62	650760	1	Screw, 8-32 x 3/8"
63	28545	1	Grommet
65	650128	1	Screw, 10-24 x 1/2"
69	27677A	1	* Cylinder Cover Gasket
70	35863A	1	Cylinder Cover (Incl. 75 thru 83,311)
72	27642	2	Oil Drain Plug
75	26208	1	Oil Seal
80	30574A	1	Governor Shaft
81	30590A	1	Washer
82	30591	1	Governor Gear Assembly (Incl. 81)
83	30588A	1	Governor Spool
86	650488	7	Screw, 1/4-20 x 1-1/4"
89	610961	1	Flywheel Key
90	611195	1	Flywheel
92	650815	1	Belleville Washer
93	650816	1	Flywheel Nut
100	34443C	1	Solid State Ignition
101	610118	1	Spark Plug Cover
102	651024	2	Solid State Mounting Stud
103	651007	2	Screw, T-15, 10-24 x 15/16"
103A	650767	1	Screw, 8-32 x 27/64"
110B	37602	1	Ground Wire
110A	37601	1	Ground Wire
111B	611224	1	Rocker On/Off Switch
118	35515	1	Guard Rope
119	36437	1	* Cylinder Head Gasket
120	36438	1	Cylinder Head (Incl. 130)
125	36471	1	Exhaust Valve (Std.) (Incl. 151)
125	36472	1	Exhaust Valve (1/32" OS) (Incl. 151)
126	29314C	1	Intake Valve (Std.) (Incl. 151)

Ref #	Part Number	Qty	Description
	127 650691	1	Washer
	130B 650818	1	Screw, 5/16-18 x 1-15/32"
	130A 6021A	2	Screw, 5/16-18 x 1-1/2"
	130 650694A	5	Screw, 5/16-18 x 2"
	135 33636	1	Spark Plug (RJ17LM)
	150 31672	2	Valve Spring
	151A 40016A	1	Intake Valve Seal
	151 31673	2	Valve Spring Cap
	169 27234A	2	* Valve Cover Gasket
	170 27666	1	Breather Body
	171 31410	1	Breather Element
	172 34146	1	Valve Cover
	173 32447	1	Breather Tube
	173A 32446	2	Breather Tube Grommet
	174 650783	2	Screw, 10-24 x 3/4"
	178 29752	2	Nut & Lock Washer, 1/4-28
	182 6201	2	Screw, 1/4-28 x 7/8"
	184 26756	1	* Carburetor To Intake Pipe Gasket
	185 28416A	1	Intake Pipe
	186 37728	1	Governor Link
	200 36677	1	Control Bracket (Incl. 203-209A,212-2 17)
	203 31342	1	Compression Spring
	204 651029	1	Screw, T-10, 5-40 x 7/16"
	206 610973	1	Terminal
	209 650139	1	Screw, 8-32 x 3/4"
	209A 30322	1	Lock Nut, 8-32
	210 27793	1	Conduit Clip
	211 28942	1	Screw, 10-32 x 3/8"
	213 28942	1	Screw, 10-32 x 3/8"
	223A 650840	1	Screw, 1/4-20 x 1-7/32"
	223 650664	1	Screw, 1/4-20 x 1-19/32"
	224 26754A	1	* Intake Pipe Gasket
	238 650152	2	Screw, 8-32 x 3/8"
	239 27272A	1	* Air Cleaner Gasket
	242 31691	1	Air Cleaner Base
	243 28820	2	Screw, 10-32 x 1/2"
	245 30727	1	Air Cleaner Filter
	250 31715	1	Air Cleaner Cover
	260 35657A	1	Blower Housing
	262 650737	2	Screw, 1/4-20 x 1/2"
	267 34212	1	Hold Down Bracket
	268 30200	1	Screw, 10-24 x 9/16"
	275 40001A	1	Muffler
	277 650988	2	Screw, 1/4-20 x 2-5/16"
	279B 650488	1	Screw, 1/4-20 x 1-1/4"
	279 651028	1	Screw, 10-24 x 1/2"
	279A 30063	1	Screw, 1/4-20 x 1/2"
	280 37633	1	Heat Shield
	285 36467B	1	Starter Cup
	287 650926	2	Screw, 8-32 x 21/64"
	290 30962	1	Fuel Line
	292 26460	2	Fuel Line Clamp
	298 650665	2	Screw, 1/4-15 x 7/8"
	300 35591	1	Fuel Tank (Incl. 292 & 301)
	301 37485	1	Fuel Cap
	311 27625	2	Oil Fill Plug
	312 29673	2	* Oil Fill Plug Gasket
	313 34080	1	Spacer

Ref #	Part Number	Qty	Description
325A	27275	1	Wire Clip
340	35230	1	Fuel Tank Bracket
342	650751	1	Screw, 1/4-20 x 7/16"
370K	36695	1	Starter Decal
370A	36261	1	Instruction Decal
380	640134	1	Carburetor (Incl. 184)
390	590732A	1	Rewind Starter
400	36439	1	* Gasket Set (Incl. items marked PK i n notes)
420	730225A	1	SAE 30 4-Cycle Engine Oil (Quart)

ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY OEM.

VIEW 2 OF 2



OPTIONAL 110 - 120 VOLT
STARTER MOTOR KIT



396

Ref #	Part Number	Qty	Description
	16 37729	1	Governor Lever
	17 31335	1	Governor Lever Clamp
	18 651018	1	Screw, T-15, 8-32 x 19/64"
	28 30322	1	Nut & Lock Washer, 8-32
	35 29826	1	Screw, 10-32 x 3/4"
	36 29918	1	Lock Washer
	37 29216	1	Nut & Lock Washer, 10-32
103A	650767	1	Screw, 8-32 x 27/64"
110B	37602	1	Ground Wire
110A	37601	1	Ground Wire
111B	611224	1	Rocker On/Off Switch
151A	40016A	1	Intake Valve Seal
	178 29752	2	Nut & Lock Washer, 1/4-28
	200 36677	1	Control Bracket (Incl. 203-209A,212-2 17)
	203 31342	1	Compression Spring
	204 651029	1	Screw, T-10, 5-40 x 7/16"
	206 610973	1	Terminal
209A	30322	1	Lock Nut, 8-32
	209 650139	1	Screw, 8-32 x 3/4"
	238 650152	2	Screw, 8-32 x 3/8"
	242 31691	1	Air Cleaner Base
245A	35974	1	Air Cleaner Filter
	245 30727	1	Air Cleaner Filter
	250 31715	1	Air Cleaner Cover
	275 40001A	1	Muffler
	277 650988	2	Screw, 1/4-20 x 2-5/16"
	279 651028	1	Screw, 10-24 x 1/2"
279A	30063	1	Screw, 1/4-20 x 1/2"
279B	650488	1	Screw, 1/4-20 x 1-1/4"
	280 37633	1	Heat Shield
325A	27275	1	Wire Clip
370A	36261	1	Instruction Decal
	380 640134	1	Carburetor (Incl. 184)
	416 36085	1	Spark Arrestor Kit (Incl. 417)
	417 650760	1	Screw, 8-32 x 3/8"