










Ref #	Part Number	Qty	Description
	1 34919B	1	Cylinder (Incl. 2, 20 & 72)
	2 27652	2	Dowel Pin
	15A 30700	1	Governor Yoke
	15B 650494	1	Screw, 6-40 x 5/16"
	15 30699C	1	Governor Rod (Incl. 15A & 15B)
	16 33454	1	Governor Lever
	17 29916	1	Governor Lever Clamp
	18 650548	1	Screw, 8-32 x 5/16"
	19 34663	1	Speed Control Spring
	20 32630	1	Oil Seal
	25 29536	1	Blower Housing Baffle
	26 650561	2	Screw, 1/4-20 x 5/8"
	28 30322	1	Lock Nut, 8-32
	30 36282	1	Crankshaft
	35 29826	1	Screw, 10-32 x 3/4"
	36 29918	1	Lock Washer
	37 29216	1	Lock Nut, 10-32
	38 29642	1	Retaining Ring
	40 34531	1	Piston, Pin & Ring Set (Std.)
	40 34532	1	Piston, Pin & Ring Set (.010" OS)
	40 34533	1	Piston, Pin & Ring Set (.020" OS)
	41 33312B	1	Piston & Pin Ass'y. (Std.) (Incl. 43)
	41 33313B	1	Piston & Pin Ass'y. (.010" OS) (Incl. 43)
	41 33314B	1	Piston & Pin Ass'y. (.020" OS) (Incl. 43)
	42 34854	1	Ring Set (Std.)
	42 34855	1	Ring Set (.010" OS)
	42 34856	1	Ring Set (.020" OS)
	43 27888	2	Piston Pin Retaining Ring
	45 31380C	1	Connecting Rod Ass'y. (Incl. 46)
	46 650662C	2	Connecting Rod Bolt
	48 34034	2	Valve Lifter
	50 33156	1	Camshaft (BCR)
	60 30622A	1	Blower Housing Extension
	65 650128	1	Screw, 10-24 x 1/2"
	69 30684	1	* Cylinder Cover Gasket
	70 31303C	1	Cylinder Cover (Incl. 71, 75 & 80)
	71 31546	1	Crankshaft Bushing
	72 27642	2	Oil Drain Plug
	75 28427	1	Oil Seal
	80 31845	1	Governor Shaft
	81 30590A	1	Washer
	82 30591	1	Governor Gear Ass'y. (Incl. 81)
	83 30588A	1	Governor Spool
	84 29193	1	Retaining Ring
	86 650488	7	Screw, 1/4-20 x 1-1/4"
	87 650493	1	Screw, 1/4-20 x 1-3/4"
	89 32589	1	Flywheel Key
	90 611084	1	Flywheel
	92A 650815	1	Belleville Washer
	92 650815	1	Belleville Washer
	93 8116	1	Flywheel Nut
	100 34443A	1	Solid State Ignition
	101 610118	1	Spark Plug Cover
	102 650872	2	Solid State Mounting Stud
	103 650814	2	Screw, Torx T-15, 10-24 x 1"
	110 30831	1	Ground Wire
	110A 35187	1	Ground Wire
	119 28938C	1	* Cylinder Head Gasket

Ref #	Part Number	Qty	Description
	120 30938A	1	Cylinder Head (Incl. 3 of 130)
	125 27878A	1	Exhaust Valve (Std.) (Incl. 151)
	125 27880A	1	Exhaust Valve (1/32" OS)(Incl. 151)
	126 32783	1	Intake Valve (Std.) (Incl. 151)
	126 32784	1	Intake Valve (1/32" OS)(Incl. 151)
	127 650691	6	Washer
	128 650690	5	Belleville Washer
	129 650905	4	Screw, 5/16-18 x 2-5/8"
	130 650697A	4	Screw, 5/16-18 x 2-1/2"
131A	29212	2	Screw, 1/4-28 x 7/16"
	135 33636	1	Resistor Spark Plug (RJ17LM)
	139 31843A	1	Governor Gear Bracket
	140 650965	2	Screw, Torx T-25, 10-24 x 1/2"
	149 27882	2	Valve Spring Cap
	150 27881	2	Valve Spring
	151 32581	2	Valve Spring Keeper
	169 27896A	2	* Valve Cover Gasket
	170 28423	1	Breather Body
	171 28424	1	Breather Element
	172 28425	1	Valve Cover
	173 35350	1	Breather Tube
	174 650128	2	Screw, 10-24 x 1/2"
	182 650517	2	Screw, 1/4-20 x 27/32"
	184 31688A	1	* Carburetor To Intake Pipe Gasket
	186 34661	1	Governor Link
	200 34664	1	Control Bracket (Incl.19,203,204,206)
	203 31342	1	Compression Spring
	204 650549	1	Screw, 5-40 x 7/16"
	206 610973	1	Terminal
	207 34662	1	Throttle Link
	209 650821	2	Screw, 10-32 x 1/2"
	210 27793	1	Conduit Clip
	211 28942	1	Screw, 10-32 x 3/8"
	215 30985	1	Throttle Control
	224 27915A	1	* Intake Pipe Gasket
	238 28820	2	Screw, 10-32 x 1/2"
	239 27272A	1	* Air Cleaner Gasket
	242 31914	1	Air Cleaner Bracket
	243 650152	2	Screw, 8-32 x 3/8"
	245 30727	1	Air Cleaner Filter
	250 31715	1	Air Cleaner Cover
	260 35887	1	Blower Housing
	262 29747B	2	Screw, Torx T-40, 5/16-24 x 21/32"
	265 30939A	1	Cylinder Head Cover
	269 35865	1	* Exhaust Manifold Gasket
	272 30196	2	Screw, 5/16-18 x 3/4"
	273 34712	1	Carburetor Flange
	275 36220	1	Muffler
277A	30196	2	Screw, 5/16-18 x 3/4"
	285 36221	1	Starter Cup
287A	650926	4	Screw, 8-32 x 21/64"
	287 650926	1	Screw, 8-32 x 21/64"
	291 30962	1	Fuel Line
	292 26460	2	Fuel Line Clamp
	298 650665	2	Screw, 1/4-15 x 3/4"
	299 650764	1	"U" Type Nut
	300 34186A	1	Fuel Tank (Incl. 292 & 301)
	301 35355	1	Fuel Cap



Ref #	Part Number	Qty	Description
305	35574	1	Oil Fill Tube
307	35499	1	"O" Ring
308	33997	1	Fill Tube Clip
309	650760	1	Screw, 8-32 x 3/8"
310	36223	1	Dipstick
324	33177	1	Terminal
325A	34246	1	Wire Clip
325	29443	1	Wire Clip
340	36209	1	Fuel Tank Bracket
342	30063	1	Screw, Torx T-30, 1/4-20 x 1/2"
370B	35274	1	Instruction Decal
370A	550223	1	Name Decal
370C	36224	1	Debris Guard Decal
370	36261	1	Instruction Decal
380	632631	1	Carburetor (Incl. 184)
390	590666A	1	Rewind Starter
398	36222	1	Blower Housing Recoil Extension
400	33235A	1	* Gasket Set (Incl. items marked PK i n notes) Incl. part #'s 27272A (2), 27896A (2), 27913A (1), 27915A (2), 28938C (1), 29673 (1), 30684 (1), 31688A (1), 33355A (1), 35865 (1)
420	730225	1	SAE 30 4-Cycle Engine Oil (Quart)
453	29538	1	Engine Mounting Base
454	650542	4	Screw, 5/16-18 x 3/4"




**OPTIONAL 110-120  
VOLT STARTER  
MOTOR KIT**



Ref #	Part Number	Qty	Description
62	650760	1	Screw, 8-32 x 3/8"
63	28545	1	Grommet
92A	650815	1	Belleville Washer
110A	35187	1	Ground Wire
129	650905	4	Screw, 5/16-18 x 2-5/8"
131A	29212	2	Screw, 1/4-28 x 7/16"
172	28425	1	Valve Cover
262	29747B	2	Screw, Torx T-40, 5/16-24 x 21/32"
269	35865	1	* Exhaust Manifold Gasket
277A	30196	2	Screw, 5/16-18 x 3/4"
287A	650926	4	Screw, 8-32 x 21/64"
309	650760	1	Screw, 8-32 x 3/8"
370C	36224	1	Debris Guard Decal



**730571**  
Can be used on H50-60 with  
stamped steel starter.



Ref #	Part Number	Qty	Description
90	611084	1	Flywheel
92A	650815	1	Belleville Washer
110A	35187	1	Ground Wire
129	650905	4	Screw, 5/16-18 x 2-5/8"
131A	29212	2	Screw, 1/4-28 x 7/16"
239	27272A	1	* Air Cleaner Gasket
242	31914	1	Air Cleaner Bracket
245	30727	1	Air Cleaner Filter
245A	35974	1	Air Cleaner Filter
250	31715	1	Air Cleaner Cover
287A	650926	4	Screw, 8-32 x 21/64"
309	650760	1	Screw, 8-32 x 3/8"
370C	36224	1	Debris Guard Decal