ILLUSTRATION SHOWS TYPICAL PARTS ONLY, ORDER BY PART NUMBER, PARTS NOT LISTED ARE SUPPLIED BY DEAL




Ref #	Part Number C	ty Description
	33042	Cylinder (Incl. 2, 4, 30 & 47) (3-1/2 " Bore)
	27652	Pin, Dowel
	31950	Seal, Oil
	31940	Intake Valve (Std.)
	31941	` ,
		Intake Valve (1/32" OS) (Incl. 9)
	31942	Exhaust Valve (Std.)
	31943	Exhaust Valve (1/32" OS) (Incl. 9)
	650592	Key, Flywheel
	31944	Spring, Valve
	31946	Cap, Lower valve spring (1/32" OS)
	31945	Cap, Lower valve spring (Std.)
	31945	Cap, Lower valve spring (Std.)
	31946	Cap, Lower valve spring (1/32" OS)
	20810	Pin, Valve spring retainer
	33390B	Crankshaft (Incl. 12, 13, 78 & 79)
	29783	Pin, Crankshaft gear
	31931	Gear, Crankshaft
	34511	Piston, Pin & Ring Set (Std.) (3-1/2" Bore)
	34512	Piston, Pin & Ring Set (.010" OS)
	34513	Piston, Pin & Ring Set (.020" OS)
	34524	Piston, Pin & Ring Set (.030" OS)
	34525	Piston, Pin & Ring Set (.040" OS)
	32238B	Piston & Pin Ass'y. (Std.)(Incl.16)(3 -1/2")
	32239B	Piston & Pin Ass'y. (.010" OS) (Incl. 16)
	32240B	Piston & Pin Ass'y. (.020" OS) (Incl. 16)
	32621B	Piston & Pin Ass'y. (.030" OS) (Incl. 16)
	32622B	Piston & Pin Ass'y. (.040" OS) (Incl. 16)
	32241	Ring Set (Std.) (3-1/2" Bore)
	32242	Ring Set (.010" OS)
	32243	Ring Set (.020" OS)
15	32625	Ring Set (.030" OS)
15	32626	Ring Set (.040" OS)
15	32336	Re-Ringing Set, Piston
16	31919	Ring, Piston pin retaining
17	33093A	Connecting Rod Ass'y.(Std.)(Incl.18, 19 & 20)
17	34383	Connecting Rod Assy.(.010" US)(Incl.1 8,19,20)
17	34384	Connecting Rod Assy.(.020" US)(Incl.1 8,19,20)
18	32077	Bolt, Connecting rod
19	26073	Washer, Connecting rod
20	28264	Nut Assy., Lock
21	32150	Camshaft (MCR)
22	31939	Lifter, Valve
23A	31956A	* Gasket, Cylinder cover
23	32580A	Cover, Cylinder (Incl. 4, 28, 30, 34, & 43)
24	33893A	Oil Fill Tube
25A	33590	"O" Ring
26	33984A	Dipstick (Incl. 25A)
28	32426	Spacer, Governor rod
	650588	Screw, 1/4-20 x 2"
31	31968	Link, Governor
	650451	Screw, 1/4-20 x 1"
33	31964	Clamp, Governor lever
	29193	Ring, Retaining
	31963	Lever, Governor adjusting
	650518	Lockwasher
	650544	Screw, 10-24 x 7/8"
	7975	Nut, 10-24
	31965	Plate, Governor spring
		, , , , , , , , , , , , , , , , , , , ,


Ref #	Part Number	Qty	Description
	30312	Gty	Screw, 10-32 x 1/2"
	31967		
			Spring, Governor
	30590A		Washer, Flat
	32425		Rod Assy., Governor
	31948		Spool, Governor
45	29193		Ring, Retaining
46	31947		Gear Assy., Governor
47	31930		Shaft, Mechanical Governor
48	32246A		* Gasket, Cylinder head
	33034		Head, Cylinder
	650694A		Screw, 5/16-18 x 2" (Use as required)
	650711		Screw, 5/16-18 x 1-5/8" (Use as required)
	650628A		Screw, 5/16-18 x 2-3/8" (Use as requi red)
	650695A		Screw, 5/16-18 x 2-1/4" (Use as requi red)
	650714		Screw, 5/16-18 x 1-5/8" (Use as requi red)
	650697A		Screw, 5/16-18 x 2-1/2" (Use as requi red)
51	650692		Screw, 5/16-18 x 1-3/4" (Use as requi red)
51	650603		Screw, 5/16-18 x 5/8" (Use as require d)
53	33636		Resistor Spark Plug (RJ-8C)
	34251		Resistor Spark Plug (RJ-17LM)
	33035		Cover, Cylinder head
	28537		Washer, Plain
	650691		Washer, Flat (Use as required)
	650690		Washer, Belleville (Use as required)
	8274		Washer, Lock (Use as required)
	650128		Screw, 10-24 x 1/2"
	31976		Extension, Blower housing
	410144B		Fuel Cap (White Plastic)(Std.)(As req uired)
63	34210		Fuel Cap (Red Plastic) (Spurt resistant, High profile) (Use as
			required)
67	050547		Coron 1/1 20 x 27/22 (Hee on required)
	650517		Screw, 1/4-20 x 27/32" (Use as required)
	650561		Screw, 1/4-20 x 5/8" (Use as required)
	30063		Screw, 1/4-20 x 1/2" (Use as required)
	792028		Screw, 5/16-18 x 7/8" (Use as require d)
71	26460		Clamp, Fuel line (Use as required)
72	29774		Fuel Line (Braided) (8.25") (Use as r equired)
72	30705		Fuel Line (Braided) (16") (Use as req uired)
	30962		Fuel Line (Braided) (32") (Use as req uired)
	30965		Fuel Line (Braided) (48") (Use as req uired)
	31400		Fuel Line (3-1/2" Metal)
	32579		Baffle, Blower housing
	650561		Screw, 1/4-20 x 5/8"
	31932		Bearing, Tapered roller
	31928		Cup, Bearing
80	32031		Spacer, Steel (.010" thick) NOTE: Determine the gap
			between the cover and the machined surface on the cylinder
			which can be from .001"up to .007" in which case no shim
			gaskets will be required. Use of gasket must be limited to a
			combined total of .010" thick. Steel spacersmust be used
			as required
			·
81	31971		* Gasket, Shim (.004/.005 thick) NOTE: Determine the gap
			between the cover and the machined surface on the cylinder
			which can be from .001"up to .007" in which case no shim
			gaskets will be required. Use of gasket must be limited to a
			combined total of .010" thick. Steel spacersmust be used
			as req

Ref #	Part Number Qt	y Description
82	31972	* Gasket, Shim (.005/.007 thick) NOTE: Determine the gap between the cover and the machined surface on the cylinder which can be from .001"up to .007" in which case no shim gaskets will be required. Use of gasket must be limited to a combined total of .010" thick. Steel spacersmust be used as req
	32599 32577	"O" Ring Cover, Cylinder NOTE: Determine the gap between the cover and the machined surface on the cylinder which can be from .001"up to .007" in which case no shim gaskets will be required. Use of gasket must be limited to a combined total of .010" thick. Steel spacersmust be used as required to eliminat
84A	650679	Lockwasher, 5/16" (Use as required)
	792028	Screw, 5/16-18 x 7/8"
	650666	Washer, Lock
	650594	Nut, Flywheel, 3/4-16
	33044A	Blower Hsg. (Incl.73) (For electric s tarter)
	8274 650595	Washer, Lock
	8274	Screw, 5/16-24 x 3/8" Washer, Lock
	650624	Screw, 5/16-24 x 9/16"
	31958	* Gasket, Breather
99	31957	Breather Assy.
	35350	Tube, Breather
	650128	Screw, 10-24 x 1/2"
	28558	Washer, Wave
	31966 31984A	Bushing, Control lever Lever, Control
	650597	Screw, 10-24 x 5/8"
	650591	Screw, 10-24 x 2"
	33099	Spring
	33038	Plug, Button (Use as required)
	27272	* Gasket, Air cleaner
	650399 30767	Screw, 10-32 x 5/8" Spacer, Air cleaner
	650513	Nut, Wing
	650713	Screw, 5/16-18 x 5/8" (Use as require d)
	650429	Screw, 5/16-18 x 3/4" (Use as require d)
	792028	Screw, 5/16-18 x 7/8" (Use as require d)
	8274	Lockwasher, Split (Use as required)
	26073 33263	Washer, Flat (Use as required) * Gasket, Carburetor
	650451	Screw, 1/4-20 x 1"
	34061	Baffle, Air
	610908	Terminal, Female
	730201	Trigger Pin Kit (Use as required)
	610118	Cover, Spark plug (Use as required)
	32426	Spacer, Screen
	650675 8345	Washer, Flat 1/4" Washer, 1/4 plain (Use as required)
	27070	Washer, Lock 1/4 E.T. (Use as required)
	650675	Washer, Flat 1/4 (Use as required)
	27793	Clip, Conduit
	28942	Screw, 10-32 x 3/8"
219	32154	Cap, Pipe
220	32438	Nipple, Pipe

Ref#	Part Number	Qty	Description
246	33776		Screen, Starter pulley
248	650670		Screw, 1/4-20 x 3/4"
249	32046		Rope Assy., Starter (Use as required)
264	650661		Screw, 1/4-20 x 3/4"
265	610408		Nut, Hex
266	610750		Grommet, Lead wire
267	610906		Solid State Magneto (Incl.151,173,265,266)(20 Amp)
278	610901		Solid State Flywheel
299B	32730		Decal, Craftsman
299	34346		Decal, Instruction
300A	631021		Inlet Needle, Seat & Clip Assy.
301	631878		Carburetor (Incl. 145) (Refer to Division 5, Section A, page
			134 for breakdown)
304	33237A		* Gasket Set (Incl. items marked *)



Ref #	Part Number	Qty Description
178	27070	Washer, Lock 1/4 E.T. (Use as require d)
178	650675	Washer, Flat 1/4 (Use as required)
179	33013	Cover, Starter bubble
180	650701	Screw, 8-18 x 7/16" (Use as required)
222	792028	Screw, 5/16-18 x 7/8" (Use w/32817 st r.motor)
222	650781	Screw,5/16-18 x 11/16"(Use w/33835 st r.motor)
235	34276	Plate, Cover (Use as required to cover regulator mounting hole in blower housing)
236	650736	Screw, 10-16 x 3/8" (Use as required)
252	730134	Rewind Starter Kit (Incl. 165, 166, 167, 168, 169 & 291) (Use as required)
253	33018	Harness Assy., Adapter (Use as requir ed)
254A	610902	Alternator Coil (20 Amp)(Incl.256,257,258)
255	650521	Screw, 10-32 x 1-1/8"
256	610905	Terminal
257B	610824	Flat Connector (Female terminals) (As req.)
257	610904	Terminal
258	610903	Connector, Flat
266	610750	Grommet, Lead wire
275	730198	Starter Switch Kit(Incl. 287-298) (As req.)



Ref #	Part Number	Qty	Description
41	31967	•	Spring, Governor
70G	32961		Valve, Fuel shut-off
71	26460		Clamp, Fuel line (Use as required)
72	29774		Fuel Line (Braided) (8.25") (Use as r equired)
72	30705		Fuel Line (Braided) (16") (Use as req uired)
72	30962		Fuel Line (Braided) (32") (Use as req uired)
72	30965		Fuel Line (Braided) (48") (Use as req uired)
119	28534		Pipe Plug, 1/8-27 (Use as required)
119	9556		Plug, Pipe, 1/8-27 (Use as required)
122C	32907B		Bracket, Air cleaner
122B	34071		Bracket, Air cleaner
123A	32008		Element, Air cleaner
124	32906		Element, Pre-Air cleaner
125	32904		Cover, Pre-air cleaner
184	27793		Clip, Conduit
185	28942		Screw, 10-32 x 3/8"
237	32958		Fitting, Fuel
238	32959		Fuel Pump, Impulse
239	33010		Repair Kit, Impulse fuel pump
285	32960		Washer, Lock
286	650849		Nut, Hex jam, 3/8-24