



Ref #			Description
1	34096C		Cylinder (Cl liner)(3-5/16")(Incl.2,20,41,43,72 & 119)
2	27652	P	Pin, Dowel
15A	30700	Y	′oke, Governor
15	30699C	R	Rod Assy., Governor (Incl. 15A & 15B)
	650494		Screw, 6-40 x 5/16"
	33454		Governor Lever Assy.
	29916		Damp, Governor lever
	650548		•
			Screw, 8-32 x 5/16"
	32630		
25	35256A		Blower Housing Baffle (With electric starter knockout) (Use
		a	is required)
25	29536	В	Blower Housing Baffle (Without electric starter knockout)
20	20000		Use as required)
		(C	Use as required)
26	650561	S	Screw, 1/4-20 x 5/8"
30	33365B	С	Crankshaft (Incl. 108 & 109)
	29826		Screw, 10-32 x 3/4"
	29918		ockwasher, #8 E.T.
	30322		Jut & Lockwasher, 8-32
	29216		ocknut, 10-32
	29642		Ring, Retaining
	34543		Piston, Pin & Ring Set (Std.) (3-3/16 ")
	34544		Piston, Pin & Ring Set (.010" OS)
	34545		Piston, Pin & Ring Set (.020" OS)
41	34031B	P	Piston & Pin Ass'y. (Std.)(3-3/16")(I ncl.43)
41	34032B	P	Piston & Pin Ass'y. (.010" OS) (Incl. 43)
41	34033B	Р	Piston & Pin Ass'y. (.020" OS) (Incl. 43)
	34037		Ring Set (Std.) (3-3/16" Bore)
	34038		Ring Set (.010" OS)
	34039		Ring Set (.020" OS)
	27888		Ring, Piston Pin retaining
	32591C		• •
			Rod Assy., Connecting (Incl. 46, 47 & 49)
	650662C		Bolt, Connecting rod (2 pieces)
	650662C		Bolt, Connecting rod (2 pieces)
	34034		ifter, Valve
	34242		Dipper, Oil
	34143	С	Camshaft (MCR)
60	33273A	E	Extension, Blower housing
61	34126	В	Bracket, Grommet mounting
62	650760	S	Screw, 8-32 x 3/8"
	28545		Grommet, Plastic
	650128		Screw, 10-24 x 1/2"
	35262		Gasket, Flange
	33367B		Cover, Cylinder (Incl. 71, 75 & 80)
	33368		Bushing, Crankshaft
	27642		Plug, Oil drain
	31950		Seal, Oil
	31845		Shaft, Mechanical governor
	30590A		Vasher, Flat
	30591	G	Gear Assy., Governor (Incl. 81)
83	30588A	S	Spool, Governor
	29193		king, Retaining
	650833		Screw, 1/4-20 x 1-3/16 (Use as required)
	650832		Screw, 1/4-20 x 1-11/16" (Use as required)
	32589		Key, Flywheel
	650815		
			Vasher, Belleville
	8116		Jut, Hex
101	610118	C	Cover, Spark plug

		Aty Description
	650489	Screw, 1/4-20 x 5/8"
108	29783	Pin, Crankshaft gear (Only serviceable when gear is pinned
		to crank.)
109	33245	Gear, Crankshaft
	34240	Ground Wire
	34923A	* Gasket, Cylinder head
	34030A	Head, Cylinder
	27878A	Exhaust Valve (Std.) (Incl. 151)
	27880A	Exhaust Valve (1/32" OS) (Incl. 151)
	34035	Intake Valve (Std.) (Incl. 151)
	34036	Intake Valve (1/32" OS) (Incl. 151)
	650691	Washer (Do not use with No. 6021A scr ew.)
	650690	Washer, Belleville (Use as required)
129	650727	Screw, 5/16-18 x 1-3/4 (Use as requir ed)
130	6021A	Screw, 5/16-18 x 1-1/2" (Use as required, but do notuse No
		650691 washer.)
130	650711	Screw, 5/16-18 x 1-5/8 " (Use as required) (Can use 6021A
100		but discard 650691 washer.)
130	650694A	Screw, 5/16-18 x 2" (Use as required)
131A	650713	Screw, 5/16-18 x 5/8"
	650737	Screw, 1/4-20 x 1/2" (Use as required)
	650738	Screw, $1/4-20 \times 5/8$ (Use as required)
	650890	Washer, Internal Lock
	33636	
		Resistor Spark Plug
	33369	Bracket, Governor gear
	650836	Screw, 10-24 x 1/2"
	35862	Seal Assy., Intake valve
	27881	Spring, Valve
	32581	Cap, Lower valve spring
	27896A	* Gasket, Breather
170	28423	Body, Breather
171	28424	Element, Breather
172	28425	Cover, Breather
173	35350	Tube, Breather
	650128	Screw, 10-24 x 1/2"
	29752	Nut & Lockwasher, 1/4-28
	30088A	Screw, 1/4-28 x 1"
	34587	Bracket, Choke
	33263	
		* Gasket, Carburetor
	33877	Pipe, Intake
	34667	Link, Governor lever
	34664	Control Bracket (Incl.19,203, 204, 20 6 & 209)
	31342	Spring, Compression
	650549	Screw, 5-40 x 7/16"
	33878	Link, Governor lever-to-throttle
209	650821	Screw, 10-32 x 1/2"
210	27793	Clip, Conduit
	28942	Screw, 10-32 x 3/8"
	34586	Rod, Choke
	35438	Knob, Control
	28820	
	20020	Screw, 10-32 x 1/2"
222A	CE0070	Pop Rivet (Can be purchased locally)
	650378	Screw, Torx T-30, 5/16-18 x 1-1/8"
	27915A	* Gasket, Intake pipe
	34822A	Blower Housing
	650788	Screw, 5/16-18 x 3/4"


		y Description
262	29747B	Screw, 5/16-24 x 21/32"
265	33272B	Cover, Cylinder head
275	33280A	Muffler
	31588	Plate, Muffler locking
	35741	Plate, Muffler locking
	650729	Screw, 5/16-18 x 3-3/16" (Use as required)
	651002	
		Screw, 5/16-18 x 4-1/4" (Use as required)
	33013	Cover, Starter bubble
	650760	Screw, 8-32 x 7/16"
	33662	Hub & Screen Assy.
	29752	Nut, 1/4-28
290	29774	Fuel Line (Braided 8-1/4")(21cm)(As r equired)
290	30962	Fuel Line (Braided 32")(80cm)(As requ ired)
291	30705	Fuel Line (Braided 16")(40cm)(As required)
	26460	Fuel Line Clamp (Use as required)
	650665	Screw, 1/4-15 x 7/8"
	34156A	Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
500	54150A	
		builtwith different size fuel inlet openings. Tanks with the
		1-3/16" I.D. opening use fuel cap 34210. Tanks with the
		1-1/2" I.D. opening use fuel cap 35355.
301A	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
		I.D.)
		1.0.)
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
		required) (1.5" I.D.)
0014	04040	
301A	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
		as required) (1.5" I.D.)
301A	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
	33893A	Oil Fill Tube
	33590	"O" Ring
	34011A	•
		Dipstick (Incl. 307)
	650765	Screw, 10-32 x 1/2"
	34666	Cover, Carburetor
	31291	Plug, Cover
338	28942	Screw, Sems 10-32 x 3/8"
340	34154	Plate, Upper fuel tank mtg.
341	34155	Bracket, Lower fuel tank mtg.
	650561	Screw, 1/4-20 x 5/8"
	34141	Guard, Starter
	32576	Seal, Snow Guard
	650767	Screw, 8-32 x 27/64"
	34346	Decal, Instruction
	35274	Decal, Instruction
	34589	Decal, Choke
	34686	Decal, Name
	34144	Decal, Primer
379	631021	Inlet Needle, Seat & Clip Assy.
	632110	Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A,
		page 168 for breakdown or Fiche18B, Grid E-9)
<u>.</u>		1 3
	33279G	* Gasket Set (Incl. items marked *)
420	730225	SAE 30 4-Cycle Engine Oil (Quart)
421	730226	SAE 5W30 4-Cycle Engine Oil (Quart)
422	35824	Muffler Optional



Ref #	Part Number	Qty	Description
	30322		Nut & Lockwasher, 8-32
	650760		Screw, 8-32 x 3/8"
	28545		Grommet, Plastic
	650727		Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131A	650713		Screw, 5/16-18 x 5/8"
131	650737		Screw, 1/4-20 x 1/2" (Use as required)
131	650738		Screw, 1/4-20 x 5/8 (Use as required)
222A			Pop Rivet (Can be purchased locally)
274	35865		Gasket, Exhaust
275	33280A		Muffler
277	650729		Screw, 5/16-18 x 3-3/16" (Use as required)
277	651002		Screw, 5/16-18 x 4-1/4" (Use as required)
285A	33662		Hub & Screen Assy.
290	29774		Fuel Line (Braided 8-1/4")(21cm)(As r equired)
290	30962		Fuel Line (Braided 32")(80cm)(As required)
292	26460		Fuel Line Clamp (Use as required)
298	650665		Screw, 1/4-15 x 7/8"
300	34156A		Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
			builtwith different size fuel inlet openings. Tanks with the
			1-3/16" I.D. opening use fuel cap 34210. Tanks with the
			1-1/2" I.D. opening use fuel cap 35355.
3014	410144B		Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
30 IA	410144D		I.D.)
			1.0.)
301A	33032		Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
			required) (1.5" I.D.)
3014	34210		Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
30 IA	54210		as required) (1.5" I.D.)
			as required) (1.5 1.D.)
301A	35355		Fuel Cap (Red Plastic)(1.75" I.D.)
337	34666		Cover, Carburetor
338A	31291		Plug, Cover
341	34155		Bracket, Lower fuel tank mtg.
342	650561		Screw, 1/4-20 x 5/8"
350	570682		Primer Assy.
351	32180C		Line, Primer
	34144		Decal, Primer
414	33323		Opt.Muffler Screen (Mini-Bike applica tion)
	730130		Kit, Exhaust adapter (Incl. 274 & 277)
	33700		Cover & Tube, Muffler (use as require d)
	650578		Screw, 8-18 x 3/8" (use as required)
	730226		SAE 5W30 4-Cycle Engine Oil (Quart)
	35824		Muffler Optional



	Part Number	Qty	Description
	30322		Nut & Lockwasher, 8-32
129	650727		Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131	650737		Screw, 1/4-20 x 1/2" (Use as required)
131	650738		Screw, 1/4-20 x 5/8 (Use as required)
131A	650713		Screw, 5/16-18 x 5/8"
	34587		Bracket, Choke
	730152		Control Bracket (Incl.1158-1171)(As r eq.)
	31342		Spring, Compression
	650549		Screw, 5-40 x 7/16"
	27793		Clip, Conduit
	28942		Screw, 10-32 x 3/8"
	28820		Screw, 10-32 x 1/2"
222A	20020		Pop Rivet (Can be purchased locally)
	700107		
221	730127		Air Cleaner Ass'y. (Incl. 238, 239, 242, 246, 250) (Use as required)
285A	33662		Hub & Screen Assy.
	29774		Fuel Line (Braided 8-1/4")(21cm)(As r equired)
	30962		Fuel Line (Braided 32")(80cm)(As required)
	30705		Fuel Line (Braided 16")(40cm)(As required)
	33715		Impulse Fuel Pump NOTE: 34385 and 33715 (WIP)pumps
200			are replaced by 35813 and 35800 (WIP) pumps. The 33010
			(3000 series) repair kit is still available. The 35791 repair kit
			is used with the 35813 and 35800 fuel pumps.
294	35791		Fuel Pump Repair Kit NOTE: 34385 and 33715 (WIP)pumps
			are replaced by 35813 and 35800 (WIP) pumps. The 33010
			(3000 series) repair kit is still available. The 35791 repair kit
			is used with the 35813 and 35800 fuel pumps.
301A	410144B		Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
			I.D.)
301A	33032		Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
			required) (1.5" I.D.)
301A	34210		Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
			as required) (1.5" I.D.)
201 \	35355		Fuel Cap (Red Plastic)(1.75" I.D.)
	32958		Fuel Cap (Red Plastic)(1.75" I.D.)
			Fitting, Fuel
	650765		Screw, 10-32 x 1/2"
	34666		Cover, Carburetor
	31291		Plug, Cover
	33377		Bracket, Carburetor cover mtg.
	650767		Screw, 8-32 x 27/64"
	34346		Decal, Instruction
	35274		Decal, Instruction
	34589		Decal, Choke
370D	34144		Decal, Primer
370E	34414		Decal, Warning
	730226		SAE 5W30 4-Cycle Engine Oil (Quart)
	35824		Muffler Optional
	30312		Screw, 10-32 x 1/2"
	28820		Screw, 10-32 x 1/2"
1100			Lockwasher
1160			
1160 1185	33816		Hub & Screen Assy.



		Description
1	34096C	Cylinder (CI liner)(3-5/16")(Incl.2,20,41,43,72 & 119)
2	27652	Pin, Dowel
37A	30322	Nut & Lockwasher, 8-32
	27642	Plug, Oil drain
	610118	Cover, Spark plug
	650489	Screw, 1/4-20 x 5/8"
	650727	
		Screw, 5/16-18 x 1-3/4 (Use as required)
	650713	Screw, 5/16-18 x 5/8"
	650737	Screw, 1/4-20 x 1/2" (Use as required)
	650738	Screw, 1/4-20 x 5/8 (Use as required)
	27896A	* Gasket, Breather
170	28423	Body, Breather
171	28424	Element, Breather
172	28425	Cover, Breather
	35350	Tube, Breather
	650128	Screw, 10-24 x 1/2"
	29752	Nut & Lockwasher, 1/4-28
	33878	Link, Governor lever-to-throttle
	33070	
222A	001000	Pop Rivet (Can be purchased locally)
275B	391026	Muffler (Incl. 284, 284A & 416) (This spark arrester
		mufflercan be used on any model.)
275	33280A	Muffler
	31588	
		Plate, Muffler locking
	35741	Plate, Muffler locking
	650729	Screw, 5/16-18 x 3-3/16" (Use as requ ired)
	651002	Screw, 5/16-18 x 4-1/4" (Use as requi red)
	33662	Hub & Screen Assy.
301A	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
		I.D.)
201 4	22022	Fuel Can (Bad Plantia) (Sourt Desigtant Law Profile) (Las as
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
		required) (1.5" I.D.)
301A	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
001/1	34210	as required) (1.5" I.D.)
		as required (1.5 1.D.)
301A	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
	33876	Gasket, Stator (Used only on Std. poi nt ign.)
	34666	Cover, Carburetor
	31291	Plug, Cover
	34144	Decal, Primer
375	610842	Magneto NOTE: The complete magneto is not available as
		an assembly. Themagneto number is shown for reference
		purpose only. Order component parts individually, as shown
		in parts list. (Refer to Division 5, Section B, page 28 for
		breakdown or Fiche 18B, Grid F-1)
	005 (5)	
	30547A	Breaker Points (Use with Std. point i gn.)
378	30548B	Condenser
380	632110	Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A,
		page 168 for breakdown or Fiche18B, Grid E-9)
	730226 35824	SAE 5W30 4-Cycle Engine Oil (Quart) Muffler Optional