



Ref #	Part Number Qty	Description
1	34922A	Cylinder (CI liner)(3-5/16")(Incl.2,2 0 & 72)
	27652	Pin, Dowel
	650820	Screw, 1/4-20 x 1/2"
	30700	Yoke, Governor
15	30699C	Rod Assy., Governor (Incl. 15A & 15B)
15B	650494	Screw, 6-40 x 5/16"
	33454	Governor Lever Assy.
	29916	Clamp, Governor lever
	650548	Screw, 8-32 x 5/16"
20	32630	Seal, Oil
25	29536	Blower Housing Baffle (Without electric starter knockout)
		(Use as required)
	050504	
25	35256A	Blower Housing Baffle (With electric starter knockout) (Use
		as required)
26	650561	Screw, 1/4-20 x 5/8"
	33365B	Crankshaft (Incl. 108 & 109)
	29826	Screw, 10-32 x 3/4"
36	29918	Lockwasher, #8 E.T.
37A	30322	Nut & Lockwasher, 8-32
	29216	Locknut, 10-32
	29642	Ring, Retaining
	34860A	Piston, Pin & Ring Set (Std.)(3-5/16")
40	34861A	Piston, Pin & Ring Set (.010" OS)
40	34862A	Piston, Pin & Ring Set (.020" OS)
	34863	Piston & Pin Ass'y. (Std.)(3-5/16")(I ncl.43)
	34864	Piston & Pin Ass'y. (.010" OS) (Incl. 43)
41	34865	Piston & Pin Ass'y. (.020" OS) (Incl. 43)
42	34866A	Ring Set (Std.) (3-5/16" Bore)
	34867A	Ring Set (.010" OS)
	34868A	Ring Set (.020" OS)
	27888	Ring, Piston Pin retaining
45	32591C	Rod Assy., Connecting (Incl. 46, 47 & 49)
46	650662C	Bolt, Connecting rod (2 pieces)
	650662C	Bolt, Connecting rod (2 pieces)
	34034	Lifter, Valve
49	34242	Dipper, Oil
50	34143	Camshaft (MCR)
	33273A	Extension, Blower housing
	34126	Bracket, Grommet mounting
	650760	Screw, 8-32 x 3/8"
63	28545	Grommet, Plastic
65	650128	Screw, 10-24 x 1/2"
	35262	* Gasket, Flange
	33367B	Cover, Cylinder (Incl. 71, 75 & 80)
	33368	Bushing, Crankshaft
72	27642	Plug, Oil drain
75	31950	Seal, Oil
	31845	Shaft, Mechanical governor
		•
	30590A	Washer, Flat
	30591	Gear Assy., Governor (Incl. 81)
83	30588A	Spool, Governor
	29193	Ring, Retaining
80	650833	Screw, 1/4-20 x 1-3/16 (Use as required)
	650832	Screw, 1/4-20 x 1-11/16" (Use as requ ired)
	32589	Key, Flywheel
89		
89 92	32589 650815 8116	Key, Flywheel Washer, Belleville Nut, Hex

Ref #	Part Number	Qtv	Description
	610118	<u> </u>	
			Cover, Spark plug
103	650489		Screw, 1/4-20 x 5/8"
108	29783		Pin, Crankshaft gear (Only serviceable when gear is pinned
			to crank.)
109	33245		Gear, Crankshaft
	34240		Ground Wire
119	34923A		* Gasket, Cylinder head
120	34030A		Head, Cylinder
	27878A		Exhaust Valve (Std.) (Incl. 151)
	27880A		Exhaust Valve (1/32" OS) (Incl. 151)
126	34035		Intake Valve (Std.) (Incl. 151)
	34036		Intake Valve (1/32" OS) (Incl. 151)
	650691		Washer (Do not use with No. 6021A scr ew.)
128	650690		Washer, Belleville (Use as required)
129	650727		Screw, 5/16-18 x 1-3/4 (Use as required)
	6021A		Screw, $5/16-18 \times 1-1/2$ " (Use as required, but do notuse No.
130	002 TA		
			650691 washer.)
130	650711		Screw, 5/16-18 x 1-5/8 " (Use as required) (Can use 6021A
			but discard 650691 washer.)
			bul discard 000091 washel.
130	650694A		Screw, 5/16-18 x 2" (Use as required)
	650737		Screw, 1/4-20 x 1/2" (Use as required)
131	650738		Screw, 1/4-20 x 5/8 (Use as required)
131A	650713		Screw, 5/16-18 x 5/8"
	650890		
			Washer, Internal Lock
135	33636		Resistor Spark Plug
139	33369		Bracket, Governor gear
	650836		Screw, 10-24 x 1/2"
	35862		Seal Assy., Intake valve
150	27881		Spring, Valve
151	32581		Cap, Lower valve spring
	27896A		* Gasket, Breather
170	28423		Body, Breather
171	28424		Element, Breather
	28425		Cover, Breather
			•
	35350		Tube, Breather
174	650128		Screw, 10-24 x 1/2"
178	29752		Nut & Lockwasher, 1/4-28
	30088A		Screw, 1/4-28 x 1"
	34587		Bracket, Choke
184	33263		* Gasket, Carburetor
	33877		Pipe, Intake
	34667		•
			Link, Governor lever
	34664		Control Bracket (Incl.19,203, 204, 20 6 & 209)
203	31342		Spring, Compression
	650549		Screw, 5-40 x 7/16"
	33878		Link, Governor lever-to-throttle
209	650821		Screw, 10-32 x 1/2"
	27793		Clip, Conduit
	28942		•
			Screw, 10-32 x 3/8"
	34586		Rod, Choke
220	35438		Knob, Control
	28820		Screw, 10-32 x 1/2"
222A			Pop Rivet (Can be purchased locally)
223	650378		Screw, Torx T-30, 5/16-18 x 1-1/8"
	27915A		* Gasket, Intake pipe
200	34822A		Blower Housing


		Description
	650788	Screw, 5/16-18 x 3/4"
262	29747B	Screw, 5/16-24 x 21/32"
265	33272B	Cover, Cylinder head
	35056	Muffler
	31588	Plate, Muffler locking
	35741	Plate, Muffler locking
	650729	Screw, 5/16-18 x 3-3/16" (Use as required)
	651002	
		Screw, 5/16-18 x 4-1/4" (Use as required)
	33013	Cover, Starter bubble
	650760	Screw, 8-32 x 7/16"
	33662	Hub & Screen Assy.
	29752	Nut, 1/4-28
290	29774	Fuel Line (Braided 8-1/4")(21cm)(As r equired)
290	30962	Fuel Line (Braided 32")(80cm)(As requ ired)
291	30705	Fuel Line (Braided 16")(40cm)(As required)
	26460	Fuel Line Clamp (Use as required)
	32961	Valve, Fuel shut-off
	650665	Screw, 1/4-15 x 7/8"
	34156A	Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
500	34130A	builtwith different size fuel inlet openings. Tanks with the
		, e
		1-3/16" I.D. opening use fuel cap 34210. Tanks with the
		1-1/2" I.D. opening use fuel cap 35355.
301A	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
001/1		
		,
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
		required) (1.5" I.D.)
001 4	24240	
301A	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
		as required) (1.5" I.D.)
3014	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
	33893A	Oil Fill Tube
	33590	
	34011A	Dipstick (Incl. 307)
	650765	Screw, 10-32 x 1/2"
337	35057A	Cover, Carburetor (Incl. 329)
338	28942	Screw, Sems 10-32 x 3/8"
338A	31291	Plug, Cover
340	34154	Plate, Upper fuel tank mtg.
	34155	Bracket, Lower fuel tank mtg.
	650561	Screw, 1/4-20 x 5/8"
	34141	Guard, Starter
	32576	Seal, Snow Guard
	650767	Screw, 8-32 x 27/64"
	34589	Decal, Choke
	34144	Decal, Primer
	34346	Decal, Instruction
370	35274	Decal, Instruction
379	631021	Inlet Needle, Seat & Clip Assy.
	632370	Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A,
		page 200 for breakdown or Fiche18B, Grid E-13)
000		$Page Los ior broakdown or nonorod, Ond L^10)$
	33279G	* Gasket Set (Incl. items marked *)
400	33279G 730225	* Gasket Set (Incl. items marked *) SAE 30 4-Cycle Engine Oil (Quart)
400 420	730225	SAE 30 4-Cycle Engine Oil (Quart)
400 420 421		



		Description
	30322	Nut & Lockwasher, 8-32
	650760	Screw, 8-32 x 3/8"
63	28545	Grommet, Plastic
129	650727	Screw, 5/16-18 x 1-3/4 (Use as required)
131	650737	Screw, 1/4-20 x 1/2" (Use as required)
131	650738	Screw, 1/4-20 x 5/8 (Use as required)
131A	650713	Screw, 5/16-18 x 5/8"
222A		Pop Rivet (Can be purchased locally)
274	35865	Gasket, Exhaust
275C	35056	Muffler
	650729	Screw, 5/16-18 x 3-3/16" (Use as requ ired)
	651002	Screw, 5/16-18 x 4-1/4" (Use as required)
	33662	Hub & Screen Assy.
	29774	Fuel Line (Braided 8-1/4")(21cm)(As r equired)
	30962	Fuel Line (Braided 32")(80cm)(As required)
	26460	Fuel Line Clamp (Use as required)
	32961	Valve, Fuel shut-off
	650665	Screw, 1/4-15 x 7/8"
	34156A	Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
		builtwith different size fuel inlet openings. Tanks with the
		1-3/16" I.D. opening use fuel cap 34210. Tanks with the
		1-1/2" I.D. opening use fuel cap 35355.
301A	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
		I.D.)
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
00171	00002	required) (1.5" I.D.)
301A	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
		as required) (1.5" I.D.)
301A	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
	35057A	Cover, Carburetor (Incl. 329)
	31291	Plug, Cover
	34155	Bracket, Lower fuel tank mtg.
	650561	Screw, 1/4-20 x 5/8"
	570682	Primer Assy.
	32180C	Line, Primer
	34144	Decal, Primer
	33323	•
		Opt.Muffler Screen (Mini-Bike applica tion)
	730130	Kit, Exhaust adapter (Incl. 274 & 277)
	33700	Cover & Tube, Muffler (use as require d)
	650578 720226	Screw, 8-18 x 3/8" (use as required)
	730226 35824	SAE 5W30 4-Cycle Engine Oil (Quart) Muffler Optional
	3778 //I	



		Qty	Description
	30322		Nut & Lockwasher, 8-32
129	650727		Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131A	650713		Screw, 5/16-18 x 5/8"
131	650737		Screw, 1/4-20 x 1/2" (Use as required)
131	650738		Screw, 1/4-20 x 5/8 (Use as required)
	34587		Bracket, Choke
	730152		Control Bracket (Incl.1158-1171)(As r eq.)
	31342		
			Spring, Compression
	650549		Screw, 5-40 x 7/16"
	27793		Clip, Conduit
211	28942		Screw, 10-32 x 3/8"
222	28820		Screw, 10-32 x 1/2"
222A			Pop Rivet (Can be purchased locally)
227	730127		Air Cleaner Ass'y. (Incl. 238, 239, 242, 246, 250) (Use as
			required)
275C	35056		Muffler
285A	33662		Hub & Screen Assy.
	29774		Fuel Line (Braided 8-1/4")(21cm)(As r equired)
	30962		Fuel Line (Braided 32")(80cm)(As required)
	30705		Fuel Line (Braided 16")(40cm)(As required)
293	33715		Impulse Fuel Pump NOTE: 34385 and 33715 (WIP)pumps
			are replaced by 35813 and 35800 (WIP) pumps. The 33010
			(3000 series) repair kit is still available. The 35791 repair kit
			is used with the 35813 and 35800 fuel pumps.
204	05704		Fuel Duran Densit 1/t NOTE: 24205 and 22745 (M/ID)numero
294	35791		Fuel Pump Repair Kit NOTE: 34385 and 33715 (WIP)pumps
			are replaced by 35813 and 35800 (WIP) pumps. The 33010
			(3000 series) repair kit is still available. The 35791 repair kit
			is used with the 35813 and 35800 fuel pumps.
201 4	4404.44D		Fuel Cap (M/bite Directio)/Standard) (Lice as required) (1 5"
301A	410144B		Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
			I.D.)
301A	33032		Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
00177	00002		required) (1.5" I.D.)
			required) (1.5 1.D.)
301A	34210		Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
			as required) (1.5" I.D.)
301A	35355		Fuel Cap (Red Plastic)(1.75" I.D.)
303	32958		Fitting, Fuel
336	650765		Screw, 10-32 x 1/2"
	35057A		Cover, Carburetor (Incl. 329)
	31291		Plug, Cover
	33377		Bracket, Carburetor cover mtg.
	650767		Screw, 8-32 x 27/64"
	34144		Decal, Primer
370C	34589		Decal, Choke
	34346		Decal, Instruction
	35274		Decal, Instruction
370	730226		•
			SAE 5W30 4-Cycle Engine Oil (Quart)
421			Muffler Optional
421 422	35824		
421 422 1159	35824 30312		Screw, 10-32 x 1/2"
421 422 1159	35824		
421 422 1159 1160	35824 30312 28820		Screw, 10-32 x 1/2"
421 422 1159 1160 1160	35824 30312		Screw, 10-32 x 1/2" Screw, 10-32 x 1/2"



		Description
1 3	34922A	Cylinder (CI liner)(3-5/16")(Incl.2,2 0 & 72)
2 2	27652	Pin, Dowel
3 6	650820	Screw, 1/4-20 x 1/2"
37A 3		Nut & Lockwasher, 8-32
	27642	Plug, Oil drain
	610118	Cover, Spark plug
	650489	Screw, 1/4-20 x 5/8"
	650727	Screw, 5/16-18 x 1-3/4 (Use as required)
	650737	Screw, 1/4-20 x 1/2" (Use as required)
	650738	Screw, 1/4-20 x 5/8 (Use as required)
131A 6	650713	Screw, 5/16-18 x 5/8"
169 2	27896A	* Gasket, Breather
170 2	28423	Body, Breather
171 2	28424	Element, Breather
	28425	Cover, Breather
	35350	Tube, Breather
	650128	Screw, 10-24 x 1/2"
	29752	Nut & Lockwasher, 1/4-28
207 3	53676	Link, Governor lever-to-throttle
222A		Pop Rivet (Can be purchased locally)
275C 3		Muffler
275B 3	391026	Muffler (Incl. 284, 284A & 416) (This spark arrester
		mufflercan be used on any model.)
276 3	21599	Plate, Muffler locking
276 3		Plate, Muffler locking
	650729	Screw, 5/16-18 x 3-3/16" (Use as required)
	651002	Screw, 5/16-18 x 4-1/4" (Use as required)
285A 3		Hub & Screen Assy.
301A 4	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
		I.D.)
301A 3	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
		required) (1.5" I.D.)
301A 3	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
		as required) (1.5" I.D.)
301A (35355	Fuel Cap (Red Plastic)(1.75" I.D.)
313A 3		Gasket, Stator (Used only on Std. poi nt ign.)
	35057A	Cover, Carburetor (Incl. 329)
338A 3		Plug, Cover
370D 3	34144	Decal, Primer
375 6	610848	Magneto (w/ring gear for 120 Volt sta rter) NOTE: The
		complete magneto is not available as an assembly.
		The magneto number is shown for reference purpose only.
		Order component parts individually, as shown in parts list.
		(Refer to Division 5, Section B, page 28 for breakdown or
		Fiche 18B, Grid F-1
377 3	30547A	Breaker Points (Use with Std. point i gn.)
	30548B	Condenser
	632370	Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A,
380 6		
380 6		page 200 for breakdown or Fiche18R Grid F-13)
		page 200 for breakdown or Fiche18B, Grid E-13)
	730226	page 200 for breakdown or Fiche18B, Grid E-13) SAE 5W30 4-Cycle Engine Oil (Quart) Muffler Optional