



	Part Number Qty	
1	34922A	Cylinder (CI liner)(3-5/16")(Incl.2,2 0 & 72)
2	27652	Pin, Dowel
3	650820	Screw, 1/4-20 x 1/2"
	30968	Nipple, Oil drain
	30969	Cap, Oil drain
	30699C	Rod Assy., Governor (Incl. 15A & 15B)
	650494	Screw, 6-40 x 5/16"
	30700	Yoke, Governor
	33454	Governor Lever Assy.
17	29916	Clamp, Governor lever
18	650548	Screw, 8-32 x 5/16"
	32630	Seal, Oil
	29536	Blower Housing Baffle (Without electric starter knockout)
20	2000	(Use as required)
25	35256A	Blower Housing Baffle (With electric starter knockout) (Use
		as required)
	650561	Screw, 1/4-20 x 5/8"
	33719B	Crankshaft (Incl. 108 & 109)
	29826	Screw, 10-32 x 3/4"
36	29918	Lockwasher, #8 E.T.
37	29216	Locknut, 10-32
37A	30322	Nut & Lockwasher, 8-32
	29642	Ring, Retaining
	34860A	Piston, Pin & Ring Set (Std.)(3-5/16")
	34861A	
		Piston, Pin & Ring Set (.010" OS)
	34862A	Piston, Pin & Ring Set (.020" OS)
	34863	Piston & Pin Ass'y. (Std.)(3-5/16")(I ncl.43)
41	34864	Piston & Pin Ass'y. (.010" OS) (Incl. 43)
41	34865	Piston & Pin Ass'y. (.020" OS) (Incl. 43)
42	34866A	Ring Set (Std.) (3-5/16" Bore)
	34867A	Ring Set (.010" OS)
	34868A	Ring Set (.020" OS)
	27888	Ring, Piston Pin retaining
		• •
	32591C	Rod Assy., Connecting (Incl. 46, 47 & 49)
	650662C	Bolt, Connecting rod (2 pieces)
	650662C	Bolt, Connecting rod (2 pieces)
48	34034	Lifter, Valve
49	34242	Dipper, Oil
50	34143	Camshaft (MCR)
	33273A	Extension, Blower housing
	34126	Bracket, Grommet mounting
	650760 295.45	Screw, 8-32 x 3/8"
	28545	Grommet, Plastic
	650128	Screw, 10-24 x 1/2"
69	35262	* Gasket, Flange
70	33367B	Cover, Cylinder (Incl. 71, 75 & 80)
	33368	Bushing, Crankshaft
	27642	Plug, Oil drain
	31950	Seal, Oil
		-
	31845	Shaft, Mechanical governor
	30590A	Washer, Flat
82	30591	Gear Assy., Governor (Incl. 81)
83	30588A	Spool, Governor
	29193	Ring, Retaining
54	650833	Screw, 1/4-20 x 1-3/16 (Use as required)
20		
87	650832 32589	Screw, 1/4-20 x 1-11/16" (Use as required) Key, Flywheel

92 93 101 103	Part Number 650815 8116 610118 650489 29783	Qty	Description Washer, Belleville Nut, Hex Cover, Spark plug Screw, 1/4-20 x 5/8" Pin, Crankshaft gear (Only serviceable when gear is pinned to crank.)
110 119 120 125 125 125 126 126 127 128 129	33245 34240 34923A 34030A 27878A 27880A 34035 34036 650691 650690 650727 6021A		Gear, Crankshaft Ground Wire * Gasket, Cylinder head Head, Cylinder Exhaust Valve (Std.) (Incl. 151) Exhaust Valve (1/32" OS) (Incl. 151) Intake Valve (Std.) (Incl. 151) Intake Valve (1/32" OS) (Incl. 151) Washer (Do not use with No. 6021A scr ew.) Washer, Belleville (Use as required) Screw, 5/16-18 x 1-3/4 (Use as required) Screw, 5/16-18 x 1-1/2" (Use as required, but do notuse No. 650691 washer.)
130	650711		Screw, 5/16-18 x 1-5/8 " (Use as required) (Can use 6021A but discard 650691 washer.)
131A 131 131 133 135 139 140 149A 150 151 169 170 171 172 173 174 178 182 183 184 185 186 200 203 204 207 209 210 211 219 220	650694A 650713 650737 650738 650890 33636 33369 650836 35862 27881 32581 27896A 28423 28424 28425 35350 650128 29752 30088A 34587 33263 33877 34667 34667 34664 31342 650549 33878 650821 27793 28942 34586 35438		Screw, 5/16-18 x 2" (Use as required) Screw, 5/16-18 x 5/8" Screw, 1/4-20 x 1/2" (Use as required) Screw, 1/4-20 x 5/8 (Use as required) Washer, Internal Lock Resistor Spark Plug Bracket, Governor gear Screw, 10-24 x 1/2" Seal Assy., Intake valve Spring, Valve Cap, Lower valve spring * Gasket, Breather Body, Breather Element, Breather Element, Breather Cover, Breather Tube, Breather Screw, 10-24 x 1/2" Nut & Lockwasher, 1/4-28 Screw, 1/4-28 x 1" Bracket, Choke * Gasket, Carburetor Pipe, Intake Link, Governor lever Control Bracket (Incl.19,203, 204, 20 6 & 209) Spring, Compression Screw, 10-32 x 1/2"


	Part Number	Qty	Description
	27915A		* Gasket, Intake pipe
260	34822A		Blower Housing
261	650788		Screw, 5/16-18 x 3/4"
	29747B		Screw, 5/16-24 x 21/32"
	33272B		Cover, Cylinder head
	33280A		Muffler
	31588		Plate, Muffler locking
	35741		Plate, Muffler locking
	650729		Screw, 5/16-18 x 3-3/16" (Use as requ ired)
277	651002		Screw, 5/16-18 x 4-1/4" (Use as required)
281	33013		Cover, Starter bubble
	650760		Screw, 8-32 x 7/16"
	33662		Hub & Screen Assy.
	29752		
			Nut, 1/4-28
	29774		Fuel Line (Braided 8-1/4")(21cm)(As r equired)
	30962		Fuel Line (Braided 32")(80cm)(As requ ired)
291	30705		Fuel Line (Braided 16")(40cm)(As required)
292	26460		Fuel Line Clamp (Use as required)
298	650665		Screw, 1/4-15 x 7/8"
	34156A		Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
000			builtwith different size fuel inlet openings. Tanks with the
			1-3/16" I.D. opening use fuel cap 34210. Tanks with the
			1-1/2" I.D. opening use fuel cap 35355.
301A	410144B		Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
00171			
			,
301A	33032		Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
			required) (1.5" I.D.)
2014	34210		Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
301A	34210		
			as required) (1.5" I.D.)
301A	35355		Fuel Cap (Red Plastic)(1.75" I.D.)
	33893A		Oil Fill Tube
	33590		"O" Ring
	34011A		Dipstick (Incl. 307)
336	650765		Screw, 10-32 x 1/2"
337	34666		Cover, Carburetor
338A	31291		Plug, Cover
	28942		Screw, Sems 10-32 x 3/8"
	34154		Plate, Upper fuel tank mtg.
	34155		Bracket, Lower fuel tank mtg.
	650561		Screw, 1/4-20 x 5/8"
359	34141		Guard, Starter
360	32576		Seal, Snow Guard
	650767		Screw, 8-32 x 27/64"
	34416		Decal, Instruction
	35274		Decal, Instruction
			•
3/00	34589		Decal, Choke
	3/1686		Decal, Name
370A			Decal, Primer
370A	34417		
370A 370D			Inlet Needle, Seat & Clip Assy.
370A 370D 379	34417 631021		Inlet Needle, Seat & Clip Assy. Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A.
370A 370D 379	34417		Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A,
370A 370D 379 380	34417 631021 632110		Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)
370A 370D 379 380 400	34417 631021 632110 33279G		Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9) * Gasket Set (Incl. items marked *)
370A 370D 379 380 400 420	34417 631021 632110 33279G 730225		Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9) * Gasket Set (Incl. items marked *) SAE 30 4-Cycle Engine Oil (Quart)
370A 370D 379 380 400 420 421	34417 631021 632110 33279G		Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9) * Gasket Set (Incl. items marked *)



			Description
37A 3	30322		Nut & Lockwasher, 8-32
	650760		Screw, 8-32 x 3/8"
	28545		Grommet, Plastic
	650727		Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131 (650737	9	Screw, 1/4-20 x 1/2" (Use as required)
131 (650738	9	Screw, 1/4-20 x 5/8 (Use as required)
	650713	9	Screw, 5/16-18 x 5/8"
222A		I	Pop Rivet (Can be purchased locally)
274 3	35865		Gasket, Exhaust
275 3	33280A	1	Muffler
277	650729		Screw, 5/16-18 x 3-3/16" (Use as requ ired)
277 (651002		Screw, 5/16-18 x 4-1/4" (Use as requi red)
285A 3	33662	ł	Hub & Screen Assy.
290 2	29774	F	Fuel Line (Braided 8-1/4")(21cm)(As r equired)
290 3	30962	I	Fuel Line (Braided 32")(80cm)(As requ ired)
292 2	26460	F	Fuel Line Clamp (Use as required)
298	650665		Screw, 1/4-15 x 7/8"
300 (34156A	F	Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
		k	builtwith different size fuel inlet openings. Tanks with the
			1-3/16" I.D. opening use fuel cap 34210. Tanks with the
			1-1/2" I.D. opening use fuel cap 35355.
3014	410144B	ſ	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
001/1			I.D.)
301A 3	33032		Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
		r	required) (1.5" I.D.)
301A 3	34210	F	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
001/1			as required) (1.5" I.D.)
301A 3			Fuel Cap (Red Plastic)(1.75" I.D.)
	34666		Cover, Carburetor
338A 3			Plug, Cover
	34155		Bracket, Lower fuel tank mtg.
	650561		Screw, 1/4-20 x 5/8"
350	570682		Primer Assy.
351 3	32180C		Line, Primer
370D 3	34417	[Decal, Primer
414 3	33323	(Opt.Muffler Screen (Mini-Bike applica tion)
415	730130	ł	Kit, Exhaust adapter (Incl. 274 & 277)
418 3	33700	(Cover & Tube, Muffler (use as require d)
419 (650578	9	Screw, 8-18 x 3/8" (use as required)
	730226		SAE 5W30 4-Cycle Engine Oil (Quart)



	Part Number	Qty	Description
37A	30322		Nut & Lockwasher, 8-32
129	650727		Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131A	650713		Screw, 5/16-18 x 5/8"
	650737		Screw, 1/4-20 x 1/2" (Use as required)
	650738		Screw, $1/4-20 \times 5/8$ (Use as required)
	34587		Bracket, Choke
	730152		Control Bracket (Incl.1158-1171)(As r eq.)
	31342		Spring, Compression
204	650549		Screw, 5-40 x 7/16"
210	27793		Clip, Conduit
211	28942		Screw, 10-32 x 3/8"
	28820		Screw, 10-32 x 1/2"
222A			Pop Rivet (Can be purchased locally)
221	730127		Air Cleaner Ass'y. (Incl. 238, 239, 242, 246, 250) (Use as
			required)
2854	33662		Hub & Screen Assy.
	29774		Fuel Line (Braided 8-1/4")(21cm)(As r equired)
	30962		Fuel Line (Braided 32")(80cm)(As required)
	30705		Fuel Line (Braided 16")(40cm)(As requ ired)
293	33715		Impulse Fuel Pump NOTE: 34385 and 33715 (WIP)pumps
			are replaced by 35813 and 35800 (WIP) pumps. The 33010
			(3000 series) repair kit is still available. The 35791 repair ki
			is used with the 35813 and 35800 fuel pumps.
294	35791		Fuel Pump Repair Kit NOTE: 34385 and 33715 (WIP)pump
			are replaced by 35813 and 35800 (WIP) pumps. The 33010
			(3000 series) repair kit is still available. The 35791 repair ki
			is used with the 35813 and 35800 fuel pumps.
301A	410144B		Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
			I.D.)
2014	22222		
301A	33032		Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use a
			required) (1.5" I.D.)
2010	34210		Fuel Cap (Pod Plastic) (Spurt Posistant, High Profile) (Lise
301A	34210		Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
			as required) (1.5" I.D.)
<u>3</u> ∩1Δ	35355		Fuel Cap (Red Plastic)(1.75" I.D.)
	32958		
			Fitting, Fuel
	650765		Screw, 10-32 x 1/2"
	34666		Cover, Carburetor
338A	31291		Plug, Cover
364	33377		Bracket, Carburetor cover mtg.
	650767		Screw, 8-32 x 27/64"
	34416		Decal, Instruction
	35274		Decal, Instruction
			•
	34589		Decal, Choke
	34417		Decal, Primer
370E	34414		Decal, Warning
401	730226		SAE 5W30 4-Cycle Engine Oil (Quart)
421	35824		Muffler Optional
			Screw, $10-32 \times 1/2$ "
422	30317		$\nabla U = \nabla V$. $ U = U = \Delta Z$
422 1159			
422 1159 1160	28820		Screw, 10-32 x 1/2"
422 1159 1160 1160			



		/ Description
1	34922A	Cylinder (Cl liner)(3-5/16")(Incl.2,2 0 & 72)
2	27652	Pin, Dowel
3	650820	Screw, 1/4-20 x 1/2"
37A	30322	Nut & Lockwasher, 8-32
	27642	Plug, Oil drain
	610118	Cover, Spark plug
	650489	Screw, 1/4-20 x 5/8"
	650727	
		Screw, 5/16-18 x 1-3/4 (Use as required)
	650713	Screw, 5/16-18 x 5/8"
	650737	Screw, 1/4-20 x 1/2" (Use as required)
	650738	Screw, 1/4-20 x 5/8 (Use as required)
	27896A	* Gasket, Breather
	28423	Body, Breather
171	28424	Element, Breather
172	28425	Cover, Breather
173	35350	Tube, Breather
	650128	Screw, 10-24 x 1/2"
	29752	Nut & Lockwasher, 1/4-28
	33878	Link, Governor lever-to-throttle
222A		Pop Rivet (Can be purchased locally)
	391026	Muffler (Incl. 284, 284A & 416) (This spark arrester
2130	391020	
		mufflercan be used on any model.)
275	33280A	Muffler
276	31588	Plate, Muffler locking
	35741	Plate, Muffler locking
	650729	Screw, 5/16-18 x 3-3/16" (Use as required)
	651002	Screw, 5/16-18 x 4-1/4" (Use as required)
	33662	Hub & Screen Assy.
	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
301A	410144D	
		I.D.)
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
		required) (1.5" I.D.)
201 4	34310	Fuel Can (Rad Plastic) (Sourt Desistant High Profile) (Las
301A	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
		as required) (1.5" I.D.)
301A	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
	33876	Gasket, Stator (Used only on Std. poi nt ign.)
	34666	Cover, Carburetor
	31291	Plug, Cover
	34417	Decal, Primer
3/5	610848	Magneto (w/ring gear for 120 Volt sta rter) NOTE: The
		complete magneto is not available as an assembly.
		Themagneto number is shown for reference purpose only.
		Order component parts individually, as shown in parts list.
		(Refer to Division 5, Section B, page 28 for breakdown or
		Fiche 18B, Grid F-1
	205474	Procker Dointe (I leavith Std. point i an)
	30547A	Breaker Points (Use with Std. point i gn.)
	30548B	Condenser
380	632110	Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A,
		page 168 for breakdown or Fiche18B, Grid E-9)
<u>4</u> 21	730226	SAE 5W30 4-Cycle Engine Oil (Quart)
	35824	Muffler Optional
722		