



Ref #	Part Number Qty	
1	34922A	Cylinder (CI liner)(3-5/16")(Incl.2,2 0 & 72)
2	27652	Pin, Dowel
	650820	Screw, 1/4-20 x 1/2"
	30699C	Rod Assy., Governor (Incl. 15A & 15B)
	650494	Screw, 6-40 x 5/16"
15A	30700	Yoke, Governor
16	33454	Governor Lever Assy.
	29916	Clamp, Governor lever
		•
	650548	Screw, 8-32 x 5/16"
	32630	Seal, Oil
25	29536	Blower Housing Baffle (Without electric starter knockout)
		(Use as required)
05	050504	
25	35256A	Blower Housing Baffle (With electric starter knockout) (Use
		as required)
26	650561	Screw, 1/4-20 x 5/8"
	33365B	Crankshaft (Incl. 108 & 109)
	29826	Screw, 10-32 x 3/4"
36	29918	Lockwasher, #8 E.T.
37	29216	Locknut, 10-32
	30322	Nut & Lockwasher, 8-32
	29642	Ring, Retaining
	34860A	Piston, Pin & Ring Set (Std.)(3-5/16")
40	34861A	Piston, Pin & Ring Set (.010" OS)
40	34862A	Piston, Pin & Ring Set (.020" OS)
	34863	Piston & Pin Ass'y. (Std.)(3-5/16")(I ncl.43)
	34864	Piston & Pin Ass'y. (.010" OS) (Incl. 43)
	34865	Piston & Pin Ass'y. (.020" OS) (Incl. 43)
42	34866A	Ring Set (Std.) (3-5/16" Bore)
42	34867A	Ring Set (.010" OS)
	34868A	Ring Set (.020" OS)
	27888	Ring, Piston Pin retaining
	32591C	Rod Assy., Connecting (Incl. 46, 47 & 49)
46	650662C	Bolt, Connecting rod (2 pieces)
47	650662C	Bolt, Connecting rod (2 pieces)
48	34034	Lifter, Valve
	34242	
		Dipper, Oil
	34143	Camshaft (MCR)
	33273A	Extension, Blower housing
61	34126	Bracket, Grommet mounting
	650760	Screw, 8-32 x 3/8"
	28545	
	650128	Screw, 10-24 x 1/2"
69	35262	* Gasket, Flange
70	33367B	Cover, Cylinder (Incl. 71, 75 & 80)
	33368	Bushing, Crankshaft
	27642	Plug, Oil drain
	31950	Seal, Oil
80	31845	Shaft, Mechanical governor
81	30590A	Washer, Flat
	30591	Gear Assy., Governor (Incl. 81)
	30588A	Spool, Governor
84	29193	Ring, Retaining
86	650833	Screw, 1/4-20 x 1-3/16 (Use as requir ed)
	650832	Screw, 1/4-20 x 1-11/16" (Use as required)
	32589	Key, Flywheel
	-27:00 <b>7</b>	
92	650815 8116	Washer, Belleville Nut, Hex

	Part Number 610118	Qty	Description Cover, Spark plug
	650489		Screw, 1/4-20 x 5/8"
	29783		Pin, Crankshaft gear (Only serviceable when gear is pinned
100	20100		to crank.)
109	33245		Gear, Crankshaft
110	34240		Ground Wire
119	34923A		* Gasket, Cylinder head
120	34030A		Head, Cylinder
125	27878A		Exhaust Valve (Std.) (Incl. 151)
	27880A		Exhaust Valve (1/32" OS) (Incl. 151)
	34035		Intake Valve (Std.) (Incl. 151)
126	34036		Intake Valve (1/32" OS) (Incl. 151)
	650691		Washer (Do not use with No. 6021A scr ew.)
	650690		Washer, Belleville (Use as required)
	650727		Screw, 5/16-18 x 1-3/4 (Use as requir ed)
	6021A		Screw, 5/16-18 x 1-1/2" (Use as required, but do notuse No
			650691 washer.)
130	650711		Screw, 5/16-18 x 1-5/8 " (Use as required) (Can use 6021A
			but discard 650691 washer.)
	650694A		Screw, 5/16-18 x 2" (Use as required)
	650737		Screw, 1/4-20 x 1/2" (Use as required )
	650738		Screw, 1/4-20 x 5/8 (Use as required)
	650713		Screw, 5/16-18 x 5/8"
	650890		Washer, Internal Lock
135	33636		Resistor Spark Plug
	33369		Bracket, Governor gear
	650836		Screw, 10-24 x 1/2"
	35862		Seal Assy., Intake valve
	27881		Spring, Valve
	32581		Cap, Lower valve spring
	27896A		* Gasket, Breather
	28423		Body, Breather
	28424		Element, Breather
	28425		Cover, Breather
	35350		Tube, Breather
	650128		Screw, 10-24 x 1/2"
	29752		Nut & Lockwasher, 1/4-28
	30088A		Screw, 1/4-28 x 1"
	34587		Bracket, Choke
	33263		* Gasket, Carburetor
	33877		Pipe, Intake
	34667		Link, Governor lever
	34664		Control Bracket (Incl.19,203, 204, 20 6 & 209)
	31342		Spring, Compression
	650549 610072		Screw, 5-40 x 7/16"
	610973		Terminal Assy.
	33878		Link, Governor lever-to-throttle
	650821		Screw, 10-32 x 1/2"
	27793		Clip, Conduit
	28942		Screw, 10-32 x 3/8"
	34586		Rod, Choke
	35438		Knob, Control
	28820		Screw, 10-32 x 1/2"
222A	00020		Pop Rivet (Can be purchased locally)
	650378		Screw, Torx T-30, 5/16-18 x 1-1/8"
	27915A		* Gasket, Intake pipe


260     Blower Housing       261     650788     Screw, 5/16-18 x 34"       262     29747B     Screw, 5/16-18 x 34"       265     33272B     Cover, Cylinder head       275     33280A     Muffer       276     31588     Plate, Muffer locking       277     550729     Screw, 5/16-18 x 3-4/16" (Use as required)       277     550729     Screw, 5/16-18 x 3-4/16" (Use as required)       286     33652     Hub 8 Screw, 8-23 x 7/16"       286     33652     Hub 8 Screw, 8-23 x 7/16"       287     29752     Hub 8 Screw, 8-23 x 7/16"       280     29772     Hub 8 Screw, 10-18 x 3-3/16"       280     29772     Hub 18 Screw, 10-14 x 14/2 (21 cm)/(As required)       281     20062     Fuel Line (Braided 32'/(30 cm)/(As required)       283     23061     Valve, Fuel shut-off       284     28060     Fuel Line (Braided 32'/(30 cm)/(As required)       285     23061     Valve, Fuel shut-off       286     56065     Screw, 14-14 S C 78'       300     34156A     Fuel Cap (Red Plastic) (Sput Resistant, Hugh Profile)			Description
262     29747B     Screw, 5/16-24, 2/132"       265     33272B     Cover, Cylinder head       276     31588     Plate, Muffler locking       276     37741     Plate, Muffler locking       277     650729     Screw, 5/16-18 x 3-3/16" (Use as required)       277     651002     Screw, 5/16-18 x 3-3/16" (Use as required)       281     30013     Cover, Starter bubble       282     650760     Screw, 5/3       2867     29752     Nut, 14-28       290     29774     Fuel Line (Braided 5-1/4")(21cm)(As required)       291     30765     Fuel Line (Braided 5-1/4")(21cm)(As required)       292     28460     Fuel Line (Braided 5-1/4")(21cm)(As required)       293     30765     Fuel Line (Braided 5-1/4")(21cm)(As required)       294     292     28460     Fuel Line (Braided 5-1/4")(21cm)(As required)       294     292     29361     Vake, Fuel shut-off       296     650065     Screw, 1-20     These tanks were       291     Vake, Fuel shut-off     These tanks with the       1-1/2" LD, opening use fuel cap 35356.     Jul A 4			
265     322728     Cover, Cylinder head       276     31588     Plate, Muffler locking       276     31588     Plate, Muffler locking       277     650729     Screw, 5/16-18 x 3-3/16" (Use as required)       277     650729     Screw, 5/16-18 x 4-1/4" (Use as required)       281     30013     Cover, Starter bubbe       282     650760     Screw, 8-32 x 7/16"       2855     30652     Hub 8 Screen Assy.       287     29752     Nut, 1/4-28       280     297774     Fue Line (Braided 42")(Born)(As required)       281     30705     Fue Line (Braided 42")(Born)(As required)       282     28460     Fue Line (Braided 42")(Born)(As required)       286     Sorew, 174-15 x 78"       300     34156A     Fue Line (Damig use fuel ap 3255.       301A     410144B     Fuel Cap (White Plastic)(Standard) (Use as required) (1.5" LD.)       301A     34210     Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" LD.)       301A     34210     Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" LD.)       301A     34210	261	650788	Screw, 5/16-18 x 3/4"
275   32200A   Muffler     276   3558   Plate, Muffler locking     277   651002   Screw, 5716-18     277   651002   Screw, 5716-18     281   30013   Cover, Statter bubble     282   660760   Screw, 5716-18     286   30662   Hub & Screw, 582X 7716"     286   30662   Hub & Screw, 582X 7716"     280   29774   Fue Line (Braided 5-1/47)(21cm)(As required)     281   300302   Fue Line (Braided 5-1/47)(21cm)(As required)     283   30662   Fue Line (Braided 5-1/47)(21cm)(As required)     284   280   Screw, 5716"     284   520   29774   Fue Line (Braided 5-1/47)(21cm)(As required)     283   32961   Vake, Fuel shut-off     284   5200   Screw, 14-15 x 7.8"     300   34156A   Fuel Cap (Cap (Morthe Plastic) (Sandard) (Use as required)     284   5200   Screw, 14-15 x 7.8"     301A   33032   Fuel Cap (Red Plastic) (Sput Resistant, Low Profile) (Use as required) (1.5" LD)     301A   33032   Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" LD)<	262	29747B	Screw, 5/16-24 x 21/32"
275   32800A   Muffler     276   3558   Plate, Muffler locking     276   35741   Plate, Muffler locking     277   651002   Screw, 5/16-18 x 3-3/16" (Use as required)     281   30013   Corew, 5/32 x 7/16"     281   30013   Corew, 5/32 x 7/16"     285A   33662   Hub & Screw, 8-32 x 7/16"     280   29774   Fuel Line (Braided 2-1/4")(21cm)(As required)     280   29774   Fuel Line (Braided 2-1/4")(21cm)(As required)     280   29774   Fuel Line (Braided 2-1/4")(21cm)(As required)     281   200   30962   Fuel Line (Braided 2-1/4")(21cm)(As required)     282   26460   Fuel Line (Braided 2-1/4")(21cm)(As required)   16     283   3003   3015   Fuel Line (Braided 2-1/4")(20cm)(As required)   17     284   6500665   Screw, 1/4-15 x 7.0"   Fuel Line (Braided 2-1/4")(21cm)(As required)   18     284   6500665   Screw, 1/4-15 x 7.0"   Fuel Tank (Ind. 292 & 301) NOTE: These tanks were builtwith (Inferent size (use) inlet openings. Tanks with the 1-3/16" LD, opening use fuel cap 35355.   Fuel Cap (Ned Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" LD)     3	265	33272B	Cover, Cylinder head
276   35741   Plate, Muffler locking     277   650729   Screw, \$716-18 x -3716" (Use as required)     277   651002   Screw, \$716-18 x -414" (Use as required)     281   33013   Cover, Satare bubble     282   650760   Screw, 8-32 x 716"     285A   3682   Hub & Screen, Asy.     287   29752   Nut, 14-28     290   29774   Fuel Line (Braided 8-1/4")(21 cm)(As required)     291   30705   Fuel Line (Braided 45-1/4")(21 cm)(As required)     292   29752   Nut, 114-28     290   30705   Fuel Line (Braided 51/4")(21 cm)(As required)     292   29764   Valve, Fuel shut-off     292   29640   Fuel Tark (Incl. 292 & 301) NOTE: These tanks were builtwith different size fuel inlet openings. Tanks with the 1-3/16" LD, opening use fuel cap 24210. Tarks with the 1-3/16" LD, opening use fuel cap 24210. Tarks with the 1-3/16" LD, opening use fuel cap 24210. Tarks with the 1-3/16" LD, appening use fuel cap (Mark TLow Profile) (Use as required) (1.5" LD)     301A   301A   3210   Fuel Cap (Red Plastic) (Sput Resistant, Low Profile) (Use as required) (1.5" LD.)     301A   32032   Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" LD.)   0016 Hill Tube </td <td>275</td> <td>33280A</td> <td></td>	275	33280A	
276   55741   Plate, Muffler locking     277   651002   Screw, 5/16-18 x 3-716" (Use as required)     281   33013   Cover, Starter bubble     286   3662   Hub & Screen Assy.     287   29752   Nut, 114-28     290   29774   Fuel Line (Braided 27/180cm)(As required)     291   200   29774     293   29660   Fuel Line (Braided 27/180cm)(As required)     292   26400   Fuel Line (Braided 27/180cm)(As required)     293   29661   Valve, Fuel shut-off     298   650665   Screw, 14-15 x 7/8"     300   34156A   Fuel Tark (Ind. 292 & 301) NOTE: These tanks were     500   50665   Screw, 14-15 x 7/8"     301A   410144B   Fuel Cap (White Plastic) (Standard) (Use as required) (1.5"     301A   410144B   Fuel Cap (Red Plastic) (Sput Resistant, Low Profile) (Use as required) (1.5" I.D.)     301A   301A   3302   Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   33032   Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   33210   Mult   <			
277     650729     Screw, 5/16-18 x 3-3/16" (Use as required)       277     651002     Screw, 5/16-18 x 1-4/14" (Use as required)       281     33013     Cover, Starter bubble       285     3362     Hub & Screen Asy.       287     23752     Nut. 1/4-28       290     29774     Fred Line (Braided 51/47)(21 cm)(As required)       291     30705     Fred Line (Braided 167)(40 cm)(As required)       292     29774     Fred Line (Braided 167)(40 cm)(As required)       293     30962     Fred Line (Braided 167)(40 cm)(As required)       294     52640     Fuel Line (Braided 167)(40 cm)(As required)       295     32661     Valve, Fuel shut-off       296     650665     Screw, 1/4-15 x 7/8"       300     34156A     Fuel Tark (Incl. 322 & 301) NOTE: These tanks were builbrith different size fuel intel cap 34210. Tanks with the 1-1/12" LD. opening use fuel cap 34210. Tanks with the 1-1/16". LD. opening use fuel cap 34355.       301A     410144B     Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" LD.)       301A     33032     Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" LD.)       301A     34210			
277   651002   Screw, \$/16-18 x 4-14" (Use as required)     281   33013   Cover, 8-32 x 7/16"     285A   33662   Hub & Screen Assy.     287   29752   Nut, 14/28     290   29774   Fuel Line (Braided 3-1/4")(21cm)(As required)     291   297752   Fuel Line (Braided 22)(80cm)(As required)     292   29460   Fuel Line (Braided 22)(80cm)(As required)     295   29261   Valve, Fuel Shut-off     295   650665   Screw, 14-15 x 78"     300   34156A   Fuel Tank (ncl. 292 & 301) Notice raps with the 1-3/16" I.D. opening use fuel cap 3355.     301A   410144B   Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" I.D.)     301A   33032   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   33032   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   33032   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   33032   Fuel Cap (Red Plastic) (1.75" I.D.)     301A   33032   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A			
281   33013   Cover, Stater bubble     282   650760   Screw, 8-32 x 7/16"     285A   33662   Hub & Screen Assy.     287   29752   Nut, 1/4-28     290   29774   Fuel Line (Braided 32*)(300m)(As required)     291   30705   Fuel Line (Braided 16*)(4/0cm)(As required)     292   22460   Fuel Line (Braided 16*)(4/0cm)(As required)     293   23961   Valve, Fuel shut-off     294   500665   Screw, 1/4-15 x 7/8"     300   34156A   Fuel Cap (Use as required)     294   500665   Screw, 1/4-15 x 7/8"     300   34156A   Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"     301A   3032   Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" I.D.)     301A   33032   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   33033   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   3303   Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" I.D.)     301A   3303   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)			
282     650760     Screw, 8-32 x 7/16"       286A     33662     Hub & Screen Assy.       287     29752     Nut, 1/4-28       290     29774     Fuel Line (Braided 8-1/4')(21cm)(As required)       291     29774     Fuel Line (Braided 8-1/4')(21cm)(As required)       291     29774     Fuel Line (Braided 2-1/4')(21cm)(As required)       292     26440     Fuel Line (Braided 2-1/4')(21cm)(As required)       292     26440     Fuel Line (Braided 2-1/4')(21cm)(As required)       293     30962     Fuel Line (Camp (Use as required)       294     650665     Screw, 1/4-15, x78"       300     34156A     Fuel Tark (trd. 292 & 301) NOTE: These tanks were builtwith different size fuel intel copaning. Tanks with the 1-1/2" I.D. opening use fuel cap 34210. Tanks with the 1-1/2" I.D. opening use fuel cap 34210. Tanks with the 1-1/2" I.D. opening use fuel cap 35355.       301A     410144B     Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" I.D.)       301A     33032     Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)       301A     34210     Fuel Cap (Red Plastic) (1.75" I.D.)       301A     33032     Fuel Cap (Red Plastic) (1.75" I.D.) <td></td> <td></td> <td></td>			
285A   33662   Hub & Screen Assy.     287   29752   Nut, 1/4-28     290   29774   Fuel Line (Braided 8-1/4")(21cm)(As required)     291   30705   Fuel Line (Braided 15")(40cm)(As required)     292   28460   Fuel Line (Braided 15")(40cm)(As required)     292   28460   Fuel Line (Braided 15")(40cm)(As required)     293   650665   Screw, 1/4-15 x 78"     300   34156A   Fuel Tank (Incl. 292 & 301) NOTE: These tanks were builtwith different size fuel inlet openings. Tanks with the 1-3/16" LD. opening use fuel cap 34210. Tanks with the 1-3/16" LD. opening use fuel cap 34355.     301A   410144B   Fuel Cap (White Plastic)(Spurt Resistant, Low Profile) (Use as required) (1.5" LD.)     301A   33032   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" LD.)     301A   33032   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" LD.)     301A   33035   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" LD.)     301A   3303   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" LD.)     301A   3303   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" LD.)     3013   34011A			
287   29752   Nut, 14-28     290   29774   Fuel Line (Braided 8-1/4")(21cm)(As required)     291   30705   Fuel Line (Braided 32")(80cm)(As required)     292   26460   Fuel Line (Braided 32")(80cm)(As required)     295   32961   Valve, Fuel shut-off     296   650665   Screw, 14-15 × 78"     300   34156A   Fuel Tank (Incl. 292 & 301) NOTE: These tanks were builtwith different size fuel cap 34210. Tanks with the 1-1/2" LD, opening use fuel cap 34210. Tanks with the 1-1/2" LD, opening use fuel cap 34210. Tanks with the 1-1/2" LD, opening use fuel cap 34210. Tanks with the 1-1/2" LD, opening use fuel cap 34210. Tanks with the 1-1/2" LD, opening use fuel cap 34210. Tanks with the 1-1/2" LD, opening use fuel cap 34210. Tanks with the 1-1/2" LD, opening use fuel cap 34210. Tanks with the 1-1/2" LD, opening use fuel cap 34210. Tanks with the 1-1/2" LD, opening use fuel cap 34210. Tanks with the 1-1/2" LD, opening use fuel cap 34210. Tanks 34210     301A   3022   Fuel Cap (Red Plastic) (Sput Resistant, Low Profile) (Use as required) (1.5" LD.)     301A   34210   Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" LD.)     301A   34210   Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" LD.)     301A   34210   Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" LD.)     301A   34210   <			
200     29774     Fuel Line (Braided 32")(80cm)(As required)       291     30705     Fuel Line (Braided 32")(80cm)(As required)       222     22460     Fuel Line (Braided 16")(40cm)(As required)       225     32951     Valve, Fuel shut-off       286     650665     Screw, 114-15 x 78"       300     34156A     Fuel Tank (Incl. 329 & 301) NOTE: These tanks were builtwith different size fuel inlet openings. Tanks with the 1-3716" LD. opening use fuel cap 34210. Tanks with the 1-172" LD. opening use fuel cap 34210. Tanks with the 1-172" LD. opening use fuel cap 34210. Tanks with the 1-172" LD. opening use fuel cap 3555.       301A     3032     Fuel Cap (Mvhite Plastic)(Standard) (Use as required) (1.5" LD.)       301A     33032     Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" LD.)       301A     34210     Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" LD.)       301A     35355     Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" LD.)       301A     35355     Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" LD.)       301A     34210     Fuel Cap (Red Plastic) (Anter Standard)       301     34011A     Distick (Incl. 307)       302     Sassss			
200     30982     Fuel Line (Braided 327)(60m)(Ås requ ired)       291     30705     Fuel Line (Braided 167)(40cm)(Ås requ ired)       292     28460     Fuel Line (Braided 167)(40cm)(Ås requ ired)       295     32961     Valve, Fuel shut-off       298     650665     Screw, 14/4 15 × 7/8"       300     34156A     Fuel Tank (Ind. 292 & 301) NOTE: These tanks were builtwith different size fuel inet openings. Tanks with the 1-3/16" I.D. opening use fuel cap 34210. Tanks with the 1-1/2" I.D. opening use fuel cap 3355.       301A     410144B     Fuel Cap (White Plastic)(Standard) (Use as required) (1.5" I.D.)       301A     3032     Fuel Cap (Red Plastic) (Sput Resistant, Low Profile) (Use as required) (1.5" I.D.)       301A     34210     Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" I.D.)       301A     34210     Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" I.D.)       301A     34210     Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" I.D.)       301A     34210     Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" I.D.)       301A     34210     Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" I.D.)       301A     3535			
291   30706   Fuel Line (Erraided 16";40cm)(Ås required)     292   26460   Fuel Line (Line (Damp (Use as required))     293   22641   Valve, Fuel shut-off     298   650665   Screw, 1/4-15 x 7/8"     300   34156A   Fuel Tank (Incl. 292 & 301) NOTE: These tanks were builtwith different size fuel inlet openings. Tanks with the 1-3/16" I.D. opening use fuel cap 34210. Tanks with the 1-1/2" I.D. opening use fuel cap 34210. Tanks with the 1-1/2" I.D. opening use fuel cap 34210.     301A   30032   Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" I.D.)     301A   33032   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   34210   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   3420   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   35355   Fuel Cap (Red Plastic) (1.75" I.D.)     303   3650765   Screw, 10-32 x 3/8"     304   34011A   Dipstick (Incl. 307)     336   650765   Screw, 10-32 x 3/8"     307   33594   Play, Cover     338   31291   Plug, Cover     338   81291   Plate,			
222   26460   Fuel Line Clamp (Use as required)     285   32961   Valve, Fuel shut-off     286   650665   Screw, 14-15 x 7/8"     300   34156A   Fuel Tank (Incl. 292 & 301) NOTE: These tanks were builtwith different size fuel inlet openings. Tanks with the 1-3/16" I.D. opening use fuel cap 34210. Tanks with the 1-1/2" I.D. opening use fuel cap 33355.     301A   410144B   Fuel Cap (White Plastic)(Standard) (Use as required) (1.5" I.D.)     301A   33032   Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" I.D.)     301A   34210   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   34210   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   3555   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   3555   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   3555   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   3555   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   3555   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A <t< td=""><td></td><td></td><td></td></t<>			
285   32961   Valve, Fuel Stui-off     286   650665   Screw, 1/4-15 x 7/8"     300   34156A   Fuel Tank (incl. 292 & 301) NOTE: These tanks were     builtwith different size fuel inlet openings. Tanks with the   1-3/16" LD. opening use fuel cap 34210. Tanks with the     1-12" LD. opening use fuel cap 3335.   301A   410144B     301A   3032   Fuel Cap (Red Plastic) (Standard) (Use as required) (1.5" LD.)     301A   33032   Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" LD.)     301A   34210   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" LD.)     301A   35355   Fuel Cap (Red Plastic) (1.75" LD.)     301A   34210   Fuel Cap (Red Plastic) (1.75" LD.)     305   33893A   Oil Fill Tube     307   33590   'O' Ring     310   340111A   Dipstick (Incl. 307)     366   Screw, 10-32 x 1/2"     383   Stafe     384   Stafe     384   Stafe     384   Stafe     384   Stafe     384   Stafe     38466   Cover, Carburetor <			
298650665Screw, 14-15, 7/8"30034156AFuel Tank (Ind. 292 & 301) NOTE: These tanks were bulkwith different size fuel ap at 34210. Tanks with the 1-3/16" I.D. opening use fuel cap 34210. Tanks with the 1-1/2" I.D. opening use fuel cap 35355.301A410144BFuel Cap (White Plastic)(Standard) (Use as required) (1.5" I.D.)301A33032Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" I.D.)301A34210Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)301A35355Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)301A35356Fuel Cap (Red Plastic) (T.5" I.D.)301A35355Fuel Cap (Red Plastic) (1.75" I.D.)301A35356Fuel Cap (Red Plastic) (1.75" I.D.)301A35350"O" Ring31034011ADipstick (Incl. 307)336650765Screw, 10-32 x 1/2"33734666Cover, Cathuretor33829942Screw, Sens 10-32 x 3/8"34034154Plate, Upper fuel tank mtg.34250561Screw, 14-20 x 5/8"34334141Guard, Starter36650767Screw, 8-32 x 27/64"37034346Decal, Instruction37034346Decal, Instruction37034144Decal, Primer37034144Decal, Primer37034144Decal, Primer37034346Decal, Instruction37034144Decal,	292	26460	Fuel Line Clamp (Use as required)
298650666Screw, 1/4-15, 7/8"30034156AFuel Tank (nd. 292 & 301) NOTE: These tanks were bulkwith different size fuel and topenings. Tanks with the 1-3/16" I.D. opening use fuel cap 34210. Tanks with the 1-1/2" I.D. opening use fuel cap 35355.301A410144BFuel Cap (White Plastic)(Standard) (Use as required) (1.5" I.D.)301A33032Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" I.D.)301A34210Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)301A35355Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)301A35355Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)301A35355Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)301A35356Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)301A35355Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)301A3607355803073580"O" Ring 30731034011ADipstick (Incl. 307)336650765Screw, 10-32 x 1/2"33734666Cover, Cathuretor33829942Screw, 587834034154Plate, Upper fuel tank mtg.34134155Bracket, Lower fuel tank mtg.342650661Screw, 14-20 x 5/8"35934141Guard, Starter366650767Screw, 8-32 x 2	295	32961	Valve, Fuel shut-off
builtwith different size fuel inlet openings. Tanks with the 1-3/16" I.D. opening use fuel cap 34210. Tanks with the 1-1/2" I.D. opening use fuel cap 35355.301A 410144BFuel Cap (White Plastic)(Standard) (Use as required) (1.5" I.D.)301A 33032Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" I.D.)301A 34210Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)301A 35355Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)301A 35355Fuel Cap (Red Plastic)(1.75" I.D.)301A 34011ADipstick (Incl. 307)336 650765Screw, 10-32 x 1/2"337 34666Cover (Carburetor338A 31291Plug, Cover338 28942Screw, Sems 10-32 x 38"340 34154Plate, Upper fuel tank mtg.342 650561Screw, 1/4-20 x 58"355 34141Guard, Starter365 650767Screw, 1/4-20 x 58"370 34346Decal, Instruction370 34346Decal, Instruction370 34346Decal, Instruction370 34346Decal, Instruction370 34346Decal, Primer370 34346Decal, Primer370 34346Decal, Primer370 34346Decal, Primer370 34346Decal, Prime	298	650665	Screw, 1/4-15 x 7/8"
builtwith different size fuel inlet openings. Tanks with the 1-3/16" I.D. opening use fuel cap 34210. Tanks with the 1-1/2" I.D. opening use fuel cap 35355.301A 410144BFuel Cap (White Plastic)(Standard) (Use as required) (1.5" I.D.)301A 33032Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" I.D.)301A 34210Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)301A 35355Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)301A 35355Fuel Cap (Red Plastic)(1.75" I.D.)301A 34011ADipstick (Incl. 307)336 650765Screw, 10-32 x 1/2"337 34666Cover (Carburetor338A 31291Plug, Cover338 28942Screw, Sems 10-32 x 38"340 34154Plate, Upper fuel tank mtg.342 650561Screw, 1/4-20 x 58"355 34141Guard, Starter365 650767Screw, 1/4-20 x 58"370 34346Decal, Instruction370 34346Decal, Instruction370 34346Decal, Instruction370 34346Decal, Instruction370 34346Decal, Primer370 34346Decal, Primer370 34346Decal, Primer370 34346Decal, Primer370 34346Decal, Prime	300	34156A	Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
1-3/16" I.D. opening use fuel cap 34210. Tanks with the 1-1/2" I.D. opening use fuel cap 35355.301A 410144BFuel Cap (White Plastic)(Standard) (Use as required) (1.5" I.D.)301A 33032Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" I.D.)301A 34210Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)301A 35355Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)301A 35355Fuel Cap (Red Plastic) (1.75" I.D.)301A 35355Fuel Cap (Red Plastic) (1.75" I.D.)305 33893AOil Fill Tube307 33590"0" Ring310 34011ADipstick (Incl. 307)336 650765Screw, 10-32 x 1/2"337 34666Cover (Carburetor338A 31291Plug, Cover338 28942Screw, Sems 10-32 x 3/8"340 34154Plate, Upper fuel tank rmg.341 34155Bracket, Lower fuel tank rmg.342 650661Screw, 1/4-20 x 5/8"359 34141Guard, Starter350 34346Decal, Instruction370 34346Decal, Instruction370 34346Decal, Instruction370 34144Decal, Choke370 34144Decal, Choke370 34144Decal, Choke370 34144Decal, Primer370 34144Decal, Primer370 34144Decal, Primer370 34144Decal, Primer370 34144Decal, Primer370 34144Decal, Primer370 34245Corburetor (Incl. 184 & 379) (Refer to Division 5, Section A, p			
1-1/2" I.D. opening use fuel cap 35355.     301A 410144B   Fuel Cap (White Plastic)(Standard) (Use as required) (1.5" I.D.)     301A 33032   Fuel Cap (Red Plastic) (Sput Resistant, Low Profile) (Use as required) (1.5" I.D.)     301A 34210   Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" I.D.)     301A 35355   Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" I.D.)     301A 35355   Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" I.D.)     301A 35355   Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" I.D.)     301A 35355   Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" I.D.)     301A 35350   "0" Ring     307 3354666   Cover, Carburetor     338A 31291   Plug, Cover     338A 31291   Plug, Cover     338A 31291   Plug, Cover     341 34155   Bracket, Lower fuel tank mtg.     342 650561   Screw, 9:32 x 2/2"     343 44155   Bracket, Lower fuel tank mtg.     342 650561   Screw, 8:32 x 2/764"     359 34141   Guard, Starter     356 650767   Screw, 8:32 x 2/764"     370 34346   Decal, Instruction     370 34549			, <b>v</b>
301A   410144B   Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"     301A   33032   Fuel Cap (Red Plastic) (Sput Resistant, Low Profile) (Use as required) (1.5" I.D.)     301A   34210   Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   35355   Fuel Cap (Red Plastic) (Sput Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   35355   Fuel Cap (Red Plastic) (1.75" I.D.)     305   33893A   Oil Fill Tube     307   33590   "0" Ring     310   34011A   Dipstick (In.3 07)     336   650765   Screw, 10-32 x 1/2"     337   34666   Cover, Carburetor     338   31291   Plug, Cover     338   28942   Screw, Sems 10-32 x 3/8"     340   34154   Plate, Upper fuel tank mtg.     341   34155   Bracket, Lower fuel tank mtg.     342   60561   Screw, 3-82 x 27/64"     370   35274   Decal, Instruction     370   35274   Decal, Instruction     370   35101   Carburetor (Ind. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)  <			
301A   33032   Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" I.D.)     301A   34210   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   35355   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     305   33893A   Oil Fill Tube     307   33590   "0" Ring     310   34011A   Dipstick (Incl. 307)     336   666   Cover, Carburetor     338   31291   Plug, Cover     338   28942   Screw, Sems 10-32 x 3/8"     340   34154   Plate, Upper fuel tank mtg.     341   34155   Bracket, Lower fuel tank mtg.     342   Screw, 8-32 x 27/64"   Screw, 8-32 x 27/64"     370   34346   Decal, Instruction     370   34346   Decal, Choke     3700   34144   Decal, Choke     3700   34144   Decal, Choke     3700   34144   Decal, Choke     3700   34144   Decal, Choke     3700   34265   Screw, 8-32 x 27/64"     3700   34263   Decal, C			
301A   33032   Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" I.D.)     301A   34210   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   35355   Fuel Cap (Red Plastic) (1.75" I.D.)     305   33893A   Oli Fill Tube     307   33590   "0" Ring     310   34011A   Dipstick (Incl. 307)     336   650765   Screw, 10-32 x 1/2"     337   34666   Cover, Carburetor     3388   31291   Plug, Cover     338   28942   Screw, Sems 10-32 x 3/8"     340   34154   Plate, Upper fuel tank mtg.     341   34155   Bracket, Lower fuel tank mtg.     342   650561   Screw, 1/4-20 x 5/8"     359   34141   Guard, Starter     365   650767   Screw, 8-32 x 27/64"     370   35274   Decal, Instruction     370   35274   Decal, Instruction     370   35274   Decal, Primer     370   631021   Inlet Needle, Seat & Clip Assy.     380   632110   Carburetor (Incl. 184 & 379) (Refer	301A	410144B	
301A   34210   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   35355   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   35355   Fuel Cap (Red Plastic) (1.75" I.D.)     305   33893A   Oil Fill Tube     307   3360   "0" Ring     310   34011A   Dipstick (Incl. 307)     336   650765   Screw, 10-32 x 1/2"     337   34666   Cover, Carburetor     338A   31291   Plug, Cover     338A   31291   Plug, Cover     338   28942   Screw, Sems 10-32 x 3/8"     340   34154   Plate, Upper fuel tank mtg.     341   34155   Bracket, Lower fuel tank mtg.     342   650561   Screw, 1/4-20 x 5/8"     359   34141   Guard, Stater     366   50767   Screw, 8-32 x 27/64"     370   35274   Decal, Instruction     370   35274   Decal, Choke     3700   34144   Decal, Primer     370   631021   Inlet Needle, Seat & Clip Assy.			I.D.)
301A   34210   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   35355   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   35355   Fuel Cap (Red Plastic) (1.75" I.D.)     305   33893A   Oil Fill Tube     307   3360   "0" Ring     310   34011A   Dipstick (Incl. 307)     336   650765   Screw, 10-32 x 1/2"     337   34666   Cover, Carburetor     338A   31291   Plug, Cover     338A   31291   Plug, Cover     338   28942   Screw, Sems 10-32 x 3/8"     340   34154   Plate, Upper fuel tank mtg.     341   34155   Bracket, Lower fuel tank mtg.     342   650561   Screw, 1/4-20 x 5/8"     359   34141   Guard, Stater     366   50767   Screw, 8-32 x 27/64"     370   35274   Decal, Instruction     370   35274   Decal, Choke     3700   34144   Decal, Primer     370   631021   Inlet Needle, Seat & Clip Assy.	3014	33032	Fuel Can (Red Plastic) (Snurt Resistant I ow Profile) (I lse as
301A   34210   Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)     301A   35355   Fuel Cap (Red Plastic)(1.75" I.D.)     305   33893A   Oil Fill Tube     307   33590   "O" Ring     310   34011A   Dipstick (Incl. 307)     336   650765   Screw, 10-32 x 1/2"     337   34666   Cover, Carburetor     338A   31291   Plug, Cover     338   28942   Screw, Sems 10-32 x 3/8"     340   34154   Plate, Upper fuel tank mtg.     341   34155   Bracket, Lower fuel tank mtg.     342   650561   Screw, 1/4-20 x 5/8"     359   34141   Guard, Starter     356   650767   Screw, 8-32 x 27/64"     370   34346   Decal, Instruction     3700   34246   Decal, Instruction     3700   342489   Decal, Choke     3700   34246   Decal, Instruction     3700   34246   Decal, Instruction     3700   34246   Decal, Choke     3700   34246   Decal, Choke </td <td>50 IA</td> <td>5000Z</td> <td></td>	50 IA	5000Z	
as required) (1.5" I.D.)     301A 35355   Fuel Cap (Red Plastic)(1.75" I.D.)     305 33893A   Oil Fill Tube     307 33590   "O" Ring     310 34011A   Dipstick (Incl. 307)     336 650765   Screw, 10-32 x 1/2"     337 34666   Cover, Carburetor     338A 31291   Plug, Cover     3384 31291   Plute, Upper fuel tank mtg.     340 34154   Plate, Upper fuel tank mtg.     341 34155   Bracket, Lower fuel tank mtg.     342 650561   Screw, 1/4-20 x 5/8"     359 34141   Guard, Starter     356 650767   Screw, 8-32 x 27/64"     370 34246   Decal, Instruction     370 34246   Decal, Instruction     370 34246   Decal, Primer     370 34241   Decal, Primer     379 631021   Inlet Needle, Seat & Clip Assy.     380 632110   Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)     400 33279G   * Gasket Set (Incl. items marked *)     420 730225   SAE 50V30 4-Cycle Engine Oil (Quart)			required) (1.5 1.D.)
301A   35355   Fuel Cap (Red Plastic)(1.75" I.D.)     305   33893A   Oil Fill Tube     307   33590   "O" Ring     310   34011A   Dipstick (Incl. 307)     336   650765   Screw, 10-32 x 1/2"     337   34666   Cover, Carburetor     338A   31291   Plug, Cover     338A   31291   Plate, Upper fuel tank mtg.     340   34154   Plate, Upper fuel tank mtg.     341   34155   Bracket, Lower fuel tank mtg.     342   Screw, 1/4-20 x 5/8"     359   34141   Guard, Starter     365   650767   Screw, 8-32 x 27/64"     370   34346   Decal, Instruction     370   34589   Decal, Choke     3700   34144   Decal, Choke     3700   34144   Decal, Primer     370   3458   Decal, Choke     3700   34144   Decal, Primer     370   34546   Decal, Choke     3700   34144   Decal, Choke     3700   34144   Decal, Primer <td< td=""><td>301A</td><td>34210</td><td>Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use</td></td<>	301A	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
305   33893A   Oil Fill Tube     307   33590   "O" Ring     310   34011A   Dipstick (Incl. 307)     336   650765   Screw, 10-32 x 1/2"     337   34666   Cover, Carburetor     338A   31291   Plug, Cover     338   28942   Screw, Sems 10-32 x 3/8"     340   34154   Plate, Upper fuel tank mtg.     341   34155   Bracket, Lower fuel tank mtg.     342   650561   Screw, 1/4-20 x 5/8"     359   34141   Guard, Starter     365   650767   Screw, 8-32 x 27/64"     370   34346   Decal, Instruction     370   34246   Decal, Instruction     3700   34144   Decal, Choke     3700   34144   Decal, Primer			as required) (1.5" I.D.)
305   33893A   Oil Fill Tube     307   33590   "O" Ring     310   34011A   Dipstick (Incl. 307)     336   650765   Screw, 10-32 x 1/2"     337   34666   Cover, Carburetor     338A   31291   Plug, Cover     338   28942   Screw, Sems 10-32 x 3/8"     340   34154   Plate, Upper fuel tank mtg.     341   34155   Bracket, Lower fuel tank mtg.     342   650561   Screw, 1/4-20 x 5/8"     359   34141   Guard, Starter     365   650767   Screw, 8-32 x 27/64"     370   34346   Decal, Instruction     370   34246   Decal, Instruction     3700   34144   Decal, Choke     3700   34144   Decal, Primer	201 4	25255	Fuel Cap (Red Plastic)(1 75"   D )
307   33590   "O" Ring     310   34011A   Dipstick (Incl. 307)     336   650765   Screw, 10-32 x 1/2"     337   34666   Cover, Carburetor     338A   31291   Plug, Cover     338   28942   Screw, Sems 10-32 x 3/8"     340   34154   Plate, Upper fuel tank mtg.     341   34155   Bracket, Lower fuel tank mtg.     342   650561   Screw, 1/4-20 x 5/8"     359   34141   Guard, Starter     365   650767   Screw, 8-32 x 27/64"     370   3426   Decal, Instruction     370   35274   Decal, Instruction     370   34144   Decal, Primer     370   34144   Decal, Choke     3700   34144   Decal, Primer     3701   34144   Decal, Primer     3702   34589   Decal, Choke     3701   34144   Decal, Primer     3702   31021   Inlet Needle, Seat & Clip Assy.     380   632110   Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)			
310   34011A   Dipstick (Incl. 307)     336   650765   Screw, 10-32 x 1/2"     337   34666   Cover, Carburetor     338A   31291   Plug, Cover     338   28942   Screw, Sems 10-32 x 3/8"     340   34154   Plate, Upper fuel tank mtg.     341   34155   Bracket, Lower fuel tank mtg.     342   650561   Screw, 1/4-20 x 5/8"     359   34141   Guard, Starter     365   650767   Screw, 8-32 x 27/64"     370   34346   Decal, Instruction     370   34346   Decal, Instruction     370   34346   Decal, Choke     3700   34346   Decal, Choke     3701   34144   Decal, Primer     3702   34289   Decal, Choke     3703   35274   Decal, Primer     370   34144   Decal, Primer     3702   34289   Decal, Choke     3701   34144   Decal, Primer     3702   380   632110   Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9			
336   650765   Screw, 10-32 x 1/2"     337   34666   Cover, Carburetor     338A   31291   Plug, Cover     338   28942   Screw, Sems 10-32 x 3/8"     340   34154   Plate, Upper fuel tank mtg.     341   34155   Bracket, Lower fuel tank mtg.     342   650561   Screw, 1/4-20 x 5/8"     359   34141   Guard, Starter     365   650767   Screw, 8-32 x 27/64"     370   34346   Decal, Instruction     370   34346   Decal, Instruction     370   3446   Decal, Choke     3700   3444   Decal, Choke     3700   34144   Decal, Primer     3700   34144   Decal, Primer     3701   34144   Decal, Choke     3702   34589   Decal, Choke     3701   34144   Decal, Primer     3702   34210   Inlet Needle, Seat & Clip Assy.     380   632110   Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)     400   33279G   * Gasket Set (Incl. it			5
337   34666   Cover, Carburetor     338A   31291   Plug, Cover     338   28942   Screw, Sems 10-32 x 3/8"     340   34154   Plate, Upper fuel tank mtg.     341   34155   Bracket, Lower fuel tank mtg.     342   650561   Screw, 1/4-20 x 5/8"     359   34141   Guard, Starter     365   650767   Screw, 8-32 x 27/64"     370   34346   Decal, Instruction     370   3454   Decal, Instruction     3700   34144   Decal, Choke     3700   34144   Decal, Primer     379   631021   Inlet Needle, Seat & Clip Assy.     380   632110   Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)     400   33279G   * Gasket Set (Incl. items marked *)     420   730225   SAE 30 4-Cycle Engine Oil (Quart)     421   730226   SAE 5W30 4-Cycle Engine Oil (Quart)			
338A   31291   Plug, Cover     338   28942   Screw, Sems 10-32 x 3/8"     340   34154   Plate, Upper fuel tank mtg.     341   34155   Bracket, Lower fuel tank mtg.     342   650561   Screw, 1/4-20 x 5/8"     359   34141   Guard, Starter     365   650767   Screw, 8-32 x 27/64"     370   34346   Decal, Instruction     370   3426589   Decal, Choke     3700   34144   Decal, Choke     3700   34144   Decal, Primer     379   631021   Inlet Needle, Seat & Clip Assy.     380   632110   Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)     400   33279G   * Gasket Set (Incl. items marked *)     420   730225   SAE 30 4-Cycle Engine Oil (Quart)     421   730226   SAE 5W30 4-Cycle Engine Oil (Quart)			
338   28942   Screw, Sems 10-32 x 3/8"     340   34154   Plate, Upper fuel tank mtg.     341   34155   Bracket, Lower fuel tank mtg.     342   650561   Screw, 1/4-20 x 5/8"     359   34141   Guard, Starter     365   650767   Screw, 8-32 x 27/64"     370   34346   Decal, Instruction     370   35274   Decal, Instruction     3700   34144   Decal, Choke     3701   34144   Decal, Primer     379   631021   Inlet Needle, Seat & Clip Assy.     380   632110   Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)     400   33279G   * Gasket Set (Incl. items marked *)     420   730225   SAE 30 4-Cycle Engine Oil (Quart)     421   730226   SAE 5W30 4-Cycle Engine Oil (Quart)			
340   34154   Plate, Upper fuel tank mtg.     341   34155   Bracket, Lower fuel tank mtg.     342   650561   Screw, 1/4-20 x 5/8"     359   34141   Guard, Starter     365   650767   Screw, 8-32 x 27/64"     370   34346   Decal, Instruction     370   35274   Decal, Instruction     3700   34144   Decal, Choke     3700   34144   Decal, Primer     379   631021   Inlet Needle, Seat & Clip Assy.     380   632110   Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)     400   33279G   * Gasket Set (Incl. items marked *)     420   730225   SAE 30 4-Cycle Engine Oil (Quart)     421   730226   SAE 5W30 4-Cycle Engine Oil (Quart)	338A	31291	Plug, Cover
341   34155   Bracket, Lower fuel tank mtg.     342   650561   Screw, 1/4-20 x 5/8"     359   34141   Guard, Starter     365   650767   Screw, 8-32 x 27/64"     370   34346   Decal, Instruction     370   35274   Decal, Instruction     3700   34589   Decal, Choke     370D   34144   Decal, Primer     379   631021   Inlet Needle, Seat & Clip Assy.     380   632110   Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)     400   33279G   * Gasket Set (Incl. items marked *)     420   730225   SAE 30 4-Cycle Engine Oil (Quart)     421   730226   SAE 5W30 4-Cycle Engine Oil (Quart)	338	28942	Screw, Sems 10-32 x 3/8"
342   650561   Screw, 1/4-20 x 5/8"     359   34141   Guard, Starter     365   650767   Screw, 8-32 x 27/64"     370   34346   Decal, Instruction     370   35274   Decal, Instruction     370C   34589   Decal, Choke     370D   34144   Decal, Primer     379   631021   Inlet Needle, Seat & Clip Assy.     380   632110   Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)     400   33279G   * Gasket Set (Incl. items marked *)     420   730225   SAE 30 4-Cycle Engine Oil (Quart)     421   730226   SAE 5W30 4-Cycle Engine Oil (Quart)	340	34154	Plate, Upper fuel tank mtg.
359   34141   Guard, Starter     365   650767   Screw, 8-32 x 27/64"     370   34346   Decal, Instruction     370   35274   Decal, Instruction     370C   34589   Decal, Choke     370D   34144   Decal, Primer     379   631021   Inlet Needle, Seat & Clip Assy.     380   632110   Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)     400   33279G   * Gasket Set (Incl. items marked *)     420   730225   SAE 30 4-Cycle Engine Oil (Quart)     421   730226   SAE 5W30 4-Cycle Engine Oil (Quart)	341	34155	Bracket, Lower fuel tank mtg.
359   34141   Guard, Starter     365   650767   Screw, 8-32 x 27/64"     370   34346   Decal, Instruction     370   35274   Decal, Instruction     370C   34589   Decal, Choke     370D   34144   Decal, Primer     379   631021   Inlet Needle, Seat & Clip Assy.     380   632110   Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)     400   33279G   * Gasket Set (Incl. items marked *)     420   730225   SAE 30 4-Cycle Engine Oil (Quart)     421   730226   SAE 5W30 4-Cycle Engine Oil (Quart)	342	650561	Screw, 1/4-20 x 5/8"
365650767Screw, 8-32 x 27/64"37034346Decal, Instruction37035274Decal, Instruction370C34589Decal, Choke370D34144Decal, Primer379631021Inlet Needle, Seat & Clip Assy.380632110Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)40033279G* Gasket Set (Incl. items marked *)420730225SAE 30 4-Cycle Engine Oil (Quart)421730226SAE 5W30 4-Cycle Engine Oil (Quart)			
37034346Decal, Instruction37035274Decal, Instruction370C34589Decal, Choke370D34144Decal, Primer379631021Inlet Needle, Seat & Clip Assy.380632110Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)40033279G* Gasket Set (Incl. items marked *)420730225SAE 30 4-Cycle Engine Oil (Quart)421730226SAE 5W30 4-Cycle Engine Oil (Quart)			•
37035274Decal, Instruction370C34589Decal, Choke370D34144Decal, Primer379631021Inlet Needle, Seat & Clip Assy.380632110Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)40033279G* Gasket Set (Incl. items marked *)420730225SAE 30 4-Cycle Engine Oil (Quart)421730226SAE 5W30 4-Cycle Engine Oil (Quart)			
370C34589Decal, Choke370D34144Decal, Primer379631021Inlet Needle, Seat & Clip Assy.380632110Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)40033279G* Gasket Set (Incl. items marked *)420730225SAE 30 4-Cycle Engine Oil (Quart)421730226SAE 5W30 4-Cycle Engine Oil (Quart)			•
370D34144Decal, Primer379631021Inlet Needle, Seat & Clip Assy.380632110Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)40033279G* Gasket Set (Incl. items marked *)420730225SAE 30 4-Cycle Engine Oil (Quart)421730226SAE 5W30 4-Cycle Engine Oil (Quart)			•
379631021Inlet Needle, Seat & Clip Assy.380632110Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)40033279G* Gasket Set (Incl. items marked *)420730225SAE 30 4-Cycle Engine Oil (Quart)421730226SAE 5W30 4-Cycle Engine Oil (Quart)			•
380632110Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)40033279G* Gasket Set (Incl. items marked *)420730225SAE 30 4-Cycle Engine Oil (Quart)421730226SAE 5W30 4-Cycle Engine Oil (Quart)			•
40033279G* Gasket Set (Incl. items marked *)420730225SAE 30 4-Cycle Engine Oil (Quart)421730226SAE 5W30 4-Cycle Engine Oil (Quart)			
40033279G* Gasket Set (Incl. items marked *)420730225SAE 30 4-Cycle Engine Oil (Quart)421730226SAE 5W30 4-Cycle Engine Oil (Quart)	380	032110	
420730225SAE 30 4-Cycle Engine Oil (Quart)421730226SAE 5W30 4-Cycle Engine Oil (Quart)			page 168 for breakdown or Fiche18B, Grid E-9)
420730225SAE 30 4-Cycle Engine Oil (Quart)421730226SAE 5W30 4-Cycle Engine Oil (Quart)	400	33279G	* Gasket Set (Incl. items marked *)
421 730226 SAE 5W30 4-Cycle Engine Oil (Quart)			
	422		



		Qty	Description
	30322		Nut & Lockwasher, 8-32
	650760		Screw, 8-32 x 3/8"
63	28545		Grommet, Plastic
129	650727		Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131	650737		Screw, 1/4-20 x 1/2" (Use as required )
131	650738		Screw, 1/4-20 x 5/8 (Use as required)
131A	650713		Screw, 5/16-18 x 5/8"
222A			Pop Rivet (Can be purchased locally)
274	35865		Gasket, Exhaust
275	33280A		Muffler
277	650729		Screw, 5/16-18 x 3-3/16" (Use as requ ired)
277	651002		Screw, 5/16-18 x 4-1/4" (Use as required)
285A	33662		Hub & Screen Assy.
290	29774		Fuel Line (Braided 8-1/4")(21cm)(As r equired)
290	30962		Fuel Line (Braided 32")(80cm)(As required)
	26460		Fuel Line Clamp (Use as required)
295	32961		Valve, Fuel shut-off
	650665		Screw, 1/4-15 x 7/8"
	34156A		Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
			builtwith different size fuel inlet openings. Tanks with the
			1-3/16" I.D. opening use fuel cap 34210. Tanks with the
			1-1/2" I.D. opening use fuel cap 35355.
0044			
301A	410144B		Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
			I.D.)
301A	33032		Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
			required) (1.5" I.D.)
0044	0.404.0		
301A	34210		Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
			as required) (1.5" I.D.)
301A	35355		Fuel Cap (Red Plastic)(1.75" I.D.)
	34666		Cover, Carburetor
	31291		Plug, Cover
	34155		Bracket, Lower fuel tank mtg.
	650561		Screw, 1/4-20 x 5/8"
	570682		Primer Assy.
	32180C		Line, Primer
	34144		Decal, Primer
	33323		Opt.Muffler Screen (Mini-Bike applica tion)
	730130		Kit, Exhaust adapter (Incl. 274 & 277 )
	33700		Cover & Tube, Muffler (use as require d)
	650578		Screw, 8-18 x 3/8" (use as required)
	730226		SAE 5W30 4-Cycle Engine Oil (Quart)
	35824		Muffler Optional



	Part Number	Qty	Description
37A	30322		Nut & Lockwasher, 8-32
129	650727		Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131	650737		Screw, 1/4-20 x 1/2" (Use as required )
131	650738		Screw, 1/4-20 x 5/8 (Use as required)
	650713		Screw, 5/16-18 x 5/8"
	34587		Bracket, Choke
	730152		Control Bracket (Incl.1158-1171)(As r eq.)
	31342		Spring, Compression
	650549		Screw, 5-40 x 7/16"
	27793		Clip, Conduit
	28942		Screw, 10-32 x 3/8"
	28820		
	20020		Screw, 10-32 x 1/2"
222A	700407		Pop Rivet (Can be purchased locally)
227	730127		Air Cleaner Ass'y. (Incl. 238, 239, 242, 246, 250) (Use as
			required)
2827	33662		Hub & Screen Assy.
	29774		Fuel Line (Braided 8-1/4")(21cm)(As r equired)
	30962		Fuel Line (Braided 32")(80cm)(As required)
	30705		Fuel Line (Braided 16")(40cm)(As required)
293	33715		Impulse Fuel Pump NOTE: 34385 and 33715 (WIP)pumps
			are replaced by 35813 and 35800 (WIP) pumps. The 33010
			(3000 series) repair kit is still available. The 35791 repair kit
			is used with the 35813 and 35800 fuel pumps.
204	35791		Fuel Pump Repair Kit NOTE: 34385 and 33715 (WIP)pumps
201	00101		are replaced by 35813 and 35800 (WIP) pumps. The 33010
			(3000 series) repair kit is still available. The 35791 repair kit
			is used with the 35813 and 35800 fuel pumps.
301A	410144B		Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
			I.D.)
0014	22020		
301A	33032		Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
			required) (1.5" I.D.)
301A	34210		Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
00177	01210		as required) (1.5" I.D.)
			as required) (1.5 1.D.)
301A	35355		Fuel Cap (Red Plastic)(1.75" I.D.)
303	32958		Fitting, Fuel
	650765		Screw, 10-32 x 1/2"
	34666		Cover, Carburetor
	31291		Plug, Cover
	33377		Bracket, Carburetor cover mtg.
	650767		Screw, 8-32 x 27/64"
	34346		Decal, Instruction
	35274		Decal, Instruction
	34589		
			Decal, Choke
	34144		Decal, Primer
	34414		Decal, Warning
	730226		SAE 5W30 4-Cycle Engine Oil (Quart)
422	35824		Muffler Optional
	30312		Screw, 10-32 x 1/2"
1159			Screw, 10-32 x 1/2"
1159 1160	28820		Screw, 10-32 x 1/2" Lockwasher
1159 1160 1160			Screw, 10-32 x 1/2" Lockwasher Hub & Screen Assy.



		ty Description
1	34922A	Cylinder (Cl liner)(3-5/16")(Incl.2,2 0 & 72)
2	27652	Pin, Dowel
3	650820	Screw, 1/4-20 x 1/2"
37A	30322	Nut & Lockwasher, 8-32
	27642	Plug, Oil drain
	610118	Cover, Spark plug
	650489	Screw, 1/4-20 x 5/8"
	650727	Screw, 5/16-18 x 1-3/4 (Use as required)
	650713	Screw, 5/16-18 x 5/8"
	650737	Screw, 1/4-20 x 1/2" (Use as required )
	650738	Screw, $1/4-20 \times 1/2$ (Use as required)
	27896A	
		* Gasket, Breather
	28423	Body, Breather
	28424	Element, Breather
	28425	Cover, Breather
	35350	Tube, Breather
	650128	Screw, 10-24 x 1/2"
	29752	Nut & Lockwasher, 1/4-28
	33878	Link, Governor lever-to-throttle
222A		Pop Rivet (Can be purchased locally)
275B	391026	Muffler (Incl. 284, 284A & 416) (This spark arrester
		mufflercan be used on any model.)
075	220004	
	33280A	Muffler
	31588	Plate, Muffler locking
	35741	Plate, Muffler locking
	650729	Screw, 5/16-18 x 3-3/16" (Use as requ ired)
	651002	Screw, 5/16-18 x 4-1/4" (Use as requi red)
285A	33662	Hub & Screen Assy.
301A	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
		I.D.)
201 4	22022	Fuel Cap (Bad Plantia) (Sourt Pagistant Law Profile) (Las a
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
		required) (1.5" I.D.)
301A	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
		as required) (1.5" I.D.)
	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
313A	33876	Gasket, Stator (Used only on Std. poi nt ign.)
337	34666	Cover, Carburetor
338A	31291	Plug, Cover
370D	34144	Decal, Primer
375	610848	Magneto (w/ring gear for 120 Volt sta rter) NOTE: The
		complete magneto is not available as an assembly.
		Themagneto number is shown for reference purpose only.
		Order component parts individually, as shown in parts list.
		(Refer to Division 5, Section B, page 28 for breakdown or
		Fiche 18B, Grid F-1
	30547A	Breaker Points (Use with Std. point i gn.)
377	303477	
		Condenser
378	30548B	Condenser Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A.
378		Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A,
378 380	30548B 632110	Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)
378 380	30548B	Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A,