



1	34096C		er (Cl liner)(3-5/16")(Incl.2,20,41,43,72 & 119)
	27652	Pin, Do	
	30700		Governor
	650494		r, 6-40 x 5/16"
15	30699C	Rod A	ssy., Governor (Incl. 15A & 15B)
16	33454	Gover	nor Lever Assy.
17	29916	Clamp	o, Governor lever
18	650548	Screw	r, 8-32 x 5/16"
	32630	Seal, (-
	35256A		r Housing Baffle (With electric starter knockout) (Use
-		as req	•
25	29536	Blowe	r Housing Baffle (Without electric starter knockout)
		(Use a	as required)
	650561		v, 1/4-20 x 5/8"
	33453A		shaft (Incl. 108 & 109)
	29826	Screw	v, 10-32 x 3/4"
36	29918	Lockw	/asher, #8 E.T.
37	29216	Lockn	ut, 10-32
37A	30322	Nut &	Lockwasher, 8-32
38	29642	Ring, I	Retaining
40	34543		n, Pin & Řing Set (Std.) (3-3/16 ")
	34544		, Pin & Ring Set (.010" OS)
	34545		, Pin & Ring Set (.020" OS)
	34031B		& Pin Ass'y. (Std.)(3-3/16")(I ncl.43)
	34032B		& Pin Ass'y. (.010" OS) (Incl. 43)
	34033B		& Pin Ass'y. (.020" OS) (Incl. 43)
	34037		Set (Std.) (3-3/16" Bore)
	34038		Set (.010" OS)
	34039		
	27888		Set (.020" OS)
		•	Piston Pin retaining
	32591C		Assy., Connecting (Incl. 46, 47 & 49)
	650662C		Connecting rod (2 pieces)
	650662C		Connecting rod (2 pieces)
	34034	Lifter, \	
	34242	Dipper	
	34143		haft (MCR)
	33273A		sion, Blower housing
	650760		v, 8-32 x 3/8"
	28545		met, Plastic
	650128		v, 10-24 x 1/2"
	35262		ket, Flange
	33367B		, Cylinder (Incl. 71, 75 & 80)
71	33368		ng, Crankshaft
72	27642	Plug, (Oil drain
75	31950	Seal, (
80	31845	Shaft,	Mechanical governor
81	30590A		er, Flat
	30591		Assy., Governor (Incl. 81)
	30588A		Governor
	29193		Retaining
	650833		v, 1/4-20 x 1-3/16 (Use as requir ed)
	650832		, 1/4-20 x 1-11/16" (Use as required)
	32589		lywheel
			•
	650815 8116		er, Belleville
	8116	Nut, H	
	27276		, Spark plug
103	650489	Screw	v, 1/4-20 x 5/8"

	Part Number 29783	Qty	Description Pin, Crankshaft gear (Only serviceable when gear is pinned to crank.)
			,
	33245		Gear, Crankshaft
110	30831		Ground Wire (Incl. 156)
119	34041A		* Gasket, Cylinder head
120	34030A		Head, Cylinder
125	27878A		Exhaust Valve (Std.) (Incl. 151)
125	27880A		Exhaust Valve (1/32" OS) (Incl. 151)
	34035		Intake Valve (Std.) (Incl. 151)
	34036		Intake Valve (1/32" OS) (Incl. 151)
	650691		Washer (Do not use with No. 6021A scr ew.)
	650690		Washer, Belleville (Use as required)
	650727		Screw, 5/16-18 x 1-3/4 (Use as required)
	6021A		Screw, $5/16-18 \times 1-1/2$ " (Use as required, but do notuse No
130	0021A		650691 washer.)
130	650711		Screw, 5/16-18 x 1-5/8 " (Use as required) (Can use 6021A but discard 650691 washer.)
130	650694A		Screw, 5/16-18 x 2" (Use as required)
	650737		Screw, 1/4-20 x 1/2" (Use as required)
	650738		Screw, 1/4-20 x 5/8 (Use as required)
	650713		Screw, 5/16-18 x 5/8"
	650890		Washer, Internal Lock
	30747		Clip, Spark plug shorting
	33636		Resistor Spark Plug
	33369		
			Bracket, Governor gear
	650836		Screw, 10-24 x 1/2"
	27882		Cap, Upper valve spring
	27881		Spring, Valve
	32581		Cap, Lower valve spring
	27896A		* Gasket, Breather
	28423		Body, Breather
	28424		Element, Breather
172	28425		Cover, Breather
173	35350		Tube, Breather
174	650128		Screw, 10-24 x 1/2"
178	29752		Nut & Lockwasher, 1/4-28
	30088A		Screw, 1/4-28 x 1"
	33263		* Gasket, Carburetor
	33877		Pipe, Intake
	33878		Link, Governor lever-to-throttle
222A			Pop Rivet (Can be purchased locally)
	650378		Screw, Torx T-30, 5/16-18 x 1-1/8"
	27915A		* Gasket, Intake pipe
	33269A		
			Cover, Air cleaner
	33375D		Blower Housing (For electric starter)
	650788 20747D		Screw, 5/16-18 x 3/4"
	29747B		Screw, 5/16-24 x 21/32"
	33272B		Cover, Cylinder head
	35741		Plate, Muffler locking
	650729		Screw, 5/16-18 x 3-3/16" (Use as requ ired)
	651002		Screw, 5/16-18 x 4-1/4" (Use as requi red)
281	33013		Cover, Starter bubble
282	650760		Screw, 8-32 x 7/16"
	33662		Hub & Screen Assy.
	29752		Nut, 1/4-28
	29774		


		Qty Description
	30962	Fuel Line (Braided 32")(80cm)(As requ ired)
	30705	Fuel Line (Braided 16")(40cm)(As requ ired)
	26460	Fuel Line Clamp (Use as required)
	650665	Screw, 1/4-15 x 7/8"
300	34156A	Fuel Tank (Incl. 292 & 301) NOTE: These tanks were builtwith different size fuel inlet openings. Tanks with the 1-3/16" I.D. opening use fuel cap 34210. Tanks with the 1-1/2" I.D. opening use fuel cap 35355.
301A	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5" I.D.)
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as required) (1.5" I.D.)
301A	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)
301A	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
306	29673	* Gasket, Oil filler
310	31297	Dipstick (Incl. 307)
311	27625	Oil Fill Plug (Incl. 312)
312	29673	* Gasket, Oil filler plug
338A	31291	Plug, Cover
340	34154	Plate, Upper fuel tank mtg.
	34155	Bracket, Lower fuel tank mtg.
	650561	Screw, 1/4-20 x 5/8"
	34346	Decal, Instruction
	35274	Decal, Instruction
	631725	Inlet Needle, Seat & Clip Assy.
380	631983	Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page A3-6 for breakdown or Fiche 18B, Grid E-5)
400	33279G	* Gasket Set (Incl. items marked *)
	730225	SAE 30 4-Cycle Engine Oil (Quart)
	730226	SAE 5W30 4-Cycle Engine Oil (Quart)
	35824	Muffler Optional



		Qty	Description
	30322		Nut & Lockwasher, 8-32
	650760		Screw, 8-32 x 3/8"
	28545		Grommet, Plastic
68	33356		Tab, Ground terminal
129	650727		Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131A	650713		Screw, 5/16-18 x 5/8"
131	650737		Screw, 1/4-20 x 1/2" (Use as required)
131	650738		Screw, 1/4-20 x 5/8 (Use as required)
222A			Pop Rivet (Can be purchased locally)
250B	33269A		Cover, Air cleaner
274	35865		Gasket, Exhaust
277	650729		Screw, 5/16-18 x 3-3/16" (Use as requ ired)
277	651002		Screw, 5/16-18 x 4-1/4" (Use as required)
285A	33662		Hub & Screen Assy.
290	29774		Fuel Line (Braided 8-1/4")(21cm)(As r equired)
290	30962		Fuel Line (Braided 32")(80cm)(As requ ired)
292	26460		Fuel Line Clamp (Use as required)
298	650665		Screw, 1/4-15 x 7/8"
300	34156A		Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
			builtwith different size fuel inlet openings. Tanks with the
			1-3/16" I.D. opening use fuel cap 34210. Tanks with the
			1-1/2" I.D. opening use fuel cap 35355.
201 0	410144B		Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
301A	410144D		
			I.D.)
301A	33032		Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
			required) (1.5" I.D.)
201 0	34210		Fuel Can (Pad Diactia) (Spurt Pasistant, High Drafila) (Lisa
301A	34210		Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
			as required) (1.5" I.D.)
301A	35355		Fuel Cap (Red Plastic)(1.75" I.D.)
306	29673		* Gasket, Oil filler
338A	31291		Plug, Cover
341	34155		Bracket, Lower fuel tank mtg.
	650561		Screw, 1/4-20 x 5/8"
414	33323		Opt.Muffler Screen (Mini-Bike applica tion)
	730130		Kit, Exhaust adapter (Incl. 274 & 277)
418	33700		Cover & Tube, Muffler (use as require d)
	650578		Screw, 8-18 x 3/8" (use as required)
	730226		SAE 5W30 4-Cycle Engine Oil (Quart)
	35824		Muffler Optional



		Qty Description
	30322	Nut & Lockwasher, 8-32
129	650727	Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131	650737	Screw, 1/4-20 x 1/2" (Use as required)
131	650738	Screw, 1/4-20 x 5/8 (Use as required)
131A	650713	Screw, 5/16-18 x 5/8"
	730152	Control Bracket (Incl.1158-1171)(As r eq.)
222A		Pop Rivet (Can be purchased locally)
	730127	Air Cleaner Ass'y. (Incl. 238, 239, 242, 246, 250) (Use as
		required)
238	28820	Screw, 10-32 x 1/2"
	27272A	* Gasket, Air cleaner
	33266	Bracket, Air cleaner
	33267	Bracket, Air cleaner
	33268	Element, Air cleaner
	33269A	Cover, Air cleaner
	650513	Nut, Wing 1/4-20
	33662 29774	Hub & Screen Assy.
		Fuel Line (Braided 8-1/4")(21cm)(As r equired)
	30962	Fuel Line (Braided 32")(80cm)(As required)
	30705	Fuel Line (Braided 16")(40cm)(As required)
293	33715	Impulse Fuel Pump NOTE: 34385 and 33715 (WIP)pumps
		are replaced by 35813 and 35800 (WIP) pumps. The 33010
		(3000 series) repair kit is still available. The 35791 repair kit
		is used with the 35813 and 35800 fuel pumps.
294	33010	Fuel Pump Repair Kit NOTE: 34385 and 33715 (WIP)pumps
		are replaced by 35813 and 35800 (WIP) pumps. The 33010
		(3000 series) repair kit is still available. The 35791 repair kit
		is used with the 35813 and 35800 fuel pumps.
294	35791	Fuel Pump Repair Kit NOTE: 34385 and 33715 (WIP)pumps
201		are replaced by 35813 and 35800 (WIP) pumps. The 33010
		(3000 series) repair kit is still available. The 35791 repair kit
		is used with the 35813 and 35800 fuel pumps.
301A	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
		I.D.)
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
		required) (1.5" I.D.)
2014 0	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
501A		
		as required) (1.5" I.D.)
301A	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
303	32958	Fitting, Fuel
	33713	Fitting, Fuel line elbow
	29673	* Gasket, Oil filler
	31291	Plug, Cover
	34346	Decal, Instruction
	35274	Decal, Instruction
	730226	SAE 5W30 4-Cycle Engine Oil (Quart)
	35824	Muffler Optional
	30312	Screw, 10-32 x $1/2$ "
	28820	Screw, 10-32 x 1/2"
	27070	Lockwasher
	33816	Hub & Screen Assy.
1100		



	Part Number	Qty Description
	34096C	Cylinder (CI liner)(3-5/16")(Incl.2,20,41,43,72 & 119)
2	27652	Pin, Dowel
37A	30322	Nut & Lockwasher, 8-32
	27642	Plug, Oil drain
	33450	Lock Nut, 10-32
	30886A	Spring, Governor bolt
	30845A	Bolt, Governor adjusting
101	27276	Cover, Spark plug
	650489	Screw, 1/4-20 x 5/8"
	650727	Screw, 5/16-18 x 1-3/4 (Use as required)
	650737	Screw, 1/4-20 x 1/2" (Use as required)
131	650738	Screw, 1/4-20 x 5/8 (Use as required)
131A	650713	Screw, 5/16-18 x 5/8"
	27896A	* Gasket, Breather
	28423	
		Body, Breather
	28424	Element, Breather
172	28425	Cover, Breather
173	35350	Tube, Breather
	650128	Screw, 10-24 x 1/2"
	29752	
		Nut & Lockwasher, 1/4-28
	33878	Link, Governor lever-to-throttle
222A		Pop Rivet (Can be purchased locally)
238	28820	Screw, 10-32 x 1/2"
	27272A	* Gasket, Air cleaner
	33266	Bracket, Air cleaner
	33267	Bracket, Air cleaner
245	33268	Element, Air cleaner
250B	33269A	Cover, Air cleaner
	650513	Nut, Wing 1/4-20
275B	391026	Muffler (Incl. 284, 284A & 416) (This spark arrester
		mufflercan be used on any model.)
276	35741	Plata Muffler lecking
		Plate, Muffler locking
	650729	Screw, 5/16-18 x 3-3/16" (Use as requ ired)
277	651002	Screw, 5/16-18 x 4-1/4" (Use as requi red)
285A	33662	Hub & Screen Assy.
	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
501A	4101440	
		I.D.)
3014	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
501A	33032	
		required) (1.5" I.D.)
3014	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
501A	34210	
		as required) (1.5" I.D.)
201 \	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
	29673	* Gasket, Oil filler
313A	33876	Gasket, Stator (Used only on Std. poi nt ign.)
338A	31291	Plug, Cover
	610848	Magneto (w/ring gear for 120 Volt sta rter) NOTE: The
515	0100-10	
		complete magneto is not available as an assembly.
		Themagneto number is shown for reference purpose only.
		Order component parts individually, as shown in parts list.
		(Refer to Lilvision 5, Section & Dade 28 for Dreakdowin or
		(Refer to Division 5, Section B, page 28 for breakdown or
		(Refer to Division 5, Section B, page 28 for breakdown or Fiche 18B, Grid F-1
377	305474	Fiche 18B, Grid F-1
	30547A	Fiche 18B, Grid F-1 Breaker Points (Use with Std. point i gn.)
378	30548B	Fiche 18B, Grid F-1 Breaker Points (Use with Std. point i gn.) Condenser
378		Fiche 18B, Grid F-1 Breaker Points (Use with Std. point i gn.)

Ref #	Part Number	Qty	Description
421	730226		SAE 5W30 4-Cycle Engine Oil (Quart)
422	35824		Muffler Optional