


	Part Number Qty	
1	34922A	Cylinder (CI liner)(3-5/16")(Incl.2,2 0 & 72)
2	27652	Pin, Dowel
	650820	Screw, 1/4-20 x 1/2"
	32678	Nipple, Oil drain
	30969	Cap, Oil drain
15B	650494	Screw, 6-40 x 5/16"
15A	30700	Yoke, Governor
	30699C	Rod Assy., Governor (Incl. 15A & 15B)
	33454	Governor Lever Assy.
	29916	Clamp, Governor lever
18	650548	Screw, 8-32 x 5/16"
20	32630	Seal, Oil
	29536	Blower Housing Baffle (Without electric starter knockout)
20	20000	(Use as required)
25	35256A	Blower Housing Baffle (With electric starter knockout) (Use
		as required)
26	650561	Screw, 1/4-20 x 5/8"
30	33365B	Crankshaft (Incl. 108 & 109)
	29826	Screw, 10-32 x 3/4"
	29918	Lockwasher, #8 E.T.
	30322	Nut & Lockwasher, 8-32
37	29216	Locknut, 10-32
38	29642	Ring, Retaining
	34860A	Piston, Pin & Ring Set (Std.)(3-5/16")
	34861A	Piston, Pin & Ring Set (.010" OS)
	34862A	Piston, Pin & Ring Set (.020" OS)
41	34863	Piston & Pin Ass'y. (Std.)(3-5/16")(I ncl.43)
41	34864	Piston & Pin Ass'y. (.010" OS) (Incl. 43)
41	34865	Piston & Pin Ass'y. (.020" OS) (Incl. 43)
	34866A	Ring Set (Std.) (3-5/16" Bore)
	34867A	Ring Set (.010" OS)
42	34868A	Ring Set (.020" OS)
43	27888	Ring, Piston Pin retaining
45	32591C	Rod Assy., Connecting (Incl. 46, 47 & 49)
	650662C	Bolt, Connecting rod (2 pieces)
	650662C	Bolt, Connecting rod (2 pieces)
48	34034	Lifter, Valve
49	34242	Dipper, Oil
	34143	Camshaft (MCR)
	33273A	Extension, Blower housing
	34126	Bracket, Grommet mounting
62	650760	Screw, 8-32 x 3/8"
63	28545	Grommet, Plastic
	650128	Screw, 10-24 x 1/2"
	35262	
		* Gasket, Flange
	33367B	Cover, Cylinder (Incl. 71, 75 & 80)
71	33368	Bushing, Crankshaft
72	27642	Plug, Oil drain
	31950	Seal, Oil
	31845	Shaft, Mechanical governor
	30590A	Washer, Flat
82	30591	Gear Assy., Governor (Incl. 81)
	30588A	Spool, Governor
		•
84	29193	Ring, Retaining
		Sorow $1/1.00 \times 1.0/16$ (Lloo on roquir od)
86	650833	Screw, 1/4-20 x 1-3/16 (Use as requir ed)
86	650832	Screw, 1/4-20 x 1-3/16 (Use as required) Screw, 1/4-20 x 1-11/16" (Use as required)


		ty Description
92	650815	Washer, Belleville
93	8116	Nut, Hex
	610118	Cover, Spark plug
	650516	Screw, 1/4-20 x 1-1/8"
	29783	Pin, Crankshaft gear (Only serviceable when gear is pinned
100	23/05	to crank.)
109	33245	Gear, Crankshaft
110	34240	Ground Wire
119	34923A	* Gasket, Cylinder head
120	34030A	Head, Cylinder
	27878A	Exhaust Valve (Std.) (Incl. 151)
	27880A	Exhaust Valve (1/32" OS) (Incl. 151)
	34035	Intake Valve (Std.) (Incl. 151)
	34036	Intake Valve (1/32" OS) (Incl. 151)
	650691	Washer (Do not use with No. 6021A scr ew.)
	650690	Washer, Belleville (Use as required)
	650727	Screw, 5/16-18 x 1-3/4 (Use as required)
130	6021A	Screw, 5/16-18 x 1-1/2" (Use as required, but do notuse No. 650691 washer.)
130	650711	, Screw, 5/16-18 x 1-5/8 " (Use as required) (Can use 6021A
		but discard 650691 washer.)
130	650694A	Screw, 5/16-18 x 2" (Use as required)
	650713	Screw, 5/16-18 x 5/8"
	650737	Screw, 1/4-20 x 1/2" (Use as required )
	650738	Screw, $1/4-20 \times 5/8$ (Use as required)
	650890	Washer, Internal Lock
	33636	Resistor Spark Plug
	33369	Bracket, Governor gear
	650836	Screw, 10-24 x $1/2$ "
	35862	Seal Assy., Intake valve
	27881	Spring, Valve
	32581	Cap, Lower valve spring
	27896A	* Gasket, Breather
	28423	Body, Breather
	28424	Element, Breather
	28425	Cover, Breather
	35350	Tube, Breather
	650128	Screw, 10-24 x 1/2"
	29752	Nut & Lockwasher, 1/4-28
182	30088A	Screw, 1/4-28 x 1"
183	34587	Bracket, Choke
	33263	* Gasket, Carburetor
	33877	Pipe, Intake
	34667	Link, Governor lever
	34664	Control Bracket (Incl.19,203, 204, 20 6 & 209)
	31342	Spring, Compression
	650549	Screw, 5-40 x 7/16"
	610973	Terminal Assy.
	33878	Link, Governor lever-to-throttle
	650821	Screw, 10-32 x 1/2"
	27793	Clip, Conduit
211	28942	Screw, 10-32 x 3/8"
	34586	Rod, Choke
219		
219 220	35438	Knob, Control
219 220		

	Part Number	Qty	Description
	650378		Screw, Torx T-30, 5/16-18 x 1-1/8"
224	27915A		* Gasket, Intake pipe
260	34822A		Blower Housing
261	650788		Screw, 5/16-18 x 3/4"
	29747B		Screw, 5/16-24 x 21/32"
	33272B		Cover, Cylinder head
	33280A		Muffler
	31588		Plate, Muffler locking
	35741		Plate, Muffler locking
277	650729		Screw, 5/16-18 x 3-3/16" (Use as requ ired)
277	651002		Screw, 5/16-18 x 4-1/4" (Use as required)
281	33013		Cover, Starter bubble
	650760		Screw, 8-32 x 7/16"
	33662		Hub & Screen Assy.
	29752		Nut, 1/4-28
	29774		Fuel Line (Braided 8-1/4")(21cm)(As r equired)
	30962		Fuel Line (Braided 32")(80cm)(As required)
291	30705		Fuel Line (Braided 16")(40cm)(As required)
	26460		Fuel Line Clamp (Use as required)
	650665		Screw, 1/4-15 x 7/8"
	34156A		Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
500	541507		
			builtwith different size fuel inlet openings. Tanks with the
			1-3/16" I.D. opening use fuel cap 34210. Tanks with the
			1-1/2" I.D. opening use fuel cap 35355.
3014	410144B		Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
50 IA	-101 <del>-1</del> 0		I.D.)
301A	33032		Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use a
			required) (1.5" I.D.)
201 4	04040		Fuel Car (Ded Diastic) (Crunt Desistant Llink Profile) (Llas
301A	34210		Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
			as required) (1.5" I.D.)
3014	35355		Fuel Cap (Red Plastic)(1.75" I.D.)
	33893A		Oil Fill Tube
	33590		"O" Ring
310	34011A		Dipstick (Incl. 307)
336	650765		Screw, 10-32 x 1/2"
337	34666		Cover, Carburetor
	31291		Plug, Cover
	28942		Screw, Sems 10-32 x 3/8"
	34154		Plate, Upper fuel tank mtg.
	34155		Bracket, Lower fuel tank mtg.
342	650561		Screw, 1/4-20 x 5/8"
359	34141		Guard, Starter
	32576		Seal, Snow Guard
	650767		Screw, 8-32 x 27/64"
	34346		Decal, Instruction
	35274		Decal, Instruction
	34170		Decal, Instruction
370C	34589		Decal, Choke
	34144		Decal, Primer
	631021		Inlet Needle, Seat & Clip Assy.
370D			Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A,
370D 379			Calburelo (IIIC), 104 & 3731 (Relet to DIVISION 3, Section A.
370D 379	632110		page 168 for breakdown or Fiche18B, Grid E-9)
370D 379 380	632110		page 168 for breakdown or Fiche18B, Grid E-9)
370D 379 380 400	632110 33279G		page 168 for breakdown or Fiche18B, Grid E-9) * Gasket Set (Incl. items marked *)
370D 379 380 400 420	632110		page 168 for breakdown or Fiche18B, Grid E-9)


Ref # P	ar Numper Un	Description
		Decomption
422 3	5824	Muffler Optional



			Description
37A	30322		lut & Lockwasher, 8-32
62	650760	S	Screw, 8-32 x 3/8"
63	28545	G	Grommet, Plastic
	650727	S	Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131A	650713	S	Screw, 5/16-18 x 5/8"
131	650737	S	Screw, 1/4-20 x 1/2" (Use as required )
131	650738	S	Screw, 1/4-20 x 5/8 (Use as required)
222A		P	op Rivet (Can be purchased locally)
274	35865		Gasket, Exhaust
275	33280A	Μ	<i>luffler</i>
277	650729	S	Screw, 5/16-18 x 3-3/16" (Use as requ ired)
277	651002	S	Screw, 5/16-18 x 4-1/4" (Use as requi red)
285A	33662	Н	lub & Screen Assy.
290	29774	Fu	uel Line (Braided 8-1/4")(21cm)(As r equired)
290	30962	Fu	uel Line (Braided 32")(80cm)(As requ ired)
292	26460	Fu	uel Line Clamp (Use as required)
298	650665	S	Screw, 1/4-15 x 7/8"
300	34156A	Fu	uel Tank (Incl. 292 & 301) NOTE: These tanks were
		bu	uiltwith different size fuel inlet openings. Tanks with the
			-3/16" I.D. opening use fuel cap 34210. Tanks with the
			-1/2" I.D. opening use fuel cap 35355.
201 4	4101440	г.	ivel Cap (M/bita Diastia)(Standard) (Lias as required) (1 5"
301A	410144B		uel Cap (White Plastic)(Standard) (Use as required) (1.5"
		1.1	D.)
301A	33032	Fu	uel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
			equired) (1.5" I.D.)
201 4	24240	г.	ual Can (Dad Daatia) (Sourt Daaistant Lligh Drofila) (Llaa
301A	34210		uel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
		as	s required) (1.5" I.D.)
301A	35355	Fu	uel Cap (Red Plastic)(1.75" I.D.)
337	34666		Cover, Carburetor
338A	31291	PI	Plug, Cover
	34155		bracket, Lower fuel tank mtg.
	650561		Screw, 1/4-20 x 5/8"
	570682		Primer Assy.
	32180C		ine, Primer
	34144		Decal, Primer
	33323		Opt.Muffler Screen (Mini-Bike applica tion)
	730130		(it, Exhaust adapter (Incl. 274 & 277)
	33700		Cover & Tube, Muffler (use as require d)
	650578		Screw, 8-18 x 3/8" (use as required)
	730226		SAE 5W30 4-Cycle Engine Oil (Quart)
	35824		Auffler Optional



		Qty Description
37A	30322	Nut & Lockwasher, 8-32
129	650727	Screw, 5/16-18 x 1-3/4 (Use as requir ed)
	650737	Screw, 1/4-20 x 1/2" (Use as required )
	650738	Screw, 1/4-20 x 5/8 (Use as required)
	650713	Screw, 5/16-18 x 5/8"
	34587	Bracket, Choke
	730152	•
		Control Bracket (Incl.1158-1171)(As r eq.)
	31342	Spring, Compression
	650549	Screw, 5-40 x 7/16"
	27793	Clip, Conduit
	28942	Screw, 10-32 x 3/8"
222	28820	Screw, 10-32 x 1/2"
222A		Pop Rivet (Can be purchased locally)
227	730127	Air Cleaner Ass'y. (Incl. 238, 239, 242, 246, 250) (Use as
		required)
	33662	Hub & Screen Assy.
	29774	Fuel Line (Braided 8-1/4")(21cm)(As r equired)
	30962	Fuel Line (Braided 32")(80cm)(As requ ired)
291	30705	Fuel Line (Braided 16")(40cm)(As requ ired)
293	33715	Impulse Fuel Pump NOTE: 34385 and 33715 (WIP)pumps
		are replaced by 35813 and 35800 (WIP) pumps. The 33010
		(3000 series) repair kit is still available. The 35791 repair kit
		is used with the 35813 and 35800 fuel pumps.
294	35791	Fuel Pump Repair Kit NOTE: 34385 and 33715 (WIP)pump
		are replaced by 35813 and 35800 (WIP) pumps. The 33010
		(3000 series) repair kit is still available. The 35791 repair ki
		is used with the 35813 and 35800 fuel pumps.
201 4	4404.440	
301A	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
		I.D.)
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use a
0017	00002	required) (1.5" I.D.)
301A	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
		as required) (1.5" I.D.)
0044	25255	
	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
	32958	Fitting, Fuel
	650765	Screw, 10-32 x 1/2"
	34666	Cover, Carburetor
338A	31291	Plug, Cover
	33377	Bracket, Carburetor cover mtg.
	650767	Screw, 8-32 x 27/64"
	34346	Decal, Instruction
	35274	Decal, Instruction
	34170	Decal, Instruction
	34589	
		Decal, Choke
	34144	Decal, Primer
	34414	Decal, Warning
	730226	SAE 5W30 4-Cycle Engine Oil (Quart)
422	35824	Muffler Optional
1159	30312	Screw, 10-32 x 1/2"
	28820	Screw, 10-32 x 1/2"
	27070	Lockwasher
1100		
1185	33816	Hub & Screen Assy.



	Part Number Qt	
1	34922A	Cylinder (CI liner)(3-5/16")(Incl.2,2 0 & 72)
2	27652	Pin, Dowel
3	650820	Screw, 1/4-20 x 1/2"
37A	30322	Nut & Lockwasher, 8-32
72	27642	Plug, Oil drain
	610118	Cover, Spark plug
	650516	Screw, 1/4-20 x 1-1/8"
	650727	Screw, 5/16-18 x 1-3/4 (Use as required)
	650713	Screw, 5/16-18 x 5/8"
	650737	Screw, 1/4-20 x 1/2" (Use as required )
	650738	Screw, $1/4-20 \times 1/2$ (Use as required)
	27896A	* Gasket, Breather
	28423	Body, Breather
	28424	Element, Breather
	28425	Cover, Breather
	35350	Tube, Breather
	650128	Screw, 10-24 x 1/2"
	29752	Nut & Lockwasher, 1/4-28
	33878	Link, Governor lever-to-throttle
222A		Pop Rivet (Can be purchased locally)
275B	391026	Muffler (Incl. 284, 284A & 416) (This spark arrester
		mufflercan be used on any model.)
075	22000.4	N 4. 40
	33280A	Muffler
	31588	Plate, Muffler locking
	35741	Plate, Muffler locking
	650729	Screw, 5/16-18 x 3-3/16" (Use as requ ired)
	651002	Screw, 5/16-18 x 4-1/4" (Use as requi red)
285A	33662	Hub & Screen Assy.
301A	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
		I.D.)
201 4	22022	Fuel Con (Dod Dipatio) (Court Desigtant Low Drofile) (Line o
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use a
		required) (1.5" I.D.)
301A	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
00111	0.2.10	as required) (1.5" I.D.)
301A	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
313A	33876	Gasket, Stator (Used only on Std. poi nt ign.)
337	34666	Cover, Carburetor
338A	31291	Plug, Cover
370D	34144	Decal, Primer
	610982	Magneto (w/ring gear) (12 Volt, 3 Amp ) NOTE: The
0.0		complete magneto is not available as an assembly.
		Themagneto number is shown for reference purpose only.
		Order component parts individually, as shown in parts list.
		(Refer to Division 5, Section B, page 36 for breakdown or
		Fiche 18B, Grid F-3
	30547A	Breaker Points (Use with Std. point i gn.)
377	610767A	Condenser
378		Carburetor (Incl. 184 & 370) (Refer to Division 5 Section A
378	632110	Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A,
378		Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 168 for breakdown or Fiche18B, Grid E-9)
378 380		