



		ty Description
1	34096C	Cylinder (CI liner)(3-5/16")(Incl.2,20,41,43,72 & 119)
2	27652	Pin, Dowel
4	30968	Nipple, Oil drain
5	30969	Cap, Oil drain
15	30699C	Rod Assy., Governor (Incl. 15A & 15B)
	30700	Yoke, Governor
	650494	Screw, 6-40 x 5/16"
	33454	Governor Lever Assy.
	29916	•
		Clamp, Governor lever
	650548	Screw, 8-32 x 5/16"
	32630	Seal, Oil
25	29536	Blower Housing Baffle (Without electric starter knockout)
		(Use as required)
25	35256A	Blower Housing Baffle (With electric starter knockout) (Use
25	30200A	•
		as required)
26	650561	Screw, 1/4-20 x 5/8"
30	33459A	Crankshaft (Incl. 108 & 109)
	29826	Screw, 10-32 x 3/4"
	29918	Lockwasher, #8 E.T.
	30322	Nut & Lockwasher, 8-32
	29216	Locknut, 10-32
	29642	Ring, Retaining
	34543	Piston, Pin & Ring Set (Std.) (3-3/16 ")
	34544	Piston, Pin & Ring Set (.010" OS)
	34545	Piston, Pin & Ring Set (.020" OS)
	34031B	Piston & Pin Ass'y. (Std.)(3-3/16")(I ncl.43)
41	34032B	Piston & Pin Ass'y. (.010" OS) (Incl. 43)
41	34033B	Piston & Pin Ass'y. (.020" OS) (Incl. 43)
42	34037	Ring Set (Std.) (3-3/16" Bore)
42	34038	Ring Set (.010" OS)
42	34039	Ring Set (.020" OS)
	27888	Ring, Piston Pin retaining
	32591C	Rod Assy., Connecting (Incl. 46, 47 & 49)
	650662C	Bolt, Connecting rod (2 pieces)
	650662C	Bolt, Connecting rod (2 pieces)
	34034	Lifter, Valve
	34242	
		Dipper, Oil
	34143	Camshaft (MCR)
	33273A	Extension, Blower housing
	34126	Bracket, Grommet mounting
	650760	Screw, 8-32 x 3/8"
	28545	Grommet, Plastic
	650128	Screw, 10-24 x 1/2"
	35262	* Gasket, Flange
70	33367B	Cover, Cylinder (Incl. 71, 75 & 80)
71	33368	Bushing, Crankshaft
72	27642	Plug, Oil drain
75	31950	Seal, Oil
	31845	Shaft, Mechanical governor
	30590A	Washer, Flat
	30591	Gear Assy., Governor (Incl. 81)
	30588A	Spool, Governor
	29193	Ring, Retaining
		• •
	650833	Screw, 1/4-20 x 1-3/16 (Use as required)
	650832 22590	Screw, 1/4-20 x 1-11/16" (Use as required)
	32589	Key, Flywheel
92	650815	Washer, Belleville

	Part Number Qty 8116	7 Description Nut, Hex
	610118	Cover, Spark plug
	650489	Screw, 1/4-20 x 5/8"
	29783	
100	29705	Pin, Crankshaft gear (Only serviceable when gear is pinned to crank.)
	33245	Gear, Crankshaft
	34240	Ground Wire
	34041A	* Gasket, Cylinder head
	34030A	Head, Cylinder
	27878A	Exhaust Valve (Std.) (Incl. 151)
	27880A	Exhaust Valve (1/32" OS) (Incl. 151)
	34035	Intake Valve (Std.) (Incl. 151)
	34036	Intake Valve (1/32" OS) (Incl. 151)
	650691	Washer (Do not use with No. 6021A scr ew.)
128	650690	Washer, Belleville (Use as required)
129	650727	Screw, 5/16-18 x 1-3/4 (Use as requir ed)
130	6021A	Screw, 5/16-18 x 1-1/2" (Use as required, but do notuse No
		650691 washer.)
130	650711	Screw, 5/16-18 x 1-5/8 " (Use as required) (Can use 6021A
		but discard 650691 washer.)
	650694A	Screw, 5/16-18 x 2" (Use as required)
	650713	Screw, 5/16-18 x 5/8"
	650737	Screw, 1/4-20 x 1/2" (Use as required )
	650738	Screw, 1/4-20 x 5/8 (Use as required)
	650890	Washer, Internal Lock
	33636	Resistor Spark Plug
	33369	Bracket, Governor gear
	650836	Screw, 10-24 x 1/2"
	27882	Cap, Upper valve spring
	27881	Spring, Valve
	32581	Cap, Lower valve spring
	27896A	* Gasket, Breather
	28423	Body, Breather
171	28424	Element, Breather
172	28425	Cover, Breather
173	35350	Tube, Breather
174	650128	Screw, 10-24 x 1/2"
178	29752	Nut & Lockwasher, 1/4-28
182	30088A	Screw, 1/4-28 x 1"
	34587	Bracket, Choke
184	33263	* Gasket, Carburetor
	33877	Pipe, Intake
186	33371	Link, Governor lever
203	31342	Spring, Compression
204	650549	Screw, 5-40 x 7/16"
206	610973	Terminal Assy.
	33878	Link, Governor lever-to-throttle
	27793	Clip, Conduit
	28942	Screw, 10-32 x 3/8"
	34586	Rod, Choke
	35438	Knob, Control
	28820	Screw, 10-32 x 1/2"
222A		Pop Rivet (Can be purchased locally)
	650378	Screw, Torx T-30, 5/16-18 x 1-1/8"
223		
	27915A	* Gasket, Intake pipe


	Part Number	Qty	Description
	650788		Screw, 5/16-18 x 3/4"
	29747B		Screw, 5/16-24 x 21/32"
	33272B		Cover, Cylinder head
	34185A		Muffler
276	31588		Plate, Muffler locking
	35741		Plate, Muffler locking
	650729		Screw, 5/16-18 x 3-3/16" (Use as required)
	651002		Screw, 5/16-18 x 4-1/4" (Use as required)
	33013		Cover, Starter bubble
	650760		Screw, 8-32 x 7/16"
	33662		Hub & Screen Assy.
	29752		Nut, 1/4-28
	29774		Fuel Line (Braided 8-1/4")(21cm)(As r equired)
	30962		Fuel Line (Braided 32")(80cm)(As requ ired)
291	30705		Fuel Line (Braided 16")(40cm)(As requ ired)
292	26460		Fuel Line Clamp (Use as required)
295	32961		Valve, Fuel shut-off
	650665		Screw, 1/4-15 x 7/8"
	34160A		Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
000	04100/1		builtwith different size fuel inlet openings. Tanks with the
			1-3/16" I.D. opening use fuel cap 34210. Tanks with the
			1-1/2" I.D. opening use fuel cap 35355.
301A	410144B		Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
00171			
301A	33032		Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use a
			required) (1.5" I.D.)
3 <b>∩1</b> ∆	34210		Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
30 IA	34210		as required) (1.5" I.D.)
			as required) (1.5 1.D.)
301A	35355		Fuel Cap (Red Plastic)(1.75" I.D.)
	29673		* Gasket, Oil filler
	31297		Dipstick (Incl. 307)
	650765		Screw, 10-32 x 1/2"
	34140		Cover, Carburetor
	31291		Plug, Cover
	28942		Screw, Sems 10-32 x 3/8"
	34154		Plate, Upper fuel tank mtg.
341	34155		Bracket, Lower fuel tank mtg.
342	650561		Screw, 1/4-20 x 5/8"
	34141		Guard, Starter
	32576		Seal, Snow Guard
	650767		Screw, 8-32 x 27/64"
			Decal, Instruction
	35274		
	631021		Inlet Needle, Seat & Clip Assy.
380	632110		Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A,
			page 168 for breakdown or Fiche18B, Grid E-9)
			* Gasket Set (Incl. items marked *)
100	337700		
	33279G		
420	730225		SAE 30 4-Cycle Engine Oil (Quart)
420 421			



		 Description
37A	30322	Nut & Lockwasher, 8-32
62	650760	Screw, 8-32 x 3/8"
63	28545	Grommet, Plastic
129	650727	Screw, 5/16-18 x 1-3/4 (Use as required)
131A	650713	Screw, 5/16-18 x 5/8"
131	650737	Screw, 1/4-20 x 1/2" (Use as required )
131	650738	Screw, 1/4-20 x 5/8 (Use as required)
222A		Pop Rivet (Can be purchased locally)
274	35865	Gasket, Exhaust
275	34185A	Muffler
	650729	Screw, 5/16-18 x 3-3/16" (Use as required)
	651002	Screw, 5/16-18 x 4-1/4" (Use as required)
	33662	Hub & Screen Assy.
	29774	Fuel Line (Braided 8-1/4")(21cm)(As r equired)
	30962	Fuel Line (Braided 32")(80cm)(As required)
	26460	Fuel Line Clamp (Use as required)
	32961	Valve, Fuel shut-off
	650665	Screw, 1/4-15 x 7/8"
	34160A	Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
		builtwith different size fuel inlet openings. Tanks with the
		1-3/16" I.D. opening use fuel cap 34210. Tanks with the
		1-1/2" I.D. opening use fuel cap 35355.
00/4		
301A	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
		I.D.)
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
		required) (1.5" I.D.)
0044	0.404.0	
301A	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
		as required) (1.5" I.D.)
301A	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
	29673	* Gasket, Oil filler
	34140	Cover, Carburetor
	31291	Plug, Cover
	34155	Bracket, Lower fuel tank mtg.
	650561	Screw, 1/4-20 x 5/8"
	570629A	Primer Assy.
	32180C	Line, Primer
	33323	Opt.Muffler Screen (Mini-Bike applica tion)
	730130	Kit, Exhaust adapter (Incl. 274 & 277 )
	33700	Cover & Tube, Muffler (use as require d)
	650578	Screw, 8-18 x 3/8" (use as required)
	730226	SAE 5W30 4-Cycle Engine Oil (Quart)
	35824	
<u>A</u> .).)	.3.10/4	Muffler Optional



Ref #	Part Number C	ty Description
37A	30322	Nut & Lockwasher, 8-32
129	650727	Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131A	650713	Screw, 5/16-18 x 5/8"
131	650737	Screw, 1/4-20 x 1/2" (Use as required )
131	650738	Screw, 1/4-20 x 5/8 (Use as required)
183	34587	Bracket, Choke
	730152	Control Bracket (Incl.1158-1171)(As r eq.)
	33461A	Control Bracket (Incl. 19, 203, 204 & 206)
	31342	Spring, Compression
	650549	Screw, 5-40 x 7/16"
	27793	Clip, Conduit
	28942	Screw, 10-32 x 3/8"
	28820	Screw, 10-32 x 1/2"
222A		Pop Rivet (Can be purchased locally)
	730127	Air Cleaner Ass'y. (Incl. 238, 239, 242, 246, 250) (Use as
	100121	required)
0054	22000	
	33662	Hub & Screen Assy.
	29774	Fuel Line (Braided 8-1/4")(21cm)(As r equired)
	30962	Fuel Line (Braided 32")(80cm)(As required)
	30705	Fuel Line (Braided 16")(40cm)(As required)
293	33715	Impulse Fuel Pump NOTE: 34385 and 33715 (WIP)pumps
		are replaced by 35813 and 35800 (WIP) pumps. The 33010
		(3000 series) repair kit is still available. The 35791 repair kit
		is used with the 35813 and 35800 fuel pumps.
294	35791	Fuel Pump Repair Kit NOTE: 34385 and 33715 (WIP)pumps
		are replaced by 35813 and 35800 (WIP) pumps. The 33010
		(3000 series) repair kit is still available. The 35791 repair kit
		is used with the 35813 and 35800 fuel pumps.
204.4	4404.440	
301A	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
		I.D.)
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
		required) (1.5" I.D.)
3014	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
001/1	01210	as required) (1.5" I.D.)
	05055	
	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
	32958	Fitting, Fuel
	29673	* Gasket, Oil filler
	650765	Screw, 10-32 x 1/2"
	34140	Cover, Carburetor
	31291	Plug, Cover
	33377	Bracket, Carburetor cover mtg.
	650767	Screw, 8-32 x 27/64"
	35274	Decal, Instruction
421	730226	SAE 5W30 4-Cycle Engine Oil (Quart)
422	35824	Muffler Optional
1158	33374	Spring Extension
	30312	Ścrew, 10-32 x 1/2"
	28820	Screw, 10-32 x 1/2"
	27070	Lockwasher
	33816	Hub & Screen Assy.
		,



		y Description
	34096C	Cylinder (Cl liner)(3-5/16")(Incl.2,20,41,43,72 & 119)
	27652	Pin, Dowel
37A	30322	Nut & Lockwasher, 8-32
72	27642	Plug, Oil drain
101	610118	Cover, Spark plug
	650489	Screw, 1/4-20 x 5/8"
	650727	Screw, 5/16-18 x 1-3/4 (Use as requir ed)
	650713	Screw, 5/16-18 x 5/8"
	650737	Screw, 1/4-20 x 1/2" (Use as required )
	650738	Screw, 1/4-20 x 5/8 (Use as required)
	27896A	* Gasket, Breather
	28423	Body, Breather
	28424	Element, Breather
	28425	Cover, Breather
	35350	
		Tube, Breather
	650128	Screw, 10-24 x 1/2"
	29752	Nut & Lockwasher, 1/4-28
	33878	Link, Governor lever-to-throttle
222A	00/000	Pop Rivet (Can be purchased locally)
275B	391026	Muffler (Incl. 284, 284A & 416) (This spark arrester
		mufflercan be used on any model.)
275	34185A	Muffler
	31588	Plate, Muffler locking
	35741	Plate, Muffler locking
	650729	Screw, 5/16-18 x 3-3/16" (Use as required)
	651002	Screw, 5/16-18 x 4-1/4" (Use as required)
	33662	Hub & Screen Assy.
	410144B	
30 IA	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
		I.D.)
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
		required) (1.5" I.D.)
201 4	24240	Fuel Can (Dad Plaatia) (Court Desistant Ulinh Profile) (Ulas
301A	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
		as required) (1.5" I.D.)
301A	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
	29673	* Gasket, Oil filler
	33876	Gasket, Stator (Used only on Std. poi nt ign.)
	34140	Cover, Carburetor
	31291	Plug, Cover
	610848	Magneto (w/ring gear for 120 Volt sta rter) NOTE: The
515	010040	complete magneto is not available as an assembly.
		Themagneto number is shown for reference purpose only.
		Order component parts individually, as shown in parts list.
		(Refer to Division 5, Section B, page 28 for breakdown or
		Fiche 18B, Grid F-1
377	30547A	Breaker Points (Use with Std. point i gn.)
	30548B	Condenser
	632110	Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A,
500	002110	page 168 for breakdown or Fiche18B, Grid E-9)
421	730226	SAE 5W30 4-Cycle Engine Oil (Quart)
422	35824	Muffler Optional