



Ref #	Part Number	Qty	Description
1	34096C		Cylinder (CI liner)(3-5/16")(Incl.2,20,41,43,72 & 119)
	27652		Pin, Dowel
	650494		Screw, 6-40 x 5/16"
	30699C		
			Rod Assy., Governor (Incl. 15A & 15B)
	30700		Yoke, Governor
	33454		Governor Lever Assy.
17	29916		Clamp, Governor lever
18	650548		Screw, 8-32 x 5/16"
20	32630		Seal, Oil
	29536		Blower Housing Baffle (Without electric starter knockout)
			(Use as required)
25	35256A		Blower Housing Baffle (With electric starter knockout) (Use
			as required)
	050504		. ,
	650561		Screw, 1/4-20 x 5/8"
	33720B		Crankshaft (Incl. 108 & 109)
35	29826		Screw, 10-32 x 3/4"
36	29918		Lockwasher, #8 E.T.
	29216		Locknut, 10-32
	30322		Nut & Lockwasher, 8-32
	29642		Ring, Retaining
	34543		Piston, Pin & Ring Set (Std.) (3-3/16 ")
	34544		Piston, Pin & Ring Set (.010" OS)
	34545		Piston, Pin & Ring Set (.020" OS)
41	34031B		Piston & Pin Ass'y. (Std.)(3-3/16")(I ncl.43)
41	34032B		Piston & Pin Ass'y. (.010" OS) (Incl. 43)
41	34033B		Piston & Pin Ass'y. (.020" OS) (Incl. 43)
	34037		Ring Set (Std.) (3-3/16" Bore)
	34038		Ring Set (.010" OS)
	34039		Ring Set (.020" OS)
	27888		Ring, Piston Pin retaining
	32591C		Rod Assy., Connecting (Incl. 46, 47 & 49)
	650662C		Bolt, Connecting rod (2 pieces)
	650662C		Bolt, Connecting rod (2 pieces)
48	34034		Lifter, Valve
49	34242		Dipper, Oil
50	34143		Camshaft (MCR)
	33273A		Extension, Blower housing
	650128		Screw, 10-24 x 1/2"
	35262		* Gasket, Flange
	33626B		Cyl.Cover (Incl.71,75,80,179,180,220, 221)
	27642		Plug, Oil drain
	33625		Seal, Oil
	31845		Shaft, Mechanical governor
	30590A		Washer, Flat
82	30591		Gear Assy., Governor (Incl. 81)
83	30588A		Spool, Governor
	29193		Ring, Retaining
	650833		Screw, 1/4-20 x 1-3/16 (Use as required)
	650832		Screw, 1/4-20 x 1-3/10 (Use as required)
	32589		Key, Flywheel
	650815		Washer, Belleville
	8116		Nut, Hex
103	650489		Screw, 1/4-20 x 5/8"
108	29783		Pin, Crankshaft gear (Only serviceable when gear is pinned
			to crank.)
	000.45		,
109	33245		Gear, Crankshaft

		Qty Description
119	34041A	* Gasket, Cylinder head
	34030A	Head, Cylinder
	27878A	Exhaust Valve (Std.) (Incl. 151)
	27880A	Exhaust Valve (1/32" OS) (Incl. 151)
	34035	Intake Valve (Std.) (Incl. 151)
	34036	Intake Valve (1/32" OS) (Incl. 151)
	650691	Washer (Do not use with No. 6021A scr ew.)
	650690	Washer, Belleville (Use as required)
129	650727	Screw, 5/16-18 x 1-3/4 (Use as requir ed)
130	6021A	Screw, 5/16-18 x 1-1/2" (Use as required, but do notuse No.
		650691 washer.)
130	650711	Screw, 5/16-18 x 1-5/8 " (Use as required) (Can use 6021A
		but discard 650691 washer.)
130	650694A	Screw, 5/16-18 x 2" (Use as required)
131	650737	Screw, 1/4-20 x 1/2" (Use as required)
	650738	Screw, 1/4-20 x 5/8 (Use as required)
	650713	Screw, 5/16-18 x 5/8"
	650890	Washer, Internal Lock
		•
	30747	Clip, Spark plug shorting
	33636	Resistor Spark Plug
	33369	Bracket, Governor gear
140	650836	Screw, 10-24 x 1/2"
149	27882	Cap, Upper valve spring
150	27881	Spring, Valve
	32581	Cap, Lower valve spring
	27896A	* Gasket, Breather
	28423	
		Body, Breather
	28424	Element, Breather
	28425	Cover, Breather
	35350	Tube, Breather
174	650128	Screw, 10-24 x 1/2"
	29752	Nut & Lockwasher, 1/4-28
	30088A	Screw, 1/4-28 x 1"
	33263	* Gasket, Carburetor
	33877	Pipe, Intake
	33371	Link, Governor lever
	31342	Spring, Compression
	650549	Screw, 5-40 x 7/16"
	33878	Link, Governor lever-to-throttle
	27793	Clip, Conduit
	650767	Screw, 8-32 x 5/8"
222A		Pop Rivet (Can be purchased locally)
	650378	Screw, Torx T-30, 5/16-18 x 1-1/8"
	27915A	* Gasket, Intake pipe
	33269A	Cover, Air cleaner
	33375D	Blower Housing (For electric starter)
261	650788	Screw, 5/16-18 x 3/4"
262	29747B	Screw, 5/16-24 x 21/32"
	33272B	Cover, Cylinder head
	33280A	Muffler
	31588	Plate, Muffler locking
	35741	Plate, Muffler locking
	650729	Screw, 5/16-18 x 3-3/16" (Use as requ ired)
277	651002	Screw, 5/16-18 x 4-1/4" (Use as requi red)
	22012	Cover, Starter bubble
281	33013	
	650760	Screw, 8-32 x 7/16"


Ref #	Part Number	Qty	Description
	29752		Nut, 1/4-28
	29774		Fuel Line (Braided 8-1/4")(21cm)(As r equired)
	30962		Fuel Line (Braided 32")(80cm)(As requ ired)
	30705		Fuel Line (Braided 16")(40cm)(As requ ired)
	26460		Fuel Line Clamp (Use as required)
	650665		Screw, 1/4-15 x 7/8"
300	34156A		Fuel Tank (Incl. 292 & 301) NOTE: These tanks were builtwith different size fuel inlet openings. Tanks with the 1-3/16" I.D. opening use fuel cap 34210. Tanks with the 1-1/2" I.D. opening use fuel cap 35355.
301A	410144B		Fuel Cap (White Plastic)(Standard) (Use as required) (1.5" I.D.)
301A	33032		Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use a required) (1.5" I.D.)
301A	34210		Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use as required) (1.5" I.D.)
301A	35355		Fuel Cap (Red Plastic)(1.75" I.D.)
306	29673		* Gasket, Oil filler
310	31297		Dipstick (Incl. 307)
338A	31291		Plug, Cover
340	34154		Plate, Upper fuel tank mtg.
341	34155		Bracket, Lower fuel tank mtg.
342	650561		Screw, 1/4-20 x 5/8"
370A	550223		Decal, Name
	34346		Decal, Instruction
370	35274		Decal, Instruction
	631021		Inlet Needle, Seat & Clip Assy.
380	631931A		Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 150 for breakdown Grid E-5)
400	33279G		* Gasket Set (Incl. items marked *)
420	730225		SAE 30 4-Cycle Engine Oil (Quart)
	730226		SAE 5W30 4-Cycle Engine Oil (Quart)
	35824		Muffler Optional



Ref # Part Num	
37A 30322	Nut & Lockwasher, 8-32
129 650727	Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131A 650713	Screw, 5/16-18 x 5/8"
131 650737	Screw, 1/4-20 x 1/2" (Use as required)
131 650738	Screw, 1/4-20 x 5/8 (Use as required)
222A	Pop Rivet (Can be purchased locally)
250B 33269A	Cover, Air cleaner
274 35865	Gasket, Exhaust
275 33280A	Muffler
277 650729	Screw, 5/16-18 x 3-3/16" (Use as requ ired)
277 651002	Screw, 5/16-18 x 4-1/4" (Use as requi red)
285A 33662	Hub & Screen Assy.
290 29774	Fuel Line (Braided 8-1/4")(21cm)(As r equired)
290 30962	Fuel Line (Braided 32")(80cm)(As requ ired)
292 26460	Fuel Line Clamp (Use as required)
298 650665	Screw, 1/4-15 x 7/8"
300 34156A	Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
	builtwith different size fuel inlet openings. Tanks with the
	1-3/16" I.D. opening use fuel cap 34210. Tanks with the
	1-1/2" I.D. opening use fuel cap 35355.
301A 410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
	I.D.)
301A 33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
	required) (1.5" I.D.)
301A 34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
00177 01210	as required) (1.5" I.D.)
301A 35355	Fuel Cap (Red Plastic)(1.75" I.D.)
306 29673	* Gasket, Oil filler
338A 31291	Plug, Cover
341 34155	Bracket, Lower fuel tank mtg.
342 650561	Screw, 1/4-20 x 5/8"
414 33323	Opt.Muffler Screen (Mini-Bike applica tion)
415 730130	Kit, Exhaust adapter (Incl. 274 & 277)
418 33700	Cover & Tube, Muffler (use as require d)
419 650578	Screw, 8-18 x 3/8" (use as required)
421 730226	SAE 5W30 4-Cycle Engine Oil (Quart)
422 35824	Muffler Optional



Ref # Part Numb	
37A 30322	Nut & Lockwasher, 8-32
129 650727	Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131A 650713	Screw, 5/16-18 x 5/8"
131 650737	Screw, 1/4-20 x 1/2" (Use as required)
131 650738	Screw, 1/4-20 x 5/8 (Use as required)
200B 730152	Control Bracket (Incl.1158-1171)(As r eq.)
200A 33388A	Control Bracket (Incl. 19, 203, 204 & 206)
203 31342	Spring, Compression
204 650549	Screw, 5-40 x 7/16"
210 27793	Clip, Conduit
211 650767	Screw, 8-32 x 5/8"
222A	Pop Rivet (Can be purchased locally)
227 730127	Air Cleaner Ass'y. (Incl. 238, 239, 242, 246, 250) (Use as
	required)
238 28820	Screw, 10-32 x 1/2"
239 27272A	* Gasket, Air cleaner
241 33266	Bracket, Air cleaner
242 33267	Bracket, Air cleaner
245 33268	Element, Air cleaner
250B 33269A	Cover, Air cleaner
251 650513	Nut, Wing 1/4-20
285A 33662	Hub & Screen Assy.
290 29774	Fuel Line (Braided 8-1/4")(21cm)(As r equired)
290 30962	Fuel Line (Braided 32")(80cm)(As required)
291 30705	Fuel Line (Braided 16")(40cm)(As required)
293 33715	Impulse Fuel Pump NOTE: 34385 and 33715 (WIP)pumps
	are replaced by 35813 and 35800 (WIP) pumps. The 33010
	(3000 series) repair kit is still available. The 35791 repair kit
	is used with the 35813 and 35800 fuel pumps.
294 35791	Fuel Pump Repair Kit NOTE: 34385 and 33715 (WIP)pumps
	are replaced by 35813 and 35800 (WIP) pumps. The 33010
	(3000 series) repair kit is still available. The 35791 repair kit
	is used with the 35813 and 35800 fuel pumps.
301A 410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
301A 410144B	I.D.)
301A 33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
301A 33032	required) (1.5" I.D.)
2014 24210	
301A 34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
	as required) (1.5" I.D.)
301A 35355	Fuel Cap (Red Plastic)(1.75" I.D.)
303 32958	Fitting, Fuel
306 29673	* Gasket, Oil filler
338A 31291	Plug, Cover
370 34346	Decal, Instruction
370 35274	Decal, Instruction
421 730226	SAE 5W30 4-Cycle Engine Oil (Quart)
422 35824	Muffler Optional
1158 33374	Spring Extension
1159 30312	Screw, 10-32 x 1/2"
1160 28820	Screw, 10-32 x 1/2"
4400 07070	
1160 27070 1185 33816	Lockwasher Hub & Screen Assy.



Ref #	Part Number	Qty	Description
1	34096C		Cylinder (CI liner)(3-5/16")(Incl.2,20,41,43,72 & 119)
2	27652		Pin, Dowel
	33627		Bearing, Ball
	33628		Washer, Thrust
	30322		Nut & Lockwasher, 8-32
	27642		Plug, Oil drain
	31855		Retainer, Bearing
	650489		Screw, 1/4-20 x 5/8"
	650727		Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131	650737		Screw, 1/4-20 x 1/2" (Use as required)
131	650738		Screw, 1/4-20 x 5/8 (Use as required)
131A	650713		Screw, 5/16-18 x 5/8"
	27896A		* Gasket, Breather
	28423		Body, Breather
	28424		Element, Breather
	28425		Cover, Breather
	35350		Tube, Breather
	650128		Screw, 10-24 x 1/2"
175	650778		Lockwasher
176	650580		Nut, Lock
178	29752		Nut & Lockwasher, 1/4-28
	33878		Link, Governor lever-to-throttle
222A			Pop Rivet (Can be purchased locally)
	28820		Screw, $10-32 \times 1/2$ "
	27272A		* Gasket, Air cleaner
	33266		Bracket, Air cleaner
	33267		Bracket, Air cleaner
245	33268		Element, Air cleaner
250B	33269A		Cover, Air cleaner
251	650513		Nut, Wing 1/4-20
275B	391026		Muffler (Incl. 284, 284A & 416) (This spark arrester
			mufflercan be used on any model.)
			• •
	33280A		Muffler
276	31588		Plate, Muffler locking
276	35741		Plate, Muffler locking
277	650729		Screw, 5/16-18 x 3-3/16" (Use as required)
	651002		Screw, 5/16-18 x 4-1/4" (Use as required)
	33662		Hub & Screen Assy.
	410144B		Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
301A	410144D		
			I.D.)
301A	33032		Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
			required) (1.5" I.D.)
301A	34210		Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
			as required) (1.5" I.D.)
0014	05055		
	35355		Fuel Cap (Red Plastic)(1.75" I.D.)
	29673		* Gasket, Oil filler
313A	33876		Gasket, Stator (Used only on Std. poi nt ign.)
338A	31291		Plug, Cover
375	610842		Magneto NOTE: The complete magneto is not available as
			an assembly. Themagneto number is shown for reference
			purpose only. Order component parts individually, as shown
			in parts list. (Refer to Division 5, Section B, page 28 for
			breakdown or Fiche 18B, Grid F-1)
			DICARUOWITUTTUTE TOD, UTIU F-1)
377	30547A		Breaker Points (Use with Std. point i gn.)
	30548B		Condenser
516			

Ref #	Part Number	Qty	Description
380	631931A		Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A, page 150 for breakdown Grid E-5)
	730226 35824		SAE 5W30 4-Cycle Engine Oil (Quart) Muffler Optional