


	Part Number Qty	
1	34922A	Cylinder (Cl liner)(3-5/16")(Incl.2,2 0 & 72)
2	27652	Pin, Dowel
3	650820	Screw, 1/4-20 x 1/2"
	30968	Nipple, Oil drain
	30969	Cap, Oil drain
	30699C	Rod Assy., Governor (Incl. 15A & 15B)
15A	30700	Yoke, Governor
15B	650494	Screw, 6-40 x 5/16"
	33454	Governor Lever Assy.
	29916	•
		Clamp, Governor lever
	650548	Screw, 8-32 x 5/16"
	32630	Seal, Oil
25	29536	Blower Housing Baffle (Without electric starter knockout)
		(Use as required)
25	35256A	Blower Housing Baffle (With electric starter knockout) (Use
		as required)
26	650561	Screw, 1/4-20 x 5/8"
	33719B	Crankshaft (Incl. 108 & 109)
	29826	Screw, 10-32 x 3/4"
36	29918	Lockwasher, #8 E.T.
37	29216	Locknut, 10-32
37A	30322	Nut & Lockwasher, 8-32
	29642	Ring, Retaining
	34860A	Piston, Pin & Ring Set (Std.)(3-5/16")
	34861A	Piston, Pin & Ring Set (.010" OS)
40	34862A	Piston, Pin & Ring Set (.020" OS)
41	34863	Piston & Pin Ass'y. (Std.)(3-5/16")(I ncl.43)
	34864	Piston & Pin Ass'y. (.010" OS) (Incl. 43)
	34865	Piston & Pin Ass'y. (.020" OS) (Incl. 43)
		• • • • •
	34866A	Ring Set (Std.) (3-5/16" Bore)
	34867A	Ring Set (.010" OS)
42	34868A	Ring Set (.020" OS)
43	27888	Ring, Piston Pin retaining
	32591C	Rod Assy., Connecting (Incl. 46, 47 & 49)
	650662C	
		Bolt, Connecting rod (2 pieces)
	650662C	Bolt, Connecting rod (2 pieces)
48	34034	Lifter, Valve
49	34242	Dipper, Oil
	34143	Camshaft (MCR)
	33273A	Extension, Blower housing
	34126	Bracket, Grommet mounting
	650760	Screw, 8-32 x 3/8"
63	28545	Grommet, Plastic
	650128	Screw, 10-24 x 1/2"
	35262	* Gasket, Flange
	33367B	Cover, Cylinder (Incl. 71, 75 & 80)
	33368	Bushing, Crankshaft
72	27642	Plug, Oil drain
75	31950	Seal, Oil
	31845	Shaft, Mechanical governor
	30590A	
		Washer, Flat
	30591	Gear Assy., Governor (Incl. 81)
83	30588A	Spool, Governor
	29193	Ring, Retaining
		Screw, 1/4-20 x 1-3/16 (Use as required)
	650833	
86	650833	
86 87	650832 32589	Screw, 1/4-20 x 1-3/16 (Use as required) Screw, 1/4-20 x 1-11/16" (Use as required) Key, Flywheel


	Part Number 650815	Qty	Description Washer, Belleville
	8116		Nut, Hex
	650863		Nut, 1/2-20
	610118		Cover, Spark plug
103	650489		Screw, 1/4-20 x 5/8"
108	29783		Pin, Crankshaft gear (Only serviceable when gear is pinned
			to crank.)
	33245		Gear, Crankshaft
	34923A		* Gasket, Cylinder head
120	34030A		Head, Cylinder
125	27878A		Exhaust Valve (Std.) (Incl. 151)
125	27880A		Exhaust Valve (1/32" OS) (Incl. 151)
126	34035		Intake Valve (Std.) (Incl. 151)
	34036		Intake Valve (1/32" OS) (Incl. 151)
	650691		Washer (Do not use with No. 6021A scr ew.)
	650690		Washer, Belleville (Use as required)
	650727		
			Screw, 5/16-18 x 1-3/4 (Use as required)
130	6021A		Screw, 5/16-18 x 1-1/2" (Use as required, but do notuse No. 650691 washer.)
130	650711		Screw, 5/16-18 x 1-5/8 " (Use as required) (Can use 6021A
			but discard 650691 washer.)
	650694A		Screw, 5/16-18 x 2" (Use as required)
131A	650713		Screw, 5/16-18 x 5/8"
131	650737		Screw, 1/4-20 x 1/2" (Use as required)
	650738		Screw, 1/4-20 x 5/8 (Use as required)
	650890		Washer, Internal Lock
	33636		Resistor Spark Plug
	33369		
			Bracket, Governor gear
	650836		Screw, 10-24 x 1/2"
	35862		Seal Assy., Intake valve
	27881		Spring, Valve
	32581		Cap, Lower valve spring
	27896A		* Gasket, Breather
170	28423		Body, Breather
171	28424		Element, Breather
172	28425		Cover, Breather
	35350		Tube, Breather
	650128		Screw, 10-24 x 1/2"
	29752		Nut & Lockwasher, 1/4-28
	30088A		Screw, 1/4-28 x 1"
	34587		Bracket, Choke
	33263		* Gasket, Carburetor
	33877		Pipe, Intake
	34667		Link, Governor lever
	34664		Control Bracket (Incl.19,203, 204, 20 6 & 209)
203	31342		Spring, Compression
204	650549		Screw, 5-40 x 7/16"
	610973		Terminal Assy.
	33878		Link, Governor lever-to-throttle
	650821		Screw, 10-32 x 1/2"
	27793		Clip, Conduit
	34586		Rod, Choke
	35438		Knob, Control
222A			Pop Rivet (Can be purchased locally)
	28820		Screw, 10-32 x 1/2"
	650378		Screw, Torx T-30, 5/16-18 x 1-1/8"

Ref #	Part Number Qty	Description
	27915A	* Gasket, Intake pipe
260	34822A	Blower Housing
261	650788	Screw, 5/16-18 x 3/4"
262	29747B	Screw, 5/16-24 x 21/32"
265	33272B	Cover, Cylinder head
275C	35056	Muffler
	31588	Plate, Muffler locking
	35741	Plate, Muffler locking
	650729	Screw, 5/16-18 x 3-3/16" (Use as required)
	651002	Screw, 5/16-18 x 4-1/4" (Use as required)
	33013	Cover, Starter bubble
	650760	Screw, 8-32 x 7/16"
	33662	
		Hub & Screen Assy.
	29752	
	29774	Fuel Line (Braided 8-1/4")(21cm)(As r equired)
	30962	Fuel Line (Braided 32")(80cm)(As required)
	30705	Fuel Line (Braided 16")(40cm)(As required)
	26460	Fuel Line Clamp (Use as required)
	32961	Valve, Fuel shut-off
298	650665	Screw, 1/4-15 x 7/8"
300	34156A	Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
		builtwith different size fuel inlet openings. Tanks with the
		1-3/16" I.D. opening use fuel cap 34210. Tanks with the
		1-1/2" I.D. opening use fuel cap 35355.
004 4		
301A	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
		I.D.)
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
		required) (1.5" I.D.)
00.44	0.404.0	
301A	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
		as required) (1.5" I.D.)
3014	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
	33893A	Oil Fill Tube
	33590	"O" Ring
	34011A	Dipstick (Incl. 307)
	35062	Ignition Key
	610973	Terminal Assy.
	35305	Wire, Ground
	650765	Screw, 10-32 x 1/2"
	35057A	Cover, Carburetor (Incl. 329)
	28942	Screw, Sems 10-32 x 3/8"
338A	31291	Plug, Cover
340	34154	Plate, Upper fuel tank mtg.
	34155	Bracket, Lower fuel tank mtg.
	650561	Screw, 1/4-20 x 5/8"
	34141	Guard, Starter
	32576	Seal, Snow Guard
	650767	Screw, 8-32 x 27/64"
	34416	Decal, Instruction
	35080	
		Decal, Instruction
	35274	Decal, Instruction
	631021	Inlet Needle, Seat & Clip Assy.
380	632370	Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A,
		page 200 for breakdown or Fiche18B, Grid E-13)
300	590593	Rewind Starter (Refer to Division 5, Section C, page 30 for
0.00		breakdown or Fiche 18B, Grid G-1)
		$\mathbf{U} = \mathbf{U} + $


D.(//		~	
Ref #	Part Number	Qty	Description
400	33279G		* Gasket Set (Incl. items marked *)
420	730225		SAE 30 4-Cycle Engine Oil (Quart)
421	730226		SAE 5W30 4-Cycle Engine Oil (Quart)
422	35824		Muffler Optional



	Part Number	Qty	Description
37A	30322		Nut & Lockwasher, 8-32
	650760		Screw, 8-32 x 3/8"
63	28545		Grommet, Plastic
129	650727		Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131A	650713		Screw, 5/16-18 x 5/8"
131	650737		Screw, 1/4-20 x 1/2" (Use as required)
131	650738		Screw, 1/4-20 x 5/8 (Use as required)
222A			Pop Rivet (Can be purchased locally)
274	35865		Gasket, Exhaust
275C	35056		Muffler
277	650729		Screw, 5/16-18 x 3-3/16" (Use as requ ired)
277	651002		Screw, 5/16-18 x 4-1/4" (Use as requi red)
285A	33662		Hub & Screen Assy.
290	29774		Fuel Line (Braided 8-1/4")(21cm)(As r equired)
290	30962		Fuel Line (Braided 32")(80cm)(As requ ired)
292	26460		Fuel Line Clamp (Use as required)
295	32961		Valve, Fuel shut-off
298	650665		Screw, 1/4-15 x 7/8"
300	34156A		Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
			builtwith different size fuel inlet openings. Tanks with the
			1-3/16" I.D. opening use fuel cap 34210. Tanks with the
			1-1/2" I.D. opening use fuel cap 35355.
3014	410144B		Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
00177			
			-
301A	33032		Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
			required) (1.5" I.D.)
301A	34210		Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
••••			as required) (1.5" I.D.)
00/1			
	35355		Fuel Cap (Red Plastic)(1.75" I.D.)
	35305		Wire, Ground
	35057A		Cover, Carburetor (Incl. 329)
	31291		Plug, Cover
	34155		Bracket, Lower fuel tank mtg.
	650561		Screw, 1/4-20 x 5/8"
	570682		Primer Assy.
	32180C		Line, Primer
	33323		Opt.Muffler Screen (Mini-Bike applica tion)
	730130		Kit, Exhaust adapter (Incl. 274 & 277)
	33700		Cover & Tube, Muffler (use as require d)
	650578		Screw, 8-18 x 3/8" (use as required)
421	730226 35824		SAE 5W30 4-Cycle Engine Oil (Quart)
			Muffler Optional



Ref #	Part Number C	Oty Description
37A	30322	Nut & Lockwasher, 8-32
129	650727	Screw, 5/16-18 x 1-3/4 (Use as requir ed)
	650737	Screw, 1/4-20 x 1/2" (Use as required)
	650738	Screw, 1/4-20 x 5/8 (Use as required)
	650713	Screw, 5/16-18 x 5/8"
	34587	Bracket, Choke
	730152	Control Bracket (Incl.1158-1171)(As r eq.)
203	31342	Spring, Compression
204	650549	Screw, 5-40 x 7/16"
210	27793	Clip, Conduit
222A		Pop Rivet (Can be purchased locally)
	28820	Screw, $10-32 \times 1/2$ "
221	730127	Air Cleaner Ass'y. (Incl. 238, 239, 242, 246, 250) (Use as
		required)
2750	35056	Muffler
	33662	Hub & Screen Assy.
	29774	Fuel Line (Braided 8-1/4")(21cm)(As r equired)
290	30962	Fuel Line (Braided 32")(80cm)(As requ ired)
291	30705	Fuel Line (Braided 16")(40cm)(As requ ired)
	33715	Impulse Fuel Pump NOTE: 34385 and 33715 (WIP)pumps
200		are replaced by 35813 and 35800 (WIP) pumps. The 33010
		(3000 series) repair kit is still available. The 35791 repair kit
		is used with the 35813 and 35800 fuel pumps.
20/	35791	Fuel Pump Repair Kit NOTE: 34385 and 33715 (WIP)pumps
207	35751	
		are replaced by 35813 and 35800 (WIP) pumps. The 33010
		(3000 series) repair kit is still available. The 35791 repair kit
		is used with the 35813 and 35800 fuel pumps.
3 ∩1∆	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
3017	4101440	
		I.D.)
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
		required) (1.5" I.D.)
301A	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
		as required) (1.5" I.D.)
301A	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
303	32958	Fitting, Fuel
330	35305	Wire, Ground
	650765	Screw, 10-32 x 1/2"
	35057A	Cover, Carburetor (Incl. 329)
	31291	Plug, Cover
364	33377	Bracket, Carburetor cover mtg.
365	650767	Screw, 8-32 x 27/64"
	34416	Decal, Instruction
	35080	Decal, Instruction
	35274	
		Decal, Instruction
	730226	SAE 5W30 4-Cycle Engine Oil (Quart)
422	35824	Muffler Optional
4450	30312	Screw, 10-32 x 1/2"
1158		
	28820	
1160	28820	Screw, 10-32 x 1/2"
1160 1160	28820 27070 33816	Lockwasher Hub & Screen Assy.



1 34922A	
	Cylinder (CI liner)(3-5/16")(Incl.2,2 0 & 72)
2 27652	Pin, Dowel
3 650820	Screw, 1/4-20 x 1/2"
37A 30322	Nut & Lockwasher, 8-32
72 27642	Plug, Oil drain
101 610118	Cover, Spark plug
103 650489	Screw, 1/4-20 x 5/8"
129 650727	
	Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131A 650713	Screw, 5/16-18 x 5/8"
131 650737	Screw, 1/4-20 x 1/2" (Use as required)
131 650738	Screw, 1/4-20 x 5/8 (Use as required)
169 27896A	* Gasket, Breather
170 28423	Body, Breather
171 28424	Element, Breather
172 28425	Cover, Breather
173 35350	Tube, Breather
174 650128	Screw, 10-24 x 1/2"
178 29752	Nut & Lockwasher, 1/4-28
207 33878	Link, Governor lever-to-throttle
222A	Pop Rivet (Can be purchased locally)
275B 391026	Muffler (Incl. 284, 284A & 416) (This spark arrester
	mufflercan be used on any model.)
275C 35056	Muffler
276 31588	Plate, Muffler locking
276 35741	Plate, Muffler locking
277 650729	Screw, 5/16-18 x 3-3/16" (Use as requ ired)
277 651002	Screw, 5/16-18 x 4-1/4" (Use as requi red)
285A 33662	Hub & Screen Assy.
301A 410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
50 // 4101+HB	
301A 33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
	required) (1.5" I.D.)
301A 34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
301A 34210	as required) (1.5" I.D.)
	as required) (1.5 1.D.)
301A 35355	Fuel Cap (Red Plastic)(1.75" I.D.)
313A 33876	Gasket, Stator (Used only on Std. poi nt ign.)
330 35305	Wire, Ground
337 35057A	Cover, Carburetor (Incl. 329)
338A 31291	Plug, Cover
375 610848	Magneto (w/ring gear for 120 Volt sta rter) NOTE: The
373 0100-0	complete magneto is not available as an assembly.
	Themagneto number is shown for reference purpose only.
	•
	Order component parts individually, as shown in parts list.
	(Refer to Division 5, Section B, page 28 for breakdown or
	Fiche 18B, Grid F-1
377 30547A	Breaker Points (Use with Std. point i gn.)
378 30548B	Condenser
380 632370	Carburetor (Incl. 184 & 379) (Refer to Division 5, Section A,
000 0020.0	page 200 for breakdown or Fiche18B, Grid E-13)
421 730226 422 35824	SAE 5W30 4-Cycle Engine Oil (Quart) Muffler Optional