


\_\_\_\_


	Part Number 35371	Qty	Description Cylinder (CI liner)(3-5/16")(Incl.2,2 0 & 72)
	27652		Pin, Dowel
			•
	30699C		Rod Assy., Governor (Incl. 15A & 15B)
	650494		Screw, 6-40 x 5/16"
	30700		Yoke, Governor
	33454		Governor Lever Assy.
17	29916		Clamp, Governor lever
18	650548		Screw, 8-32 x 5/16"
20	35319		Seal, Oil
25	35256A		Blower Housing Baffle (With electric starter knockout) (Use
			as required)
			. ,
	35326		Baffle, Blower housing
25	29536		Blower Housing Baffle (Without electric starter knockout)
			(Use as required)
26	650561		Sorow 1/4 20 x 5/9"
	650561		Screw, 1/4-20 x 5/8"
	35425A		Crankshaft
	29826		Screw, 10-32 x 3/4"
	29918		Lockwasher, #8 E.T.
	29216		Locknut, 10-32
37A	30322		Nut & Lockwasher, 8-32
38	29642		Ring, Retaining
40	34860A		Piston, Pin & Ring Set (Std.)(3-5/16")
40	34861A		Piston, Pin & Ring Set (.010" OS)
	34862A		Piston, Pin & Ring Set (.020" OS)
	35776		Piston, Pin & Ring Set (Std.)(3-3/16")
	35777		Piston, Pin & Ring Set (.010" OS)
	35778		Piston, Pin & Ring Set (.020" OS)
	34863		Piston & Pin Ass'y. (Std.)(3-5/16")(I ncl.43)
	34864		Piston & Pin Ass'y. (.010" OS) (Incl. 43)
	34865		Piston & Pin Ass'y. (.020" OS) (Incl. 43)
	35773		Piston & Pin Ass'y. (Std.)(3-5/16")(I ncl.43)
	35774		Piston & Pin Ass'y. (.010" OS) (Incl. 43)
	35775		Piston & Pin Ass'y. (.020" OS) (Incl. 43)
	34866A		Ring Set (Std.) (3-5/16" Bore)
	34867A		Ring Set (.010" OS)
42	34868A		Ring Set (.020" OS)
42	35779		Ring Set (Std.) (3-5/16" Bore)
42	35780		Ring Set (.010" OS)
42	35781		Ring Set (.020" OS)
43	27888		Ring, Piston Pin retaining
	35772		Ring, Piston Pin retaining
	35373A		Rod Assy., Connecting (Incl. 46, 47 & 49)
	35681		Rod Assy., Connecting (Incl. 46, 47 & 49)
	650908		Bolt, Connecting rod
	650882		Connecting Rod Bolt (2 pcs. on early Specs.)
	34034		Lifter, Valve
	35374		Dipper, Oil
	35375		Camshaft (MCR)
	33273A		Extension, Blower housing
	650802		Screw, 1/4-20 x 5/8"
	650128		Screw, 10-24 x 1/2"
	35262		* Gasket, Flange
	35376		Cover, Cylinder (Incl. 71, 75 & 80)
71	35377		Bushing, Crankshaft
72	27642		Plug, Oil drain
75	35319		Seal, Oil
	31845		Shaft, Mechanical governor

		ty Description
	30590A	Washer, Flat
82	35378	Gear Assy., Governor (Incl. 81)
	30588A	Spool, Governor
	29193	Ring, Retaining
	650833	Screw, 1/4-20 x 1-3/16 (Use as required)
	650832	Screw, 1/4-20 x 1-11/16" (Use as requ ired)
89	32589	Key, Flywheel
90	611090	Flywheel
	650880	Washer, Lock
	650881	Nut, 5/8-18
	35135	Solid State Assy.
	27276	Cover, Spark plug
	650872	Stud, Solid state mounting
103	650814	Screw, Torx T-15, 10-24 x 1"
108	29783	Pin, Crankshaft gear (Only serviceable when gear is pinned
		to crank.)
109	33245	Gear, Crankshaft
	34923A	* Gasket, Cylinder head
	34030A	Head, Cylinder
	27878A	Exhaust Valve (Std.) (Incl. 151)
	27880A	Exhaust Valve (1/32" OS) (Incl. 151)
126	34035	Intake Valve (Std.) (Incl. 151)
126	34036	Intake Valve (1/32" OS) (Incl. 151)
127	650691	Washer (Do not use with No. 6021A scr ew.)
	650690	Washer, Belleville (Use as required)
	650727	
		Screw, 5/16-18 x 1-3/4 (Use as required)
130	6021A	Screw, 5/16-18 x 1-1/2" (Use as required, but do notuse No
		650691 washer.)
130	650711	Screw, 5/16-18 x 1-5/8 " (Use as required) (Can use 6021A
		but discard 650691 washer.)
	650694A	Screw, 5/16-18 x 2" (Use as required)
131A	650713	Screw, 5/16-18 x 5/8"
131	650737	Screw, 1/4-20 x 1/2" (Use as required )
	650738	Screw, 1/4-20 x 5/8 (Use as required)
	650890	Washer, Internal Lock
	30747	Clip, Spark plug shorting
	33636	Resistor Spark Plug
	33369	Bracket, Governor gear
140	650836	Screw, 10-24 x 1/2"
	27882	Cap, Upper valve spring
	35862	Seal Assy., Intake valve
	27881	Spring, Valve
	32581	Cap, Lower valve spring
	27896A	* Gasket, Breather
170	28423	Body, Breather
171	28424	Element, Breather
	28425	Cover, Breather
	35350	Tube, Breather
	650128	Screw, 10-24 x 1/2"
	29752	Nut & Lockwasher, 1/4-28
	30088A	Screw, 1/4-28 x 1"
	33263	* Gasket, Carburetor
184		Pipe, Intake
	330//	
185		•
185 203	31342	Spring, Compression
185 203 204		•


 ₽.cf #	Part Number		Description
		QIY	Pop Rivet (Can be purchased locally)
	660279		• • • • • •
	650378		Screw, Torx T-30, 5/16-18 x 1-1/8"
	27915A		* Gasket, Intake pipe
	33269A		Cover, Air cleaner
	33375D		Blower Housing (For electric starter)
	650788		Screw, 5/16-18 x 3/4"
	29747B		Screw, 5/16-24 x 21/32"
	33272B		Cover, Cylinder head
	35056		Muffler
	31588		Plate, Muffler locking
	35741		Plate, Muffler locking
	650729		Screw, 5/16-18 x 3-3/16" (Use as requ ired)
	651002		Screw, 5/16-18 x 4-1/4" (Use as requi red)
	33013		Cover, Starter bubble
	650760		Screw, 8-32 x 7/16"
	35287		Cup, Starter
286	35446		Screen, Starter
287	29752		Nut, 1/4-28
290	29774		Fuel Line (Braided 8-1/4")(21cm)(As r equired)
290	30962		Fuel Line (Braided 32")(80cm)(As required)
291	30705		Fuel Line (Braided 16")(40cm)(As required)
	26460		Fuel Line Clamp (Use as required)
	650665		Screw, 1/4-15 x 7/8"
	34156A		Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
			builtwith different size fuel inlet openings. Tanks with the
			1-3/16" I.D. opening use fuel cap 34210. Tanks with the
			1-1/2" I.D. opening use fuel cap 35355.
301A	410144B		Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
			I.D.)
301A	33032		Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
001/1	00002		required) (1.5" I.D.)
301A	34210		Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
			as required) (1.5" I.D.)
301A	35355		Fuel Cap (Red Plastic)(1.75" I.D.)
	35554		Oil Fill Tube
	35499		"O" Ring
	35540		Clip, Fill tube
	36205		Dipstick
			1
	35392		Plug, Starter
	31291		Plug, Cover Plate Lipper fuel tenk mtg
	34154		Plate, Upper fuel tank mtg.
	34155		Bracket, Lower fuel tank mtg.
	650561		Screw, 1/4-20 x 5/8"
	34346		Decal, Instruction
	35274		Decal, Instruction
	34686		Decal, Name
	631021		Inlet Needle, Seat & Clip Assy.
380	632596		Carburetor (Incl. 184) (Refer to Division 5, Section A, page
			A4-4 for breakdown or Fiche 18B, Grid D-3)
200	590633		Rewind Starter (Refer to Division 5, Section C, page 30 for
550			breakdown or Fiche 18B, Grid G-1)
			· · · · · · · · · · · · · · · · · · ·
	33279G		* Gasket Set (Incl. items marked *)
	730225		SAE 30 4-Cycle Engine Oil (Quart)
	730226		SAE 5W30 4-Cycle Engine Oil (Quart)
422	35824		Muffler Optional



	,	Description
	30322	Nut & Lockwasher, 8-32
	650802	Screw, 1/4-20 x 5/8"
	650727	Screw, 5/16-18 x 1-3/4 (Use as requir ed)
131A	650713	Screw, 5/16-18 x 5/8"
131	650737	Screw, 1/4-20 x 1/2" (Use as required )
131	650738	Screw, 1/4-20 x 5/8 (Use as required)
222A		Pop Rivet (Can be purchased locally)
250B	33269A	Cover, Air cleaner
	35865	Gasket, Exhaust
275C	35056	Muffler
	650729	Screw, 5/16-18 x 3-3/16" (Use as requ ired)
277	651002	Screw, 5/16-18 x 4-1/4" (Use as requi red)
	29774	Fuel Line (Braided 8-1/4")(21cm)(As r equired)
	30962	Fuel Line (Braided 32")(80cm)(As requ ired)
	26460	Fuel Line Clamp (Use as required)
	650665	Screw, 1/4-15 x 7/8"
300	34156A	Fuel Tank (Incl. 292 & 301) NOTE: These tanks were
		builtwith different size fuel inlet openings. Tanks with the
		1-3/16" I.D. opening use fuel cap 34210. Tanks with the
		1-1/2" I.D. opening use fuel cap 35355.
301A	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
001/1		I.D.)
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
		required) (1.5" I.D.)
301A	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
00 // (		as required) (1.5" I.D.)
	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
	31291	Plug, Cover
	34155	Bracket, Lower fuel tank mtg.
	650561	Screw, 1/4-20 x 5/8"
	33323	Opt.Muffler Screen (Mini-Bike applica tion)
	730130	Kit, Exhaust adapter (Incl. 274 & 277 )
	33700	Cover & Tube, Muffler (use as require d)
	650578	Screw, 8-18 x 3/8" (use as required)
	730226	SAE 5W30 4-Cycle Engine Oil (Quart)
422	35824	Muffler Optional



Ref #	Part Number Qty	Description
37A	30322	Nut & Lockwasher, 8-32
64	650802	Screw, 1/4-20 x 5/8"
129	650727	Screw, 5/16-18 x 1-3/4 (Use as requir ed)
	650737	Screw, 1/4-20 x 1/2" (Use as required )
	650738	Screw, 1/4-20 x 5/8 (Use as required)
	650713	Screw, 5/16-18 x 5/8"
	730152	Control Bracket (Incl.1158-1171)(As r eq.)
	31342	Spring, Compression
	650549	Screw, 5-40 x 7/16"
204 222A	000049	
	700107	Pop Rivet (Can be purchased locally)
221	730127	Air Cleaner Ass'y. (Incl. 238, 239, 242, 246, 250) (Use as
		required)
238	28820	Screw, 10-32 x 1/2"
	27272A	* Gasket, Air cleaner
	33266	Bracket, Air cleaner
	33267	Bracket, Air cleaner
	33268	Element, Air cleaner
	33269A	Cover, Air cleaner
	650513	
	35056	Nut, Wing 1/4-20
		Muffler
	29774	Fuel Line (Braided 8-1/4")(21cm)(As r equired)
	30962	Fuel Line (Braided 32")(80cm)(As required)
	30705	Fuel Line (Braided 16")(40cm)(As required)
293	33715	Impulse Fuel Pump NOTE: 34385 and 33715 (WIP)pumps
		are replaced by 35813 and 35800 (WIP) pumps. The 33010
		(3000 series) repair kit is still available. The 35791 repair kit
		is used with the 35813 and 35800 fuel pumps.
294	35791	Fuel Pump Repair Kit NOTE: 34385 and 33715 (WIP)pumps
201		are replaced by 35813 and 35800 (WIP) pumps. The 33010
		(3000 series) repair kit is still available. The 35791 repair kit
		is used with the 35813 and 35800 fuel pumps.
		is used with the 55015 and 55000 rdel pumps.
301A	410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
		I.D.)
204 4	22022	Fuel Can (Bad Plantic) (Court Desistant Law Profile) (Las es
301A	33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
		required) (1.5" I.D.)
301A	34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
		as required) (1.5" I.D.)
	35355	Fuel Cap (Red Plastic)(1.75" I.D.)
	32958	Fitting, Fuel
	35392	Plug, Starter
338A	31291	Plug, Cover
	34346	Decal, Instruction
370	35274	Decal, Instruction
421	730226	SAE 5W30 4-Cycle Engine Oil (Quart)
	35824	Muffler Optional
	30312	Screw, 10-32 x 1/2"
1159		
1160	28820	Screw, 10-32 x 1/2"
1160 1160		



1 35371 2 27652	Cylinder (CI liner)(3-5/16")(Incl.2,2 0 & 72)
2 27652	
2 21002	Pin, Dowel
37A 30322	Nut & Lockwasher, 8-32
64 650802	Screw, 1/4-20 x 5/8"
72 27642	Plug, Oil drain
90 611090	Flywheel
94 33450	Lock Nut, 10-32
95 30886A	Spring, Governor bolt
96 30845A	Bolt, Governor adjusting
100 35135	
101 27276	Solid State Assy.
	Cover, Spark plug
102 650872	Stud, Solid state mounting
103 650814	Screw, Torx T-15, 10-24 x 1"
129 650727	Screw, 5/16-18 x 1-3/4 (Use as required)
131A 650713	Screw, 5/16-18 x 5/8"
131 650737	Screw, 1/4-20 x 1/2" (Use as required )
131 650738	Screw, 1/4-20 x 5/8 (Use as required)
169 27896A	* Gasket, Breather
170 28423	Body, Breather
171 28424	Element, Breather
172 28425	Cover, Breather
173 35350	Tube, Breather
174 650128	Screw, 10-24 x 1/2"
178 29752	Nut & Lockwasher, 1/4-28
207 33878	Link, Governor lever-to-throttle
207 33878 222A	
	Pop Rivet (Can be purchased locally)
238 28820	Screw, 10-32 x 1/2"
239 27272A	* Gasket, Air cleaner
241 33266	Bracket, Air cleaner
242 33267	Bracket, Air cleaner
245 33268	Element, Air cleaner
250B 33269A	Cover, Air cleaner
251 650513	Nut, Wing 1/4-20
275B 391026	Muffler (Incl. 284, 284A & 416) (This spark arrester
	mufflercan be used on any model.)
07EC 2E0EC	Mufflor
275C 35056	Muffler
276 31588	Plate, Muffler locking
276 35741	Plate, Muffler locking
277 650729	Screw, 5/16-18 x 3-3/16" (Use as required)
277 651002	Screw, 5/16-18 x 4-1/4" (Use as requi red)
301A 410144B	Fuel Cap (White Plastic)(Standard) (Use as required) (1.5"
	I.D.)
2014 22022	Fuel Can (Ded Directio) (Court Devictant Law Profile) (Lies on
301A 33032	Fuel Cap (Red Plastic) (Spurt Resistant, Low Profile) (Use as
	required) (1.5" I.D.)
301A 34210	Fuel Cap (Red Plastic) (Spurt Resistant, High Profile) (Use
00117 04210	as required) (1.5" I.D.)
301A 35355	Fuel Cap (Red Plastic)(1.75" I.D.)
313A 33876	Gasket, Stator (Used only on Std. poi nt ign.)
338A 31291	Plug, Cover
377 30547A	Breaker Points (Use with Std. point i gn.)
380 632596	Carburetor (Incl. 184) (Refer to Division 5, Section A, page
	A4-4 for breakdown or Fiche 18B, Grid D-3)
421 730226 422 35824	SAE 5W30 4-Cycle Engine Oil (Quart) Muffler Optional