










ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY OEM.



Ref #	Part Number	Qty	Description
	1		Cylinder (Order s/b if replacement is req.)
16B	490291A		Air Vane
19	570646		Extension Spring
24	530110		Ball Bearing
27	510319		Oil Seal
29	530150		Needle Bearing & Liner Set (37 needle s)
29A	530104A		Cartridge Bearing
30	290655		Crankshaft
33A	570644		Cover Plate
34A	650579		Screw, Torx T-25, 10-24 x 1/2"
41	310283A		Piston & Pin Assy. (Incl. 43)
42	310190		Ring Set
43	310167		Piston Pin Retaining Ring
45	310235B		Connecting Rod Assy. (Incl. 29, 29A & 46)
46	650633		Connecting Rod Bolt
69A	510292A		* Cylinder Cover Gasket
69	510323A		* Cover Plate Gasket
77	530105		Cartridge Bearing
89A	611032		Adapter Sleeve
90	611066		Flywheel
92	650815		Belleville Washer
93	650390		Flywheel Nut
100A	34443A		Solid State Ignition (Incl. 101)
101	610118		Spark Plug Cover
103	650814		Screw, Torx T-15, 10-24 x 1"
110	611130		Ground Wire
119	510274A		* Cylinder Head Gasket
120	250240B		Cylinder Head
131	650477		Screw, Torx T-30, 1/4-20 x 3/4"
135	611049		Resistor Spark Plug (RCJ-8Y)
169	510325A		* Cover Gasket
172	570708		Compression Release Cover
174	650579		Screw, Torx T-25, 10-24 x 1/2"
175	650838		Washer, No. 10
177A	650959		Screw, 1/4-20 x 1"
184	510326A		* Carburetor Gasket
186	490297		Governor Link
187	570438A		Spacer
216	570645		R.P.M. Adjusting Lever
257	650911		Screw, Torx T-30, 1/4-20 x 5/8"
258	350422		Blower Housing Base (Incl. 27)
260	350444		Blower Housing
261	650737		Screw, 1/4-20 x 1/2"
274	510207A		* Exhaust Gasket
285	590551		Starter Cup
287			Pop Rivet (3/16" dia.)(Purchase local ly)
301	410259A		Fuel Cap
350	570629A		Primer Bulb
370C	35977		Caution Decal
380	632608		Carburetor (Incl. 184) (Refer to Division 5, Section A, page A1-34 or Fiche 27A, Grid F-1 for breakdown)
400	510324B		* Gasket Set (Incl. items marked *)

ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY OEM.



Ref #	Part Number	Qty	Description
239A	35815		Air Cleaner Gasket (.031" thick)
275B	390331		Muffler (1 piece)
277A	650869		Screw, 1/4-20 x 2-3/4"
287A	650926		Screw, 8-32 x 21/64"
325	29443		Wire Clip
327	35392		Starter Plug
350	570629A		Primer Bulb
351A	410274		Primer Line
383	570434		Air Baffle
384	650229		Screw, Torx T-25, 10-32 x 3/8"
390A	590652		Rewind Starter (Refer to Division 5, Section C, page 34 or Fiche 27A, Grid G-10for breakdown)
422	730227A		2-Cycle Oil (8 oz.)