


Ref # Part Number Qty	
1 34305 2 31927 2 28483 2 2 9556 2 29554	Cylinder (Incl. 2, 4 & 33) (3-1/2" Bo re) Pipe Plug, 3/8-18 sq. head (Use as re quired) Pipe Plug (3/8-18 hex countersunk) (A s req.) Pipe Plug (3/4-14 sq.hd.)(As req.)(Bu y local) Pipe Plug (1/8-27 sq. hd.) (Use as re quired) Pipe Plug (1/8-27 sq. hd.) (Use as re quired)
2 28534 4 27652 5 33497C	Pipe Plug(1/8-27 hex c/sunk headless) (As req) Pin, Dowel Crankshaft (Incl. 6 thru 9, 140 & 141) NOTE: When using this crankshaft to repair older units equipped with straight cut cam and governor gears, it will be necessary to order 34751 helical governor gear assembly and 34752 helical camshaft in order to the complete the repair.
6 29783 7 34692 8 31932 9 31928 11A 32238B 11A 32239B 11A 32240B 11 34511 11 34512 11 34513 12 31919 13 32242 13 32242 13 32242 13 32243 14 33093A 14 34383 14 34384 15 32077 16 26073 17 28264 18 33470 19 33472 20 33471 21 23505	Pin, Crankshaft gear Gear Crankshaft (Helical) Bearing, Tapered roller Cup, Bearing Piston & Pin Ass'y. (Std.)(3-1/2")(In cl.12) Piston & Pin Ass'y. (.010" OS) (Incl. 12) Piston & Pin Ass'y. (.020 " OS) (Incl. 12) Piston, Pin & Ring Set (Std.) (3-1/2" Bore) Piston, Pin & Ring Set (.010" OS) Piston, Pin & Ring Set (.020" OS) Ring, Piston pin retaining Ring Set (Std.) (3-1/2" Bore) Ring Set (.010" OS) Ring Set (.020" OS) Connecting Rod Assy.(Std.)(Incl.15, 1 6 & 17) Connecting Rod Assy.(.020" US)(Incl.1 5, 16, 17) Connecting Rod Assy.(.020" US)(Incl.1 5, 16, 17) Bolt, Connecting rod Washer, Connecting rod Nut Assy. Camshaft (MCR) (Straight) Lifter, Valve Rod, Push
21 33505 21 33645 22 33506 22 33646 23 33507 24 33508 25 33509 25A 34410 26 33510 27 33473 28 650745 29 35479 29 30590A 30 31948 31 31956B 32 34307 33 31950 34 650451 35 650492 36 32425 37 32426 38 29193	Intake Valve (Std.) Intake Valve (1/32" OS) Exhaust Valve (Std.) Exhaust Valve (1/32" OS) Spring, Valve Retainer & Cap Set, Keeper valve * "O" Ring (Intake only) (Also Incl. in 251) * "O" Ring (Exhaust only) (Also Incl. in 251) Cap, Valve Governor Gear & Shaft Ass'y. (Straigh t) Washer, Flat Washer, Flat (Use with 35322 spool) Washer, Flat Spool, Governor * Gasket, Cylinder cover Cover Assy., Cylinder (Incl. 33 & 204) * Seal, Oil Screw, 1/4-20 x 1" Screw, 1/4-20 x 2-1/4" Rod Assy., Governor Spacer, Governor rod Ring, Retaining

	Part Number Qty	
	650736	Screw, 10-16 x 3/8"
	33495	Cover, Cylinder head
41	34225A	* Gasket, Cylinder head
42	34753	Head, Cylinder
45	35552	Spark Plug (RL-82C)
46A	650691	Washer, Flat
	650690	Washer, Belleville
	650692	Screw, 5/16-18 x 1-3/4"
	650746	Screw, 5/16-18 x 1-3/8"
	730218	Valve Guide Kit (Incl. 49)
	792035	Ring, Retaining
	33515A	* Gasket, Intake pipe
	33475	••
		Pipe, Intake
	650378	Screw, Torx T-30, 5/16-18 x 1-1/8"
	792028	Screw, 5/16-18 x 7/8"
	33476A	* Gasket, Carburetor
	33477A	Baffle, Air cleaner
	792075	Nut, Lock 5/16-24 (Used in early prod uction)
	33478	Link, Governor lever-to-throttle leve r
58	31963	Lever, Governor
59	31964	Clamp, Governor lever
60	650518	Lockwasher, No. 10 E.T.
61	30312	Screw, 10-32 x 1/2"
	650544	Screw, Torx T-25, 10-24 x 7/8"
	7975	Nut, 10-24
	31965	Plate, Governor spring
	34306	Lever Assy., Control
	28558	Washer, Wave
	31966	Bushing, Governor lever
	650597	Screw, 10-24 x 5/8"
	33982	
		Spring, Governor
	650591	Screw, 10-24 x 2"
	33099	Spring
	32599	"O" Ring (Incl. in 251)
	650666	Washer, Lock
	32579	Baffle, Blower housing
	650561	Screw, 1/4-20 x 5/8"
	650592	Key, Flywheel
	730201	Trigger Pin Kit (Use as required)
77	610909	Flywheel
78	650594	Nut, Flywheel
79	610906	Solid State Magneto (Incl. 158 thru 1 61)
80	650661	Screw, 1/4-20 x 3/4"
	33479	Extension, Blower housing
	30063	Screw, 1/4-20 x 1/2"
	650751	Screw, 1/4-20 x 7/16"
	34195B	Blower Hsg.(Incl.218,219)(For elec.st arter)
	8274	Washer, Lock
	8274	Washer, Lock
	650595	Screw, 5/16-24 x 3/8"
	650595	Screw, 5/16-24 x 3/8"
	650752	Screw, 1/4-20 x 7/16"
	35475	Tube, Push rod
	33481	* "O" Ring (Also Incl. in 251)
	34754	Housing, Rocker arm
	33484	* "O" Ring (Also Incl. in 251)
	650168	Washer, Flat
96	32610A	Screw, 1/4-20 x 29/32"

		Qty	Description
97 98 99 100 101 102 103 104 105 106 107 108 111 114 115 117	33485 33486 650755 650864 650756 33487 33488 31958A 33489 33490 30102 650738 35471 650399 32008 650513	Qty	Arm, Rocker Ring, Retaining Screw, 1/4-20 x 3/4" Nut, Hex, 1/4-20 Stud, Rocker arm * "O" Ring (Also Incl. in 251) Cover, Rocker arm * Gasket, Breather (Also Incl. in 251) Body Assy., Breather Tube, Breather * Screw, 10-32 x 5/8" (Also Incl. in 25 1) Screw, 1/4-20 x 5/8" * Gasket, Air cleaner Screw, 10-32 x 5/8" Element, Air cleaner Nut, Wing
146	32577		Cover, Cylinder NOTE: Determine the gap between the cover and the machined surface on the cylinder, which can be from .001" up to .007", in which case no shim gaskets will be required. Use of gaskets must be limited to a combined total of .010" thick. Steel spacersmust be used as required to eli
	792028 31971		Screw, 5/16-18 x 7/8" * Gasket, Shim (.004/.005 thick) NOTE: Determine the gap between the cover and the machined surface on the cylinder, which can be from .001" up to .007", in which case no shim gaskets will be required. Use of gaskets must be limited to a combined total of .010" thick. Steel spacersmust be used a
156	31972		* Gasket, Shim (.005/.007 thick) NOTE: Determine the gap between the cover and the machined surface on the cylinder, which can be from .001" up to .007", in which case no shim gaskets will be required. Use of gaskets must be limited to a combined total of .010" thick. Steel spacersmust be used a
157	32031		* Spacer, Steel (.010 thick) NOTE: Determine the gap between the cover and the machined surface on the cylinder, which can be from .001" up to .007", in which case no shim gaskets will be required. Use of gaskets must be limited to a combined total of .010" thick. Steel spacersmust be used as re
159 160 161 169A 170 171 194 195 244B 244 246 247	610118 610750 610408 610908 27793 28942 29634 27625 29673 31752 34308 631687 632203		Cover, Spark plug Grommet, Lead wire Nut, 8-32 Terminal, Female Clip, Conduit Screw, 10-32 x 3/8" Fitting, Fuel line Plug, Oil filler (Incl. 195) * Gasket, Oil filler plug Decal, Air cleaner Decal, Instruction Valve, Seat & Spring Assy. Carburetor (Incl. 54 & 246) (Refer to Division 5, Section A, page 160 for breakdown) * Gasket Set (Incl. itoms marked *)
250	33516G		* Gasket Set (Incl. items marked *)

Ref # Part Number	Qty Description
251 35075	"O" Ring Kit (Incl. Nos. items marked +)




		ty Description
39	650736	Screw, 10-16 x 3/8"
	30063	Screw, 1/4-20 x 1/2"
	35731	Muffler (Incl. 126B)
140	33499	Spacer
	33963	Gear, Counterbalance weight (Helical teeth)
141		Gear, Counterbalance weight (Straight teeth) (For
		replacement see Ref. 132. Order correct kit for your
		enginemodel number.)
148	610902	Alt.Coil Ass'y. (Incl.162,163,163A) (20 amp)
	650521	Screw, 10-32 x 1-1/8"
	610996	Regulator (20 Amp) (Incl. 212 thru 21 8)
	792028	Screw, 5/16-18 x 7/8"(Use w/32817 str .motor)
	650781	Screw,5/16-18 x 11/16"(Use w/33835 st r.motor)
162A	610903	Connector, Flat
163A	610905	Terminal
163	610904	Terminal
209	730178	Ech.Adapter Kit (Incl.210 & 211)(As r equired)
	34102B	Gasket, Exhaust (Use as required)
211	30196	Screw, 5/16-18 x 3/4" (Use as require d)
	610990	Connector, Male
	610921	Connector
	610922	Terminal
	610989	Terminal
	610992	Terminal, Female
	610991	Terminal, Female
	30063	Screw, 1/4-20 x 1/2"
238	730212	Adapter Plate Kit (Optional) NOTE: If you are having
		mounting problems in using a HH100 thru0H180 inplace of a
		large frame competitivebrand, we would like to call your
		attention to 730212 adapter plate kit. The kit converts the
		bottom mounting system found on HH100 thru 0H180 to a
		top mounting sys
249	33835	Electric Starter Motor (12-Volt) (Refer to Division 5, Section
		D for breakdown)

145

143

1710 196

ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY DEM.



122

Ref #	Part Number Q	ty Description
114	650399	Screw, 10-32 x 5/8"
115	32008	Element, Air cleaner
117	650513	Nut, Wing
143	29774	Fuel Line (Braided 8.25")(21 cm)(As r equired)
143	30705	Fuel Line (Braided 16")(41 cm)(As req uired)
143	30962	Fuel Line (Braided 32")(81 cm)(As req uired)
178	410144B	Fuel Cap (White Plastic)(Std)(As required)
178	34210	Fuel Cap (Red Plastic) (Spurt resistant, High profile) (Use as required)
196	26460	Clamp, Fuel line (Use as required)
	34193	Cover, Air cleaner
206	34194A	Tube, Air cleaner
207	35473	Bracket, Air cleaner
208	34197	Gasket, Air cleaner
245	730134	Rewind Starter Kit (Incl.120A, 121, 122, 187, 188 & 248) (Use as required)