



Ref #	Part Number	Qty	Description
	1 37107B	1	Cylinder (Incl. 2, 20 & 72)
	2 26727	2	Dowel Pin
14A	36288	1	Bushing
14	651052	1	Washer
15	37108	1	Governor Rod
16	37110	1	Governor Lever
30	37308	1	Crankshaft
35	651053	1	Screw, T-25, 10-32 x 63/64"
37	29216	1	Lock Nut
38	37109	1	Retaining Ring
40	35544A	1	Piston, Pin & Ring Set (Std.)
40	35545A	1	Piston, Pin & Ring Set (.010" OS)
40	35546	1	Piston, Pin & Ring Set (.020" OS)
41	35541	1	Piston & Pin Ass'y (Std.) (Incl. 43)
41	35542	1	Piston & Pin Ass'y (.010" OS) (Incl. 43)
41	35543	1	Piston & Pin Ass'y (.020" OS) (Incl. 43)
42	35547A	1	Ring Set (Std.)
42	35548A	1	Ring Set (.010" OS)
42	35549	1	Ring Set (.020" OS)
43	20381	2	Piston Pin Retaining Ring
45	32875A	1	Connecting Rod Ass'y (Incl. 46 & 49)
46	32610A	2	Connecting Rod Bolt
48	35616	2	Valve Lifter
49	36611	1	Oil Dipper
50	37040	1	Camshaft (Incl. 253 & 254)
64	651015	1	Screw, 1/4-20 x 1-1/8"
69	36624	1	* Cylinder Cover Gasket
70	36625	1	Cylinder Cover (Incl. 75 thru 83)
72	27642	2	Oil Drain Plug
75	27897	1	Oil Seal
80	30574A	1	Governor Shaft
81	30590A	1	Washer
82	30591	1	Governor Gear Ass'y (Incl. 81)
83	36057	1	Governor Spool
86	650488	8	Screw, 1/4-20 x 1-1/4"
89	610961	1	Flywheel Key
111B	611224	1	Rocker On/Off Switch
119	36738	1	* Cylinder Head Gasket
120	37455	1	Cylinder Head
125	36471	1	Exhaust Valve (Std.) (Incl. 151)
125	36472	1	Exhaust Valve (1/32" OS) (Incl. 151)
126	37711	1	Intake Valve (Std.) (Incl. 151)
130A	650999	1	Screw, 5/16-18 x 2-41/64"
130	650912	4	Screw, 5/16-18 x 1-1/2"
135	34645	1	Resistor Spark Plug (RN4C)
150	37039	2	Valve Spring
151A	40016A	1	Intake Valve Seal
151	31673	2	Valve Spring Cap
153	36649	1	Push Rod Guide
154	650913	2	Rocker Arm Stud
155	35624A	2	Rocker Arm
157	650914	2	Nut, 1/4-28
158	36629	2	Push Rod
159	35626	1	* Rocker Arm Cover Gasket
160	37543	1	Rocker Arm Cover
161	651008	2	Screw, 1/4-20 x 31/64"
161A	651012	2	Stud
173	37544	1	Breather Tube

Ref #	Part Number	Qty	Description
178	650852	2	Nut, 1/4-20
182	650451	2	Screw, 1/4-20 x 1"
184	26756	1	* Carburetor To Intake Pipe Gasket
185	36631	1	Intake Pipe
207	36632	1	Throttle Link
211	28942	1	Screw, 10-32 x 3/8"
223	650451	2	Screw, 1/4-20 x 1"
224	36581	1	* Intake Pipe Gasket
239	27272A	1	Gasket
239A	37542	1	Carburetor Adaptor
239B	651053	1	Screw,
240	0	1	Air Cleaner Body (OEM Supplied)
245	0	1	Air Cleaner (Paper) (OEM Supplied)
252	650821	1	Screw, 10-32 x 1/2"
253	36701	1	Compression Release Weight
254	36702	1	Compression Release Spring
275	36641	1	Muffler
277	650988	2	Screw, 1/4-20 x 2-9/32"
278	36674	1	Spacer
279	650852	2	Nut & Lock Washer
280	36893	1	Heat Shield
296	34279B	1	Fuel Filter
310	36678	1	Dipstick
316A	650990	3	Screw,
325A	30200	1	Screw, 10-24 X 9/16"
380	640284	1	Carburetor (Incl. 184)
395	33607A	1	Electric Starter
416	36085	1	Spark Arrestor Kit (Incl. 417) (Optional)
417	650821	1	Screw, 10-32 x 1/2" (Optional)
600	651013	1	Washer



Ref #	Part Number	Qty	Description
14A	36288	1	Bushing
19A	36741	1	Throttle Spring
19	37111	1	Extension Spring
20	32600	1	Oil Seal
25B	36869	1	Air Baffle (Right)
25	36621	1	Air Baffle (Left)
26	30200	2	Screw, 10-24 x 9/16"
60	36623A	1	Blower Housing Extension
62	650760	1	Screw, 8-32 x 3/8"
63	28545	1	Grommet
65	30200	1	Screw, 10-24 x 9/16"
90	611216	1	Flywheel
92	650815	1	Belleville Washer
93	650816	1	Flywheel Nut
100	34443B	1	Solid State Ignition
101	610118	1	Spark Plug Cover
103A	650767	1	Screw, 8-32 x 27/64"
103	651007	2	Screw, Torx T-15, 10-24 x 15/16"
110A	36964	1	Ground Wire
110	35589	1	Ground Wire
111B	611224	1	Rocker On/Off Switch
151A	40016A	1	Intake Valve Seal
186	37541	1	Governor Link
200	37540	1	Control Bracket (Incl. 19A, 210 & 211 )
209	650821	1	Screw, 10-32 x 1/2"
210	27793	1	Conduit Clip
211	28942	1	Screw, 10-32 x 3/8"
239A	37542	1	Carburetor Adaptor
239B	651053	1	Screw,
260	37539	1	Blower Housing
261	651008	1	Screw, 1/4-20 x 31/64"
261A	650821	2	Screw, 10-32 x 1/2"
262	651008	2	Screw, 1/4-20 x 31/64"
285	35985B	1	Starter Cup
287	651008	4	Screw,
290	30705	1	Fuel Line (12.00")
291	34357	1	Fuel Line (5.00")
292	26460	3	Fuel Line Clamp
296	34279B	1	Fuel Filter
313A	35189	1	Coil Spacer
313	34080	1	Spacer
314	650873	2	screw,
315	611272	1	Alternator Coil (3 Amp DC)
316A	650990	3	Screw,
324	33177	1	Terminal
325	37471	1	Fuel Line Bracket
325A	30200	1	Screw, 10-24 X 9/16"
342	651008	2	Screw,
370A	36261	1	Lubrication Decal
370K	36695	1	Starter Decal
390	590765	1	Recoil Starter
400	36716A	1	* Gasket Set (Incl. items marked PK i n notes) Incl. (1) each of 26756, 27272A, 29673, 35626, 36581, 36624, 36715
420	730225A	1	SAE 30 4-Cycle Engine Oil (Quart)