



| Ref # | Part Number | Qty | Description |
|-------|-------------|-----|---|
| | 1 36300A | 1 | Cylinder (Incl. 2, 20, 72B & 314) |
| | 2 27652 | 2 | Dowel Pin |
| | 11 36302 | 1 | Check Valve |
| 11B | 650902 | 1 | Screw, 10-32 x 7/16" |
| 11A | 36303 | 1 | Breather Plate |
| | 15 36307 | 1 | Governor Rod |
| | 20 36301 | 1 | Oil Seal |
| | 30 36308 | 1 | Crankshaft |
| | 31 36324 | 1 | Counterbalance Gear |
| | 38 29642 | 1 | Retaining Ring |
| | 40 36312 | 1 | Piston, Pin & Ring Set (Std.) |
| | 40 36313 | 1 | Piston, Pin & Ring Set (.010" OS) |
| | 40 36314 | 1 | Piston, Pin & Ring Set (.020" OS) |
| | 41 36309 | 1 | Piston & Pin Ass'y. (Std.) (Incl. 43) |
| | 41 36310 | 1 | Piston & Pin Ass'y. (.010" OS) (Incl. 43) |
| | 41 36311 | 1 | Piston & Pin Ass'y. (.020" OS) (Incl. 43) |
| | 42 36315 | 1 | Ring Set (Std.) |
| | 42 36316 | 1 | Ring Set (.010" OS) |
| | 42 36317 | 1 | Ring Set (.020" OS) |
| | 43 35772 | 2 | Piston Pin Retaining Ring |
| | 45 36318 | 1 | Connecting Rod Ass'y. (Incl. 46) |
| | 45 36319 | 1 | Connecting Rod Ass'y. (.010" US) (Incl. 46) |
| | 45 36320 | 1 | Connecting Rod Ass'y. (.020" US) (Incl. 46) |
| | 46 650908 | 2 | Connecting Rod Bolt |
| | 48 36321 | 2 | Valve Lifter |
| | 50 36533A | 1 | Camshaft (MCR) |
| 50A | 730656 | | Camshaft Repair Kit |
| | 51 36323 | 1 | Counterbalance Weight |
| | 52 36332 | 1 | Oil Pump Ass'y. |
| 52A | 36331 | 1 | Oil Pump Shaft |
| 52D | 650888 | 3 | Screw, Torx T-30, 1/4-20 x 43/64" |
| 52C | 36334 | 1 | Oil Pump Cover (Incl. 52B) |
| 52B | 36333 | 1 | * "O" Ring |
| 60A | 650781 | 1 | Screw, 5/16-18 x 11/16" |
| 60B | 650867 | 1 | Screw, 10-24 x 1/2" |
| | 60 36361 | 1 | Air Baffle |
| | 65 30063 | 1 | Screw, Torx T-30, 1/4-20 x 1/2" |
| | 66 650737 | 1 | Screw, 1/4-20 x 1/2" |
| | 69 36565 | 1 | * Mounting Flange Gasket |
| | 70 36566 | 1 | Mounting Flange (Incl. 72,75,80,381 thru 387) |
| 72A | 28483 | 3 | Oil Drain Plug |
| 72B | 28534 | 4 | Pipe Plug |
| | 75 36301 | 1 | Oil Seal |
| | 80 35712 | 1 | Governor Shaft |
| | 81 35479 | 2 | Washer |
| | 82 36327 | 1 | Governor Gear Ass'y. |
| | 83 35322 | 1 | Governor Spool |
| | 84 29193 | 1 | Retaining Ring |
| | 86 650970 | 9 | Screw, 1/4-20 x 1-15/32" |
| | 89 650592 | 1 | Flywheel Key |
| | 90 611261 | 1 | Flywheel |
| 100 | 36344 | 1 | Solid State Ignition (Incl. 101) |
| 101 | 610118 | 1 | Spark Plug Cover |
| 102 | 650872 | 2 | Solid State Mounting Stud |
| 103 | 651007 | 2 | Screw, Torx T-15, 10-24 x 15/16" |
| 110 | 36345 | 1 | Ground Wire |
| 119 | 36337 | 1 | * Cylinder Head Gasket |
| 120 | 36488 | 1 | Cylinder Head |

| Ref # | Part Number | Qty | Description |
|-------|-------------|-----|--|
| 125 | 35308 | 1 | Exhaust Valve (Std.) |
| 125 | 35433 | 1 | Exhaust Valve (1/32" OS) |
| 126 | 35309 | 1 | Intake Valve (Std.) |
| 126 | 35432 | 1 | Intake Valve (1/32" OS) |
| 127 | 650691 | 6 | Washer |
| 128 | 650690 | 6 | Belleville Washer |
| 130 | 650946 | 6 | Screw, 5/16-18 x 2-45/64" |
| 135 | 34645 | 1 | Resistor Spark Plug (RN4C) |
| 150 | 33507 | 2 | Valve Spring |
| 151 | 33508 | 2 | Valve Spring Keeper |
| 153 | 36339 | 1 | Push Rod Guide |
| 154 | 650972 | 2 | Rocker Arm Stud |
| 155 | 35950 | 2 | Rocker Arm |
| 156 | 730636 | 2 | Rocker Arm Bearing |
| 157 | 730636 | 2 | Set Screw, 5/16-24 x 1/4" |
| 158 | 36340 | 2 | Push Rod |
| 159 | 35952 | 1 | * Rocker Arm Cover Gasket |
| 160 | 35953A | 1 | Rocker Arm Housing |
| 161 | 30063 | 4 | Screw, Torx T-30, 1/4-20 x 1/2" |
| 169 | 36304 | 1 | * Breather Gasket |
| 172 | 36305 | 1 | Valve Cover |
| 173 | 36306 | 1 | Breather Tube |
| 174 | 30063 | 4 | Screw, Torx T-30, 1/4-20 x 1/2" |
| 229 | 650825 | 2 | Nut & Lock Washer, 1/4-20 |
| 265 | 36615 | 1 | Cylinder Head Cover |
| 270A | 35829A | 1 | Exhaust Port Liner |
| 305 | 36349 | 1 | Oil Fill Tube |
| 306 | 36348 | 1 | * "O" Ring |
| 307 | 35499 | 1 | "O" Ring |
| 309 | 650974 | 1 | Screw, 1/4-20 x 57/64" |
| 310 | 36366 | 1 | Dipstick |
| 314 | 651007 | 2 | Screw, Torx T-15, 10-24 x 15/16" |
| 315 | 611181 | 1 | Alternator Coil (3/5 Split) (Incl.321 - 323) |
| 321 | 611161 | 1 | Diode |
| 322 | 611142 | 1 | Connector Body |
| 323 | 611118 | 1 | Terminal |
| 325A | 27275 | 1 | Wire Clip |
| 325 | 36342 | 1 | Wire Clip |
| 361 | 650969 | 2 | Screw, 5/16-18 x 29/32" |
| 370B | 35274 | 1 | Instruction Decal |
| 381 | 650767 | 1 | Screw, 8-32 x 27/64" |
| 382 | 36328 | 1 | Oil Strainer Screen |
| 385 | 570673 | 1 | Ball |
| 386 | 36329 | 1 | Pressure Relief Spring |
| 387 | 36330 | 1 | Roll Pin |
| 394A | 650982 | 1 | Washer |
| 395 | 36264 | 1 | Electric Starter Motor (12 Volt) |
| 400 | 36567 | 1 | * Gasket Set (Incl. items marked PK i n notes) Incl. part #'s 35952 (1), 36304 (1), (1), 36333 (1), 36335 (1), 36337 (1), 36348 (1), 36351 (1), 36352 (1), 36358 (1), 36365 (1), 36490 (1), 36565 (1) |
| 420 | 730225 | 1 | SAE 30 4-Cycle Engine Oil (Quart) |
| 475 | 36563 | 1 | Oil Filter |
| 476 | 36435A | 1 | Oil Filter Adapter (Incl. 477 & 479) |
| 477 | 650978 | 2 | Screw, Torx T-30, 5/16-18 x 1-7/16" |
| 479 | 36335 | 1 | * Oil Passage Gasket |

| Ref # | Part Number | Qty | Description |
|-------|-------------|-----|--------------------------------------|
| | 14 28277 | 2 | Washer |
| | 16 36346 | 1 | Governor Lever (Incl. 212A) |
| | 17 29916 | 1 | Governor Lever Clamp |
| | 18 650548 | 1 | Screw, 8-32 x 5/16" |
| | 19 36414 | 1 | Extension Spring |
| | 28 30322 | 1 | Lock Nut, 8-32 |
| | 35 29826 | 1 | Screw, 10-32 x 3/4" |
| | 36 29918 | 1 | Lock Washer |
| | 37 29216 | 1 | Lock Nut, 10-32 |
| | 38 29642 | 1 | Retaining Ring |
| | 60A 650781 | 1 | Screw, 5/16-18 x 11/16" |
| | 60B 650867 | 1 | Screw, 10-24 x 1/2" |
| | 92 650666 | 1 | Lock Washer |
| | 93 650594 | 1 | Flywheel Nut |
| | 178 650928 | 2 | Lock Nut, 1/4-20 |
| | 182 650925 | 2 | Carburetor Mounting Stud |
| | 184 36352 | 1 | * Carburetor To Intake Pipe Gasket |
| | 185 36489 | 1 | Intake Pipe |
| | 186 36354 | 1 | Governor Link |
| | 200 36233 | 1 | Control Bracket (Incl. 203,204,212A) |
| | 209 650902 | 2 | Screw, 10-32 x 7/16" |
| | 210 27793 | 2 | Conduit Clip |
| | 211 28942 | 2 | Screw, 10-32 x 3/8" |
| | 212A 36288 | 2 | Bushing |
| | 223 650975 | 2 | Screw, Torx T-30, 5/16-18 x 1-9/32" |
| | 224 36490 | 1 | * Intake Pipe Gasket |
| | 228 650977 | 2 | Air Cleaner Stud |
| | 229 650825 | 2 | Nut & Lock Washer, 1/4-20 |
| | 239 36358 | 1 | * Air Cleaner Gasket |
| | 240 36355 | 1 | Air Cleaner Body (Incl. 228 & 239) |
| | 245 36356 | 1 | Air Cleaner Filter (Incl. 229) |
| | 250 36359 | 1 | Air Cleaner Cover |
| | 251 650886 | 2 | Wing Nut, 1/4-20 |
| | 252 650976 | 1 | Screw, 1/4-20 x 19/32" |
| | 260 36347 | 1 | Blower Housing |
| | 262 650737 | 3 | Screw, 1/4-20 x 1/2" |
| | 263 36367 | 1 | Trim Ring |
| | 286 36343 | 1 | Cup & Screen |
| | 291A 30705 | 1 | Fuel Line |
| | 292 26460 | 1 | Fuel Line Clamp |
| | 296 34279B | 1 | Fuel Filter (Incl. 292) |
| | 326 36210 | 1 | Screen Plug |
| | 347 650949 | 3 | Screw, 10-32 x 9/16" |
| | 348 36383 | 1 | Remote Choke Bracket |
| | 370B 35274 | 1 | Instruction Decal |
| | 370 36261 | 1 | Instruction Decal |
| | 380 632698 | 1 | Carburetor (Incl. 184 & 212A) |
| | 394A 650982 | 1 | Washer |