


Ref #	Part Number	Qty	Description
	1 37525	1	Cylinder (Incl. 2,11B,20,72B & 154)
	2 27652	2	Dowel Pin
	11A 36303	1	Breather Plate
	11B 650902	1	Screw, 10-32 x 7/16"
	11 36302	1	Check Valve
	15 36307	1	Governor Rod
	20 36301	1	Oil Seal
	30 36308	1	Crankshaft
	31 36324	1	Counterbalance Gear
	38 29642	1	Retainer Ring
	40 36312	1	Piston, Pin & Ring Set (Std.)
	40 36313	1	Piston, Pin & Ring Set (.010" OS)
	40 36314	1	Piston, Pin & Ring Set (.020" OS)
	41 36309	1	Piston & Pin Ass'y. (Std.) (Incl. 43)
	41 36310	1	Piston & Pin Ass'y. (.010" OS) (Incl. 43)
	41 36311	1	Piston & Pin Ass'y. (.020" OS) (Incl. 43)
	42 36315	1	Ring Set (Std.)
	42 36316	1	Ring Set (.010" OS)
	42 36317	1	Ring Set (.020" OS)
	43 35772	2	Piston Pin Retaining Ring
	45 36318A	1	Connecting Rod Ass'y. (Incl. 46)
	45 36319A	1	Connecting Rod Ass'y. (.010" US) (Incl. 46)
	45 36320A	1	Connecting Rod Ass'y. (.020" US) (Incl. 46)
	46 651063	2	Connecting Rod Bolts
	48 36321	2	Valve Lifter
	50A 730656		Camshaft Repair Kit
	50 36533A	1	Camshaft (MCR)
	51 36323	1	Counterbalance Weight
	52A 36331	1	Oil Pump Shaft
	52B 36333	1	* "O" Ring
	52C 36334	1	Oil Pump Cover (Incl. 52B)
	52D 650888	3	Screw, T-30, 1/4-20 x 43/64"
	52 37305	1	Oil Pump Ass'y.
	60B 650867	1	Screw, 10-24 x 1/2"
	60 36361	1	Air Baffle
	60A 650273	1	Screw, 5/16-18 x 11/16"
	65 30063	1	Screw, T-30, 1/4-20 x 1/2"
	66 650737	1	Screw, 1/4-20 x 1/2"
	69 36565	1	* Mounting Flange Gasket
	70 37304A	1	Mounting Flange (Incl.72,72A,72B,75,8 0,381 -387)
	72A 28483	2	Oil Drain Plug
	72B 28534	3	Oil Drain Plug
	75 36301	1	Oil Seal
	80 35712	1	Governor Shaft
	81 35479A	2	Washer
	82 36327	1	Governor Gear Ass'y.
	83 35322	1	Governor Spool
	84 29193	1	Retaining Ring
	86 650970	9	Screw, 1/4-20 x 1-15/32"
	89 650592	1	Flywheel Key
	90 611186	1	Flywheel (W/Ring Gear)
	100 36344A	1	Solid State Ignition (Incl. 101)
	101A 611284	1	Spark Plug Shield
	101 610118	1	Spark Plug Cover
	102 651024	2	Solid State Mounting Stud
	103 651007	2	Screw, T-15, 10-24 x 15/16"
	110 36345	1	Ground Wire
	119 37493	1	* Cylinder Head Gasket

Ref #	Part Number	Qty	Description
	120 37495	1	Cylinder Head (Incl. 119,151A & 270A)
	125 35308	1	Exhaust Valve (Std.)
	125 35433	1	Exhaust Valve (1/32" OS)
	126 35309	1	Intake Valve (Std.)
	127 650691	6	Washer
	128 650690	6	Belleville Washer
	130 650946	6	Screw, 5/16-18 x 2-45/64"
	135 34645	1	Spark Plug (RN4C)
	150 33507	2	Valve Spring
151A	40046	1	Intake Valve Seal
	151 33508	2	Valve Spring Keeper
	153 36339	1	Push Rod Guide
	154 651077	2	Rocker Arm Stud
	155 35950	2	Rocker Arm
	156 730636	2	Rocker Arm Bearing
157A	650586	2	Jam Nut, 5/16-24
	158 36340	2	Push Rod
	159 35952	1	* Rocker Arm Cover Gasket
	160 35953A	1	Rocker Arm Housing
	161 30063	4	Screw, T-30, 1/4-20 x 1/2"
	169 36304	1	* Breather Gasket
	172 36305	1	Valve Cover
	173 36306	1	Breather Tube
	174 30063	4	Screw, T-30, 1/4-20 x 1/2"
262A	650802	1	Screw, 1/4-20 x 5/8"
	269 36365	1	* Exhaust Manifold Gasket
270A	35829A	1	Exhsust Port Liner
	270 36364	1	Exhaust Manifold
	271 36363	1	Locking Plate (Manifold)
271A	36371	1	Muffler Clamp
	275 36372	1	Muffler
	277 650876	2	Screw, 5/16-18 x 1-9/32"
	279 650992	2	Screw, 5/16-18 x 21/64"
	280 36373	1	Heat Shield
	294 35791	1	Pulse Pump Repair Kit
	305 36349	1	Oil Fill Tube
	306 37401	1	* "O" Ring
	307 35499	1	"O" Ring
	309 650974	1	Screw, 1/4-20 x 57/64"
	310 36366	1	Dipstick
	314 651007	2	Screw, T-15, 10-24 x 15/16"
	315 611185	1	Alternator Coil (16 Amp)(Incl. 322 & 323)
	319 650737	2	Screw, 1/4-20 x 1/2"
	320 611184	1	Regulator (16 Amp)
	322 611117	1	Connector Body
	323 611118	1	Terminal
325B	37230	1	Wire Clip
	325 36342	1	Wire Clip
	346 36413	1	Fuel Pump Bracket
	361 650969	2	Screw, 5/16-18 x 29/32"
	381 650767	1	Screw, 8-32 x 27/64"
	382 36328	1	Oil Strainer Screen
	385 570673	1	Ball
	386 36329	1	Pressure Relief Spring
	387 37652	1	Cotter Pin
	395 36795	1	Electric Starter Motor (12 Volt)
400	37496	1	* Gasket Set (Incl. items marked PK i n notes)
420	730225A	1	SAE 30 4-Cycle Engine Oil (Quart)

Ref #	Part Number	Qty	Description
475	36563	1	Oil Filter
477	650978	2	Screw, T-30, 5/16-18 x 7/16
479	36335	1	* Oil Filter Adapter Gasket



Ref #	Part Number	Qty	Description
14	28277	2	Washer
16	36346A	1	Governor Lever (Incl. 212A)
17	29916	1	Governor Lever Clamp
18	651028	1	Screw, T-15, 8-32 x 7/16"
19	36414	1	Extension Spring
28	30322	1	Lock Nut, 8-32
35	29826	1	Screw, 10-32 x 3/4"
36	29918	1	Lock Washer
37	29216	1	Lock Nut, 10-32
38	29642	1	Retainer Ring
60C	650737	1	Screw, 1/4-20 x 1/2"
60B	650867	1	Screw, 10-24 x 1/2"
60A	650273	1	Screw, 5/16-18 x 11/16"
92	651082	1	Lock Washer
93	650594	1	Flywheel Nut
110A	36917	1	Ground Wire & Terminal
157A	650586	2	Jam Nut, 5/16-24
178	650928	2	Lock Nut, 1/4-20
182	650925A	2	Carburetor Mounting Stud
184	36352	1	* Carburetor To Intake Pipe Gasket
185	36852	1	Intake Pipe
186A	36353	1	Choke Link
186	36354	1	Governor Link
200	36360	1	Control Bracket (Incl. 203,204,212A)
203	36482	1	Compression Spring
204	651019	1	Screw, T-10, 6-32 x 41/64"
209	650902	2	Screw, 10-32 x 7/16"
210	27793	2	Conduit Clip
211	28942	2	Screw, 10-32 x 3/8"
212A	36288	3	Bushing
223	650975	2	Screw, T-30, 5/16-18 x 1-9/32"
224	36490	1	* Intake Spacer
228	650977	2	Air Cleaner Stud
234	650825	2	Nut & Lock Washer, 1/4-20
239	36358	1	* Air Cleaner Gasket
240	36355	1	Air Cleaner Body (Incl. 228 & 239)
245A	36357	1	Air Cleaner Filter
245	36356	1	Air Cleaner Filter (Incl. 229)
250	36359	1	Air Cleaner Cover
251	650886	2	Wing Nut, 1/4-20
252	650976	1	Screw, 1/4-20 x 19/32"
260	36347	1	Blower Housing
262	650737	3	Screw, 1/4-20 x 1/2"
263	36367	1	Trim Ring
265A	36571	1	Cylinder Head Cover
286	36343	1	Cup & Screen
290	30705	1	Fuel Line
291	29774	1	Fuel Line
291A	29774	1	Fuel Line
292	26460	2	Fuel Line Clamp
293	35787	1	Pulse Pump (Incl. 294)
296	34279B	1	Fuel Filter (Incl. 292)
303	32958	1	Fuel Fitting
326	36210	1	Screen Plug
347	650949	3	Screw, 10-24 x 9/16"
370G	35274	1	Oil Instruction Decal
380	640330	1	Carburetor (Incl. 184 & 212A)
406A	36918	1	Solenoid Spring

Ref #	Part Number	Qty	Description
406	611221	1	Fuel Shut-Off Solenoid
485	36374B	1	Oil Filter Adapter Kit (Incl. 475,476 & 477)