


ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY OEM.

VIEW 1 OF 2


MODEL and SERIAL
NUMBERS HERE



Ref #	Part Number	Qty	Description
	1 0	1	Cylinder (Order S/B if replacement is needed)
	19 490286	1	Extension Spring
	20 510319	1	Oil Seal
	24 530110	1	Ball Bearing
	29A 530104A	1	Cartridge Bearing
	29 530150	1	Needle Bearing & Liner Set (37 Needle s)
	30 290634	1	Crankshaft
	33 330171A	1	Adapter Plate
	34 650797	4	Screw, 5/16-18 x 1/2"
	41 310283A	1	Piston & Pin Ass'y.
	42 310289	2	Ring Set
	43 310167	2	Piston Pin Retaining Ring
	45 310235B	1	Connecting Rod Ass'y. (Incl. 29, 29A & 46)
	46 650633	2	Connecting Rod Bolt
	69 510292A	1	* Cylinder Cover Gasket
	75 28427	1	Oil Seal
	77 530143A	1	Cartridge Bearing
	89A 611032	1	Adapter Sleeve
	90 611112	1	Flywheel
	92 650815	1	Belleville Washer
	93 650390	1	Flywheel Nut
	100 34443C	1	Solid State Ignition
	101 610118	1	Spark Plug Cover
	103 651007	2	Screw, T-15, 10-24 x 15/16"
	110 611138	1	Ground Wire
	119 510274A	1	* Cylinder Head Gasket
	120 250240B	1	Cylinder Head
	130 650477	6	Screw, T-30, 1/4-20 x 3/4"
	135 33636	1	Resistor Spark Plug (RJ17LM)
	169 510323A	1	* Cover Plate Gasket
	170 470153B	1	Reed & Cover Plate (Incl. 178)
	174 650579	4	Screw, T-25, 10-24 x 1/2"
	178 29752	2	Nut & Lock Washer, 1/4-28
	184 510110A	1	* Carburetor Gasket
	202 570637	1	Spring
	203 31342	1	Compression Spring
	204 650549	1	Screw, 5-40 x 7/16"
	209 650544	1	Screw, T-25, 10-24 x 7/8"
	214A 570422	1	Washer
	214 650583	1	Washer
	216 570415	1	R.P.M. Adjusting Lever
	217 570691A	1	Control Lever (Incl. 203 & 204)
	239 510206A	1	Air Cleaner Gasket
	240 450232	1	Air Cleaner Body
	245A 450205	1	Air Cleaner Filter
	245 450215	1	Air Cleaner Filter
	245B 29962	1	Screen
	246 570412	1	Bushing
	250 450216	1	Air Cleaner Cover
	251 650390	1	Jam Nut, 7/16-20
	257 650911	4	Screw, T-30, 1/4-20 x 5/8"
	258 350448	1	Blower Housing Base (Incl. 20)
	260 350449	1	Blower Housing
	261 650958	3	Screw, 1/4-20 x 7/16"
	274 510257A	1	* Exhaust Gasket
	275 390276A	1	Muffler
	277 650958	2	Screw, 1/4-20 x 7/16"
	285 590551A	1	Starter Cup

Ref #	Part Number	Qty	Description
287	650926	4	Screw, 8-32 x 21/64"
290	29774	1	Fuel Line
292	26460	2	Fuel Line Clamp
300	410273	1	Fuel Tank (Incl. 301)
301	410285	1	Fuel Cap
331	610650B	1	Toggle Switch
350	570682A	1	Primer Ass'y.
351	570656	1	Primer Line Ass'y.
355	590701	1	Starter Handle (Mitten Grip)
370A	36261	1	Lubrication Decal
370I	550206	1	Warning Decal
370K	36695	1	Starter Decal
380	640225A	1	Carburetor (Incl. 184)
390	590732A	1	Rewind Starter
400	510296C	1	* Gasket Set
420	730227A	1	2-Cycle Oil (8 oz.)

VIEW 2 OF 2



Ref #	Part Number	Qty	Description
92	650815	1	Belleville Washer
93	650390	1	Flywheel Nut
103	651007	2	Screw, T-15, 10-24 x 15/16"
251	650390	1	Jam Nut, 7/16-20
261	650958	3	Screw, 1/4-20 x 7/16"
285	590551A	1	Starter Cup
287	650926	4	Screw, 8-32 x 21/64"
370K	36695	1	Starter Decal