









Ref #	Part Number	Qty	Description
1	34975	1	Cylinder Ass'y. (Incl. 2,8,9,& 20)
2	26727	2	Dowel Pin
6	33734	1	Breather Element
7	34214A	1	Breather Ass'y. (Incl. 6,8,9,12A,12B)
8	33735	1	* Breather Gasket
9	30200	2	Screw, 10-24 x 9/16
12A	33886	1	Breather Tube
12B	34695	1	Breather Tube Elbow
14	28277	1	Flat Washer
15	30589	1	Governor Rod (Incl. 14)
16	31383A	1	Governor Lever
17	31335	1	Governor Lever Clamp
18	650548	1	Screw, 8-32 x 5/16
19	31361	1	Extension Spring
20	32600	1	Oil Seal
30	34473A	1	Crankshaft
40	34514	1	Piston, Pin & Ring Set (Std.)
40	34515	1	Piston, Pin & Ring Set (.010 OS)
40	34516	1	Piston, Pin & Ring Set (.020 OS)
41	32538B	1	Piston & Pin Ass'y. (Std.) (Incl. 43)
41	32548B	1	Piston & Pin Ass'y. (.010 OS) (Incl. 43)
41	32549B	1	Piston & Pin Ass'y. (.020 OS) (Incl. 43)
42	28986	1	Ring Set (Std.)
42	28987	1	Ring Set (.010 OS)
42	28988	1	Ring Set (.020 OS)
43	20381	2	Piston Pin Retaining Ring
45	30963B	1	Connecting Rod (Incl. 46)
46	32610A	2	Connecting Rod Bolt
48	27241	2	Valve Lifter
50	35990	1	Camshaft (BCR)
52	29914	1	Oil Pump Ass'y.
69	35261	1	* Mounting Flange Gasket
70	35651C	1	Mtg. Flange (Incl. 72,75,80,81,82,83, 311,312)
72	36083	1	Oil Drain Plug
75	26208	1	Oil Seal
80	30574A	1	Governor Shaft
81	30590A	1	Flat Washer
82	30591	1	Governor Gear Ass'y. (Incl. 81)
83	30588A	1	Governor Spool
86	650488	6	Screw, 1/4-20 x 1-1/4
89	611004	1	Flywheel Key
90	611112	1	Flywheel
92	650815	1	Belleville Washer
93	650816	1	Flywheel Nut
100	34443A	1	Solid State
103	650814	2	Screw, Torx T-15, 10-24 x 1
110	34961	1	Ground Wire
119	29953C	1	* Cylinder Head Gasket
120	34335	1	Cylinder Head
125	29313C	1	Exhaust Valve (Std.) (Incl. 151)
125	29315C	1	Exhaust Valve (1/32 OS)
126	29314B	1	Intake Valve (Std.) (Incl. 151)
126	29315C	1	Intake Valve (1/32 OS)
130	6021A	8	Screw, 5/16-18 x 1-1/2
135	35395	1	Resistor Spark Plug (RJ19LM)
150	35991	2	Valve Spring
151	31673	2	Lower Valve Spring Cap
169	27234A	1	* Valve Spring Box Gasket




Ref #	Part Number	Qty	Description
172	32755	1	Valve Spring Box Cover
174	650128	2	Screw, 10-24 x 1/2
178	29752	2	Nut & Lockwasher, 1/4-28
182	6201	2	Screw, 1/4-28 x 7/8
184	26756	1	* Carburetor Gasket
185	31384A	1	Intake Pipe
186	34358	1	Governor Link Spring
189	650839	2	Screw, 1/4-20 x 3/8
191	35040B	1	S.E. Brake Bracket (Incl. 195)
192	34966	1	Control Link
193	34965	1	Brake Spring
194	32309	1	Retaining Ring
195	610973	1	Terminal
200	35727	1	Control Bracket Ass'y. (Incl. 202 Thr u 205)
202	33802	1	Compression Spring
203	31342	1	Compression Spring
204	650549	1	Screw, 5-40 x 7/16
205	650777	1	Screw, 6-32 x 21/32
207	34336	1	Throttle Link
209	30200	2	Screw, 10-24 x 9/16
215	32410	1	Control Knob
223	650451	2	Screw, 1/4-20 x 1
224	34690A	1	* Intake Pipe Gasket
238	650932	2	Screw, 10-32 x 49/64
239	34338	1	* Air Cleaner Gasket
245	35066	1	Air Cleaner Filter
250	35065	1	Air Cleaner Cover
260	35478	1	Blower Housing
261	30200	2	Screw, 10-24 x 9/16
262	650831	2	Screw, 1/4-20 x 15/32
275	27181B	1	Muffler (Incl. 277)
277	650795	2	Screw, 1/4-20 x 2-1/4
285	35000	1	Starter Hub
287	650926	2	Screw, 8-32 x 1/2
290	34357	1	Fuel Line
292	26460	2	Fuel Line Clamp
300	35586	1	Fuel Tank (Incl. 292 & 301)
301	35355	1	Fuel Cap Ass'y.
305	35577	1	Oil Fill Tube
306	34265	1	* Fill Tube Gasket
307	35499	1	"O" Ring (Oil Tube)
309	650562	1	Screw, 10-32 x 1/2
310	35578	1	Dipstick
313	34080	1	Flywheel Key Spacer
327	35392	1	Pull-Lite Decal
380	632046A	1	Carburetor (Incl. 184)
390	590686	1	Recoil Starter
400	36206	1	* Gasket Set (Incl. items marked PK i n notes) Incl. Part #'s: 26756 (1), 27234A (1), 29953C (1), 33735 (1), 34265 (1), 34338 (1), 34690A (1), 35261 (1).

ILLUSTRATION SHOWS TYPICAL PARTS ONLY, ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY OEM.



Ref #	Part Number	Qty	Description
238	650932	2	Screw, 10-32 x 49/64
239	34338	1	* Air Cleaner Gasket
245	35066	1	Air Cleaner Filter
250	35065	1	Air Cleaner Cover
260	35478	1	Blower Housing
287	650926	2	Screw, 8-32 x 1/2
300	35586	1	Fuel Tank (Incl. 292 & 301)
301	35355	1	Fuel Cap Ass'y.
370	35167	1	Instruction Decal
390	590686	1	Recoil Starter

ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY OEM.



Ref #	Part Number	Qty	Description
19	31361	1	Extension Spring
69	35261	1	* Mounting Flange Gasket
70	35651C	1	Mtg. Flange (Incl. 72,75,80,81,82,83, 311,312)
90	611112	1	Flywheel
182	6201	2	Screw, 1/4-28 x 7/8
185	31384A	1	Intake Pipe
186	34358	1	Governor Link Spring
200	35727	1	Control Bracket Ass'y. (Incl. 202 Thr u 205)
209	30200	2	Screw, 10-24 x 9/16
223	650451	2	Screw, 1/4-20 x 1
238	650932	2	Screw, 10-32 x 49/64
241	35797	1	Air Cleaner Collar
245	35066	1	Air Cleaner Filter
250	35065	1	Air Cleaner Cover
275	27181B	1	Muffler (Incl. 277)
277	650795	2	Screw, 1/4-20 x 2-1/4