



Ref #	Part Number	Qty	Description
1	32711A	1	Cylinder (Incl. 2, 20 & 311)
2	27652	2	Dowel Pin
14	28277	1	Washer
15	30669	1	Governor Rod
16	31357	1	Governor Lever
17	31335	1	Governor Lever Clamp
18	650548	1	Screw, 8-32 x 5/16"
19A	31361	1	Extension Spring
20	32630	1	Oil Seal
25	35256A	1	Blower Housing Baffle
26	650561	2	Screw, 1/4-20 x 5/8"
30	35220	1	Crankshaft
32	650625	1	Washer
40	34528	1	Piston, Pin & Ring Set (Std.)
40	34529	1	Piston, Pin & Ring Set (.010" OS)
40	34530	1	Piston, Pin & Ring Set (.020" OS)
41	32770B	1	Piston & Pin Ass'y. (Std.) (Incl. 43)
41	32771B	1	Piston & Pin Ass'y. (.010" OS) (Incl. 43)
41	32772B	1	Piston & Pin Ass'y. (.020" OS) (Incl. 43)
42	32595	1	Ring Set (Std.)
42	32596	1	Ring Set (.010" OS)
42	32597	1	Ring Set (.020" OS)
43	27888	1	Piston Pin Retaining Ring
45	32591C	1	Connecting Rod Ass'y. (Incl. 46)
46	650662C	2	Connecting Rod Bolt (2 Each)
48	34034	2	Valve Lifter
50	32114	1	Camshaft (MCR)
52	31356	1	Oil Pump Ass'y.
60	30622A	1	Blower Housing Extension
64	30063	1	Screw, Torx T-30, 1/4-20 x 1/2"
65	650128	1	Screw, 10-24 x 1/2"
69	30684	1	* Mounting Flange Gasket
70	32460	1	Mounting Flange (Incl. 72, 75, 80 & 81)
71	31461	1	Crankshaft Bushing
72	27642	1	Oil Drain Plug
75	27897	1	Oil Seal
80	30668	1	Governor Shaft
81	30590A	2	Washer
82	30591	1	Governor Gear Ass'y. (Incl. 81)
83	30588A	1	Governor Spool
84	29193	2	Retaining Ring
86	650451	7	Screw, 1/4-20 x 1"
88	31707A	1	Spacer (Incl. 81)
89	32589	1	Flywheel Key
90	611089	1	Flywheel
92	650815	1	Lock Washer
93	8116	1	Flywheel Nut
100	34443A	1	Solid State Ignition
101	610118	1	Spark Plug Cover
102	650872	2	Solid State Mounting Stud
103	650814	2	Screw, Torx T-15, 10-24 x 1"
119	32631A	1	* Cylinder Head Gasket
120	30938A	1	Cylinder Head
125	27880A	1	Exhaust Valve (1/32" OS) (Incl. 149A)
125	27878A	1	Exhaust Valve (Std.) (Incl. 149A)
126	32783	1	Intake Valve (Std.) (Incl. 149A)
126	32784	1	Intake Valve (1/32" OS) (Incl. 149A)
127	650691	3	Washer

Ref #	Part Number	Qty	Description
128	650690	3	Belleville Washer
129	650695A	3	Screw, 5/16-18 x 2-1/4"
130	650694A	5	Screw, 5/16-18 x 2
135	33636	1	Resistor Spark Plug (RJ17LM)
149	27882	2	Valve Spring Cap
149A	32581	2	Valve Spring Cap
150	27881	2	Valve Spring
169	27896A	2	Valve Cover Gasket
170	28423	1	Breather Body
171	28424	1	Breather Element
172	28425	1	Valve Cover
173	35350	1	Breather Tube
174	650128	2	Screw, 10-24 x 1/2"
178	650517	2	Screw, 1/4-20 x 27/32"
182	650378	2	Screw, 5/16-18 x 1-8"
184	26756	1	* Intake Pipe Gasket
185	32632	1	Intake Pipe
186	32582	1	Governor Link
200	32264A	1	Control Bracket (Incl. 203 & 204)
203	31342	1	Compression Spring
204	650549	1	Screw, 5-40 x 7/16"
207	31823	1	Choke Link
209	30200	2	Screw, 10-24 x 9/16"
215	32410	1	Control Knob
224	27915A	1	* Intake Pipe Gasket
238	28820	2	Screw, 10-32 x 1/2"
239	27272A	1	* Air Cleaner Gasket
240	31691	1	Air Cleaner Body
243	650152	2	Screw, 8-32 x 3/8"
245	30727	1	Air Cleaner Filter
250	31715	1	Air Cleaner Cover
260	35885	1	Blower Housing
261	29747B	2	Screw, Torx T-40, 5/16-24 x 21/32"
265	30939A	1	Cylinder Head Cover
285	32125	1	Starter Cup
286	35009	1	Starter Screen
287	29716	4	Screw, 1/4-28 x 7/16"
305	31568	1	Oil Fill Tube
306A	26073	1	Washer
307	30139	1	"O" Ring
310	31569A	1	Dipstick
313	35189	1	Spacer
314	650873	2	Screw, 1/4-20 x 3/4"
315	611097	1	Alternator Coil (7 Amp)(Incl. 322,322 A&323)
319	650874	2	Screw, 10-32 x 15/32"
320	611098	1	Regulator
322	610921	1	Connector Body
322A	610824	1	Connector Body
323	610922	1	Terminal
361	30063	4	Screw, Torx T-30, 1/4-20 x 1/2"
370B	31495	1	Instruction Decal
370	34346	1	Lubrication Decal
370A	35532	1	Logo Decal
380	631449	1	Carburetor (Incl. 184)
390	590420	1	Rewind Starter
395	35765A	1	Electric Starter Motor (12 Volt)

Ref #	Part Number	Qty	Description
400	33239A	1	*Gasket Set (Incl. items marked PK i n notes) Incl. part #'s 26756 (1), 27272A (3),27896A (2),27915A (1),29673 (1),30684 (1),31688A (1),32631A (1), 33355A (1),35865 (3)
420	730225	1	SAE 30 4 -Cycle Engine Oil (Quart)