



| Ref # | Part Number | Qty | Description |
|-------|-------------|-----|---|
| 1 | 36084 | | Cylinder (Incl. 2, 10 & 20) |
| 2 | 27652 | | Dowel Pin |
| 6 | 36059 | | Breather Element |
| 7 | 36005A | | * Breather Cover & Gasket |
| 9 | 650836 | | Screw, 10-24 x 1/2" |
| 10 | 36002 | | Breather Body |
| 11 | 36003 | | Check Valve |
| 12 | 36001 | | Breather Tube |
| 14 | 28277 | | Washer |
| 15 | 36006 | | Governor Rod |
| 16 | 36008 | | Governor Lever |
| 17 | 31335 | | Governor Lever Clamp |
| 18 | 650548 | | Screw, 8-32 x 5/16" |
| 19 | 36103 | | Extension Spring |
| 20 | 36010 | | Oil Seal |
| 25 | 36089 | | Blower Housing Baffle (Incl. 195) |
| 26 | 650802 | | Screw, 1/4-20 x 5/8" |
| 30 | 36087 | | Crankshaft |
| 40 | 36073 | | Piston, Pin & Ring Set (Std.) |
| 40 | 36074 | | Piston, Pin & Ring Set (.010" OS) |
| 40 | 36075 | | Piston, Pin & Ring Set (.020" OS) |
| 41 | 36070 | | Piston & Pin Ass'y. (Std.) (Incl. 43) |
| 41 | 36071 | | Piston & Pin Ass'y. (.010" OS) (Incl. 43) |
| 41 | 36072 | | Piston & Pin Ass'y. (.020" OS) (Incl. 43) |
| 42 | 36076 | | Ring Set (Std.) |
| 42 | 36077 | | Ring Set (.010" OS) |
| 42 | 36078 | | Ring Set (.020" OS) |
| 43 | 20381 | | Piston Pin Retaining Ring |
| 45 | 36023 | | Connecting Rod Ass'y. (Incl. 46) |
| 46 | 650923 | | Connecting Rod Bolt |
| 48 | 36030 | | Valve Lifter |
| 50 | 36031 | | Camshaft (MCR) |
| 52 | 29914 | | Oil Pump Ass'y. |
| 69 | 36032 | | * Mounting Flange Gasket |
| 70 | 36033A | | Mounting Flange (Incl. 72, 75, 80, 81, 82, 83 & 85) |
| 72 | 36083 | | Oil Drain Plug |
| 75 | 36010 | | Oil Seal |
| 80 | 30574A | | Governor Shaft |
| 81 | 30590A | | Washer |
| 82 | 30591 | | Governor Gear Ass'y. (Incl. 81) |
| 83 | 36057 | | Governor Spool |
| 85 | 36034 | | Idler Gear |
| 86 | 650924 | | Screw, 1/4-20 x 1-9/16" |
| 89 | 611154 | | Flywheel Key |
| 91 | 611156 | | Flywheel Fan |
| 92 | 650815 | | Lock Washer |
| 93 | 650816 | | Flywheel Nut |
| 100 | 34443A | | Solid State Ignition |
| 101 | 610118 | | Spark Plug Cover |
| 103 | 650814 | | Screw, 10-24 x 1" |
| 110 | 36054 | | Ground Wire |
| 119 | 36061 | | * Cylinder Head Gasket |
| 120 | 36037A | | Cylinder Head |
| 125 | 29313C | | Exhaust Valve (Std.) (Incl. 151) |
| 125 | 29315C | | Exhaust Valve (1/32" OS) (Incl. 151) |
| 126 | 29314B | | Intake Valve (Std.) (Incl. 151) |
| 126 | 29315C | | Intake Valve (1/32" OS) (Incl. 151) |
| 130 | 6021A | | Screw, 5/16-18 x 1-1/2" |

| Ref # | Part Number | Qty | Description |
|-------|-------------|-----|---|
| 135 | 35395 | | Resistor Spark Plug (RJ19LM) |
| 150 | 31672 | | Valve Spring |
| 151 | 31673 | | Valve Spring Cap |
| 169 | 27234A | | * Valve Cover Gasket |
| 172 | 32755 | | Valve Cover |
| 174 | 650128 | | Screw, 10-24 x 1/2" |
| 182 | 650925 | | Carburetor Mounting Stud |
| 186 | 36009 | | Governor Link |
| 187 | 36035 | | * Spacer |
| 190 | 36013 | | Brake Lever |
| 191 | 36012 | | Brake Control Lever |
| 192 | 36016 | | Brake Control Link |
| 193 | 36015 | | Brake Spring |
| 194 | 36014 | | Retaining Ring |
| 195 | 610973 | | Terminal |
| 198 | 36017 | | Brake Control Lever Spring |
| 199 | 36018 | | Brake Control Lever Bushings |
| 203 | 31342 | | Compression Spring |
| 204 | 650549 | | Screw, 5-40 x 7/16" |
| 239 | 36048 | | * Air Cleaner Gasket |
| 240 | 36044A | | Air Cleaner Body (Incl. 239, 299 & 35 0) |
| 243 | 650899 | | Screw, 10-32 x 2-3/32" |
| 245 | 36046 | | Air Cleaner Filter |
| 250 | 36047 | | Air Cleaner Cover |
| 251 | 650928 | | Lock Nut, 1/4-20 |
| 252 | 650929 | | Screw, 1/4-20 x 11/16" |
| 255 | 36088 | | Speed Control Cover |
| 256 | 650983 | | Screw, 8-32 x 1/2" |
| 261 | 650737 | | Screw, 1/4-20 x 1/2" |
| 263 | 36080 | | Trim Ring |
| 275 | 36065 | | Muffler |
| 276 | 36043 | | Locking Plate |
| 277 | 650927 | | Screw, 5/16-18 x 2-11/32" |
| 279 | 650956 | | Screw, Torx T-25, 12-24 x 49/64" |
| 280 | 36090 | | Heat Shield |
| 285 | 34449 | | Starter Cup |
| 287 | 650926 | | Screw, 8-32 x 21/64" |
| 290 | 34357 | | Fuel Line |
| 292 | 26460 | | Fuel Line Clamp |
| 298 | 28763 | | Screw, 10-32 x 35/64" |
| 299 | 650900 | | "U" Type Nut, 10-32 |
| 300 | 36066 | | Fuel Tank (Incl. 301) |
| 301 | 35355 | | Fuel Cap |
| 305 | 36063 | | Oil Fill Tube |
| 307 | 35499 | | "O" Ring |
| 308 | 36040 | | Fill Tube Clip |
| 310 | 36064 | | Dipstick |
| 350 | 36045 | | Primer |
| 357 | 34985 | | Starter Rope Retainer |
| 370D | 36260 | | Primer Decal |
| 370 | 36261 | | Instruction Decal |
| 380 | 632614 | | Carburetor (Incl. 187 & 239) (Refer to Division 5, Section A, Page A8-2 or Fiche 11, Grid F-7for breakdown) |
| 390 | 590686 | | Rewind Starter (Refer to Division 5, Section C, page 36 or Fiche 11, Grid G-5 for breakdown) |
| 400 | 36062A | | * Gasket Set (Incl. items marked *) |
| 420 | 730225 | | SAE 30, 4-Cycle Engine Oil (Quart) |

OPTIONAL SPARK ARRESTOR



| Ref # | Part Number | Qty | Description |
|-------|-------------|-----|------------------------|
| 90 | 611155 | | Flywheel |
| 252 | 650929 | | Screw, 1/4-20 x 11/16" |
| 260 | 36038 | | Blower Housing |
| 261 | 650737 | | Screw, 1/4-20 x 1/2" |
| 287 | 650926 | | Screw, 8-32 x 21/64" |
| 370 | 36261 | | Instruction Decal |