


Ref #	Part Number	Qty	Description
1	0	1	Cylinder (Machined) (Order engine if replacement is needed)
2	27652	2	Dowel Pin
11A	36303	1	Breather Plate
11B	650902	1	Screw, 10-32 x 7/16"
11	36302	1	Check Valve
14	37363	1	Washer
15	37364	1	Governor Rod
15B	650738	1	Screw, 1/4-20 x 5/8"
16A	37414	1	Governor Spring Bracket
16	37413	1	Governor Lever
17C	37429	1	Breather Tube Clamp
30	37371A	1	Crankshaft
35	651069	1	Screw, Carriage 1/4-20 x 1-1/2"
37	650456	1	Lock Nut, 1/4-20
38	37365	1	Retaining Ring
40	40040	1	Piston, Pin & Ring Set (Std.)
40	40041	1	Piston, Pin & Ring Set (.010"OS)
41	40038	1	Piston & Pin Ass'y. (Std.) (Incl. 43)
41	40039	1	Piston & Pin Ass'y.(.010"OS)(Incl.43)
42	40013	1	Ring Set (Std.)
42	40014	1	Ring Set (.010"OS)
43	27888	2	Piston Pin Retaining Ring
45	37372	1	Connecting Rod Ass'y. (Incl. 46)
46	651063	4	Connecting Rod Bolt
48	37373	4	Valve Lifter
50	37773	1	Camshaft (MCR)
52E	37383	1	Oil Pump Gear
52F	37384	1	Oil Pump Gear Retaining Ring
52	37305	1	Oil Pump Ass'y.
52A	37382	1	Oil Pump Shaft
52B	36333	1	"O" Ring
52C	36334	1	Oil Pump Cover (Incl. 52B)
52D	650888	3	Screw, T-30 1/4-20 x 43/64"
60A	650773	4	Screw, 1/4-20 x 1/2"
69	37377	1	* Mounting Flange Gasket
70	37378	1	Mounting Flange (Incl. 72,72A,75,80,3 81-387)
72	31927	2	Oil Drain Plug
75	36301	2	Oil Seal (1 in Ref 1, 1 in Ref 70)
75A	37369	1	Oil Seal (Governor Shaft)
80	37379	1	Governor Shaft
81	37381	1	Washer (Governor Shaft)
82	37380	1	Governor Gear Ass'y.
83	35322	1	Governor Spool
84	29193	1	Retaining Ring
86	651064	9	Screw, 5/16-18 x 1-15/32"
89	650592	1	Flywheel Key
90	611254	1	Flywheel (Incl. 91 & 91A)
91	611241A	1	Flywheel Fan
91A	611242	1	Flywheel Retainer
92	651082	1	Belleville Washer
93	650594	1	Flywheel Nut
100	37395	2	Solid State Ignition (Incl. 101)
101	610118	2	Spark Plug Cover
102	651024	4	Solid State Mounting Stud
103	651007	6	Screw, T-15 10-24 x 15/16"
119	37388A	2	* Cylinder Head Gasket
120	37782	1	Cylinder Head, Opp. Breather Side
120A	37783	1	Cylinder Head, Breather Side

Ref #	Part Number	Qty	Description
125	37780	2	Exhaust Valve (Std.)
126	37779	2	Intake Valve (Std)
127	650691	12	Flat Washer
128	650690	12	Belleville Washer
130	650697A	12	Screw, 5/16-18 x 2-1/2"(Head Mount)
135	34645	2	Spark Plug (RN4C)
143	37774	2	Rocker Arm Housing
143A	37771	2	Rocker Arm Pin
145	651088	4	Lock Washer
146	651091	4	Screw, T-
150	27881	4	Valve Spring
151A	40016A	2	Valve Seal
151	37781	4	Valve Keeper Retainer & Cap Set
155	37769	1	Rocker Arm
156	650755	1	Adjusting Screw
157	650864	1	Lock Nut
158	37772	4	Push Rod
159	35952	2	* Rocker Arm Cover Gasket
160	37770	2	Rocker Arm Cover, Opp. Breather Side
161	30063	10	Screw, T-30 1/4-20 x 1/2"
161A	651034	2	Stud, Valve Cover Mounting
162	650947	1	Rocker Arm Jam Nut, 5/16-24
166	37777	1	Engine Shroud
169	37367	1	* Valve Cover Gasket
171	37366	1	Breather Element
172	37368	1	Valve Cover
173	37393	1	Breather Tube
212	37370	4	Bushing
253A	37424	1	Compression Release Pin
253	37376	1	Compression Release Weight
254	37375	1	Compression Release Spring
260	37775	1	Blower Housing (Black)
261	651090	2	Shoulder Screw
262	651089	1	Shoulder Screw
265A	37628A	1	Cylinder Head Cover, Breather Side
265	37627A	1	Cylinder Head Cover, Opp. Breather
270A	35829A	2	Exhaust Port Liner
286	37394	1	Flywheel Screen
287	651066	4	Screw, T-20 8-18 x 1-15/32"
290	30962	1	Fuel Line (16.75")
291C	34357	1	Fuel Line (6.75")
291	29774	1	Fuel Line (8-1/4")
291A	29774	1	Fuel Line (8-1/4")
292A	37399	1	Fuel Line Retainer
292	26460	8	Fuel Line Clamp
293	35787	1	Pulse Pump
293A	650931	2	Screw, 8-32 x 1-1/2"
295A	37422	1	Fuel Fitting
296	37768	1	Fuel Filter (Incl. 292)
303	32958	1	Pulse Pump/Fuel Fitting
305	36349	1	Oil Fill Tube
306	37401	1	* O-Ring (Oil Fill, Bottom)
307	35499	1	O-Ring Oil Fill, (Top)
309	650974	1	Screw, 1/4-20 x 57/64"
310	37421	1	Dipstick
313A	36674	2	Spacer
314	651007	2	Screw, T-15, 10-24 x 15/16"
315	611292	1	Alternator Coil (16 Amp)(Incl. 322-32 3B)

Ref #	Part Number	Qty	Description
319	651015	2	Screw, 1/4-20 x 1-1/8"
320	611184	1	Regulator (16 Amp)
322	611281	1	Connector Body
323B	611282	2	Terminal
323	611276	1	Terminal
323A	611277	1	Terminal
325	36342	1	Wire Clip
342	651031	2	Screw, 1/4-20 x 9/16"(Ref. 240 & 265)
346	36413	1	Fuel Pump Bracket
347	651093	3	Stud
347	651092	3	Screw
361	651065	2	Screw, 5/16-18 x 2-3/8"
370K	36695	1	Starter Decal
370A	35274	1	Lubrication Decal
381	650767	1	Screw, 8-32 x 27/64"
382	36931	1	Oil Strainer Screen
385	570673	1	Ball
386	36329	1	Pressure Release Spring
387	37652	1	Cotter Pin
395	37284	1	Electric Starter Motor (12 Volt)
400	37423	1	* Gasket Set (Incl. items marked PK)
428	37362	1	Spacer
475	36563	1	Oil Filter
476	36929	1	Oil Filter Adaptor (Incl. 479)
477	650378	2	Screw, T-30 5/16-18 x 1 3/32"
479	36930	1	* Oil Filter Adaptor Gasket



Ref #	Part Number	Qty	Description
16E	37417	1	Governor Idle Spring
16D	37415	1	Governor Spring, Hi-speed
16F	37418	1	Bell Crank Lever
19	37416	1	Throttle Spring
173B	37409	1	Breather Tube Fitting
173A	37410	1	Breather Tube Grommet
177	651067	4	Carbuertor Mounting Stud
184	36352	2	* Carburetor to Intake Pipe Gasket
185	37396	1	Intake Pipe (Incl. 387A)
186	37404	1	Governor Link
186A	37405	2	Choke Link
200	37400	1	Control Bracket
207	37406	1	Throttle Link
210	27793	2	Conduit Clip
211	28942	2	Screw, 10-32 x 3/8"
217	37419	1	Control Lever
218	651070	2	Screw, 10-32 x 1-1/4"
223	650971	4	Screw, T-30 5/16-18 x 7/8"
224	33515A	2	* Intake Pipe Gasket (Pipe to Head)
234	650928	4	Lock Nut, 1/4-20
238	650902	2	Screw, 10-32 x 7/16"
239	36358	2	* Air Cleaner Gasket
240	37691	1	Air Cleaner Body Assy. (Incl. 239)
245	37360	1	Air Cleaner Filter (Paper)
245B	37361	1	Air Cleaner Pre-Filter (Poly)
246	37407	6	Connector Bushing Link
250	37778	1	Air Cleaner Cover
251	37689	2	Wing Nut, 1/4-20 x 1-19/32"
255	37776	1	Control Cover
262	651089	1	Shoulder Screw
314	651007	2	Screw, T-15, 10-24 x 15/16"
323B	611282	2	Terminal
323A	611277	1	Terminal
330A	37403	1	Fuel Solenoid Wire Assembly (Black)
330	37402	1	Fuel Solenoid Wire Assembly (R & G)
347	651093	3	Stud
347	651092	3	Screw
380	640333	2	Carburetor (Incl. 184 & 428)
383	37411A	1	Carburetor Baffle
384	30200	1	Screw, 10-24 x 9/16" Self Tap
387A	37397	1	Roll Pin
406	611221	2	Fuel Shut-Off Solenoid